
TURBOCKARGERS

by Hugh MacInnes

Turbo Design – Sizing & Matching – Installation Details Controls – Carburetion – Intercooling – Water Injection Street & Race Cars – Boats – Motorcycles



TURBORHARGERS

by Hugh MacInnes

TABLE OF CONTENTS

| Introduction |
|---|
| Supercharging & Turbocharging |
| Turbocharger Design |
| Choosing the Engine |
| Choosing the Turbocharger |
| Carburetion & Fuel Injection |
| Ignition |
| Exhaust Systems 6 |
| Lubrication |
| Controls |
| Intercooling |
| Marine Engines |
| Two-Stroke Engines 106 |
| High-Altitude Turbocharging 110 |
| Installations Do's Don'ts & Maybe's . 119 |
| Tractor Pulling 128 |
| Maintenance |
| Kits & Where to Buy Them 136 |
| Exhaust Emissions 152 |
| Water Injection 157 |
| Motorcycles 160 |
| Turbocharging the Indy Engine 163 |
| Appendix |
| Glossary 168 |
| Symbols 169 |
| Y Tables |
| Altitude Chart 172 |
| Turbocharger Failure Analysis 173 |
| Acknowledgements 174 |
| Compressor Selection Chart 175 |
| Horsepower Increase Chart 175 |
| Manufacturers & Distributors 188 |
| Kit Makers & Installers 192 |



"Hurry Round Hondo" jet boat is Gale Banks Engineering's racing test bed. Engine in hull is same as the one on the cover of this book. Boat holds A.P.B.A. "K" Class (unlimited) Jet Boat 1600 meter course record: 112.5 MPH for 5 miles. Boat also won 1975 Jet Boat Nationals. Stock bore & stroke 454 CID Chevrolet big-block produced 1,067 lbs. ft. torque at 8,300 RPM; 1,687 HP at 28 lbs. boost with straight alcohol. Engine equipment includes Carillo rods, forged pistons with 1.094-inch Chrysler Nascar pins, Iskenderian roller camshaft and rocker arms, O-ringed block and heads, polished combustion chambers, stock ports, 7/16-inch pushrods. TE0-691 turbochargers and the 2-3/8 inch wastegate are AiResearch units. Banks' shop did the blue-printing and assembly and supplied the stainless-steel exhaust system featuring O-rings on cast stainless header flanges and expansion bellows to prevent stress cracking. No intercooler was used in this configuration. Boat photo by Al Bond.

Editor & publisher: Bill Fisher

Cover design:

Josh Young

Book design & assembly: Nancy Fisher

Text & caption typography: Lou Duerr, Marcia Redding

Figures:

William Pine, Erwin Acuntius


Cover photo:

Photomation


Photography:

Hugh MacInnes, Bill Fisher, Howard Fisher, others ISBN: 0-912656-49-2 Library of Congress Catalog Card No. 76-6002 H. P. Book No. 49 © 1976 Printed in U.S.A. 6-76 H. P. Books, P. O. Box 5367 Tucson, AZ 85703 602/888-2150

An independent publication—not associated with AiResearch Industrial Division of Garrett Corporation, Rajay Industries, Inc., Schwitzer Corporation, Roto-Master, or any other turbocharger manufacturer or installer, or kit builder. NOTICE: The information contained in this book is true and complete to the best of our knowledge. All of the recommendations on turbocharger sizing, matching, installation and use are made without any guarantees on the part of the authors or H. P. Books. Because design matters, engineering changes and methods of application are beyond our control, the author and publisher disclaim any liability incurred in connection with the use of this data or specific details.



Allison 1720 CID engine turbocharged by Skip Cooley might end up in an unlimited hydroplane—or in a tractor-pulling contest. Either way, expect 4000 HP on methanol fuel. AiResearch T18A turbos, Schwitzer waste gates and Aviaid scavenge pumps are part of the package. Eliminating the old gear-driven supercharger gains 200 HP. Bellows connector to turbine still needs to be connected here.



USAC Ford Race Engine 159.5 CID produces 700-900 HP. It won all USAC 500-mile races from 1969-71. Now built as the Foyt engine, this is typical of the V-8 powerplants used in some USAC Championship Cars.

Photo by McGuire Studio.

INTRODUCTION


In the introduction to my book, How to Select and Install Turbochargers, I mentioned it started out as a 10-page pamphlet but kept growing. By the time it was published it had grown to a 144-page book. After three years, it was due for a revision. This book started out as that revision. It soon became apparent that enough new items were being added to make it far more than a simple revision. So, I decided to start at the beginning and rewrite each chapter besides adding about five more.

When the original book was published there were about a half-dozen turbo-charger kits for passenger cars and light trucks. Today at least 25 kits are available for passenger cars and many more are offered for marine engines and motorcycles.

In my first book I pointed out that only a few men had successfully applied turbochargers to high-performance engines in spite of the fact that their success should have sparked interest among many more. In the short time interval between then and now, turbocharger classes have been added to the drag-race circuits, been reinstated in offshore motorboat racing, and tractor pulling has become an extremely popular spectator sport in the midwest.

Because of this rise in interest in turbocharging engines, many performance-minded people who had not considered turbocharging in the past are now thinking about trying this method of getting added power instead of the old methods of boring, stroking, special cylinder heads, etc. Inflation has rapidly increased engine-component and labor costs. Now you can turbocharge an engine to get more usable horsepower for less cost than you'd spend blueprinting a racing engine.

One of the deterrents to turbocharging a stock engine in the past was the compression ratio of the engine, particularly high-performance V-8's, was so high that



Author Hugh MacInnes speaking on his favorite subject.

very little turbocharging could be done without using an anti-detonant—even with the highest octane gasoline available. As we all know, the advent of emission controls on passenger cars has caused a considerable drop in compression ratio to reduce combustion temperatures. This lowers oxides of nitrogen in the exhaust and also allows using low-octane gasoline. The lower compression ratio means it is possible to turbocharge these engines to at least 10 pounds boost pressure without any major modifications. The compression ratio is fine for turbocharging.

I hope this book will accomplish three things: First, enable the average automotive enthusiast to turbocharge his own engine with a reasonable chance of success. Second, allow the individuals or companies who manufacture turbocharger kits for the after-market to design, build and test kits without having to go through all the cut-and-try methods that were necessary several years ago because no one had any previous know-

ledge on which to learn. Third, I hope the information contained in this book will be helpful to engine manufacturers who may consider turbocharging a small engine to do the job of a large one without sacrificing fuel economy.

Because energy conservation has become a factor equally as important as air pollution, the turbocharger can help to create engines with *minimum* exhaust emissions and *maximum* fuel economy.

Most of the book is devoted to the conventional gasoline-fueled sparkignition reciprocating engine because the vast majority of engines in this country are of that type. Anyone familiar with diesel engines knows turbochargers improve them from any viewpoint. This includes fuel consumption, smoke, noise, power output, engine life and exhaust emissions. Diesel engines have hardly made a dent in the passenger-car market—particularly in the United States—but they could become a major factor in the future because of their excellent fuel

consumption and low emissions.

Other engines with a good chance of becoming more popular are those using the so-called stratified-charge system. There are many variations of this system but the type using the Texaco Controlled Combustion System lends itself very well to the use of a turbocharger and is a candidate for the "Engine of the Future."

The hardest thing about writing a book is sitting down and doing the work of putting it together. On the other hand, it has given me the opportunity to become acquainted with many interesting people that I would never have met otherwise. In the 23 years I have been associated with turbochargers, I can truthfully say there has never been a dull day. I doubt if there are many other manufactured items that cover such a broad spectrum of mechanical engineering, including thermodynamics, metallurgy, lubrication, machine design, stress analysis, manufacturing techniques and internal-combustion engines.



AiResearch Industrial Division keeps up on the latest methods of turbocharging automobiles by making installations and testing the resulting performance.

1 SUPERCHARGING & TURBOCHARGING

Many times when discussing engines and turbocharging with hotrodders and auto enthusiasts it is assumed they are familiar with the principles involved and many things are left unsaid which should have been explained. For this reason, I will start this chapter with the basic principles of operation of a typical four-stroke cycle, internal-combustion engine showing how supercharging and, in particular, turbocharging affects its operation and output.


Standard automobile engines made in the United States are naturally aspirated four-stroke cycle, spark-ignition, with four, six or eight cylinders. The schematic cross section of one cylinder of this type engine is shown in Figure 1. This schematic, familiar to all persons who have worked with automobile engines, has the following sequence:

- A. Intake Stroke—Fuel/air charge is drawn through open intake valve.
- B. Compression Stroke—Charge compressed with both valves closed.
- C. Power Stroke—Charge ignited by spark plug pushes piston down.
- D. Exhaust Stroke—Burnt gases expelled through open exhaust.


In addition to the number of cylinders, an engine is classified by its cubic-inch displacement, usually abbreviated CID. This is the number of cubic inches of air which will theoretically flow through a four-stroke cycle engine during two complete revolutions. Because it is only a matter of time before the United States joins the rest of the world in using the metric system, engine displacement is frequently listed in cubic centimeters (cc) or liters (I). One liter is almost exactly 61 cubic inches but where both are listed on a chart in this book, I have used 60 cubic inches to the liter to make the chart a lot easier to read.

In practice, the engine does not flow an amount of air equal to the displacement because:


- 1. There is always a slight pressure drop through the carburetor.
- Intake ports and valves offer some restriction.





INTAKE A



POWER C








- 3. The exhaust stroke does not expel all burnt gases because of the clearance volume
- The exhaust valve and exhaust pipe offer some restriction.


A normal automobile engine flows only about 80% of the calculated amount of charge, called 80% volumetric efficiency or η_{vol} = 80%. It is possible to tune an engine to get higher volumetric efficiency by using the correct length intake and exhaust pipes for a given engine speed. This, coupled with oversized valves and ports and carefully designed intake and exhaust passages, make it possible to have an engine with a volumetric efficiency exceeding 100% at a certain speed. This is frequently done with racing engines but it is not practical for street use where a broad speed range is required.

Figure 2 shows a compressor added to the basic engine. This may be done either before or after the carburetor. In either case, if compressor capacity is greater than that of the engine, it will force more air into the engine than it would consume naturally aspirated. The amount of additional air will be a function of the intakemanifold-charge density compared to the density of the surrounding atmosphere. Density as used in this book is the weight of air per unit of volume. There are two basic types of compressors: Positive-displacement and dynamic. Positive-displacement types, Figure 3, include reciprocating, lobe and vane compressors. There are lesserknown types in this category. These compressors are usually driven from the engine crankshaft through belts, gears or chains. The compressor pumps essentially the same amount of charge for each revolution of the engine regardless of speed, and because it is a positive-displacement device, all of this charge must pass through the engine. Assuming the compressor displacement is twice that of a normally-aspirated engine, the intake-manifold pressure must rise to enable the engine to flow the same weight of charge delivered by the compressor. This type of supercharger has the advantage of delivering approximately the same manifold pressure at all engine speeds but has the disadvantage of using crankshaft power to drive it. The Rootstype lobe compressor also has the disadvantage of inherent low efficiency-below 50%. This causes excessive charge heating



Al Lidert and Chase Knight of Ft. Lauderdale, Florida, run this Chrysler-powered dragster. Roots blower runs at 80% normal speed and puts out only 5-10 lbs. boost. Schwitzer turbos do the rest. Engine has been run at 6 to 1 compression ratio.

Figure 2-Engine with supercharger







Figure 3—Positive-displacement compressors


and therefore higher thermal stress on the engine. The Lysholm-type lobe compressor has much higher efficiency—up to 90%—but is extremely expensive and not practical for automotive use.

The reciprocating type has been used for many years on large stationary engines. Because it usually is attached directly to the crankshaft, it runs at crankshaft speed. It is rather large and cumbersome for use in an automobile engine. The sliding-vane type is sealed internally by the vanes rubbing against the outer housing. Because of this, lubricating oil is usually mixed with the charge to prevent excessive wear on the sliding vanes. This lubricating oil lowers the fuel's octane rating. An eccentric-vane type such as the smog air pump used on many U.S. Passenger Car Engines does not require lubrication of the vanes but like the Lysholm-type is very expensive in sizes large enough for most U.S. cars.


Dynamic compressors also come in several types. Figure 4 shows an axial compressor which is basically a fan or propeller. Because it is difficult to obtain a compression ratio much higher than 1.1 in a single stage, it is necessary to have several stages when this type is used. The Latham supercharger fits this category. All dynamic compressors are inherently high-speed devices because they depend on accelerating the gas to a high velocity and then slowing it down by diffusion to obtain compression. Diffusion is the process of

Figure 4-Axial compressor





Chevrolet Corvairs were produced with a TRW turbocharger. These same turbos are now made by Rajay Industries. Cutaway photodrawing clearly shows the inlet and exhaust system connections to the turbocharger. Turbocharging raised the output of these 90 to 100 HP engines to 150 HP in 1962-64; to 180 HP in 1965-66. Corvairs represented the largest automotive use of turbochargers in history . . . about 60,000 units.



Line drawing shows ultimate simplicity of a turbocharger installation.

slowing down the gas without turbulence so velocity energy is converted into pressure energy. A centrifugal type is shown in Figure 5. This differs from the axial-flow in that the direction of the gas is changed approximately 90° and because the air is in contact with the blades of the compressor impeller for a longer period of time per stage than in an axial-flow compressor. It is possible to achieve considerably higher pressure ratio in a single stage of a centrifugal flow compressor. A 4:1 pressure ratio is not uncommon.

Although there are other types of dynamic compressors such as mixed-flow and drag-type, they are not ordinarily used for supercharging engines. I have not covered them in this book.

Because the centrifugal compressor must be driven at very high speed, it is difficult to drive from the crankshaft. As can be seen from the compressor map in Figure 6, a compressor capable of supplying a pressure ratio of 3:1 with a flow capacity large enough for a 350 CID engine, must run at around 115,000 RPM. It would require a step-up gear of higher than 20:1 on an engine running at 5,000 RPM. This is impractical, not only because of the cost of the transmission, but also because sudden changes in engine speed occurring during shifting would wipe out the supercharger gears unless a slip clutch were included in the system.

During the 1920's, gear-driven centrifugal superchargers were used with success on race cars turning out as high as 300 HP from 90 CID engines. That was 3,33 HP per cubic inch displacement. Because the gear-driven supercharger probably used about 60 HP from the crankshaft, the same engine equipped with a turbocharger would have produced about 360 HP-4 HP per cubic inch. The top race-car engines today are producing about 900 HP from 160 CID-about 5.6 HP per cubic inch or a 40% improvement in 45 years. Engine builders back in those days lacked the high-strength materials we have today, so they cooled the charge between the compressor and the engine, reducing both the thermal and mechanical load while increasing the output. Advantages of intercooling are discussed in Chapter 10.

The biggest disadvantage of the centrifugal compressor when used as a super-





Figure 5-Centrifugal compressor

Figure 6-Typical centrifugal compressor map, Rajay 300E






Figure 7-Engine driving gas turbine

charger is: Pressure output from the compressor varies considerably with compressor speed. Looking again at the typical map in Rigure 6, we see this particular compressor puts out 1:2 pressure ratio at 40,000 RPM. This represents approximately 3 pounds boost pressure at sea level. This same compressor will produce 1:92 pressure ratio at 80,000 RPM, 13.8 pounds of boost pressure. In this particular case doubling the speed increased the boost pressure over four times. A rule of thumb is: Boost pressure increases as the square of the speed of the compressor. About the only way to overcome this problem with an engine-driven centrifugal compressor is to have a variable-speed drive. The Paxton supercharger which came out in the early '50's had a variable V-belt drive actuated by the accelerator pedal. When the accelerator was in normal driving position, the supercharger ran at a relatively low speed. When the driver pressed the accelerator to the floor, an actuator decreased the supercharger-pulley size and caused it to run much faster. This system worked well but was an added complication.

In addition to its higher overall efficiency—some centrifugal compressors operate at better than 80% efficiency—the centrifugal compressor has another advantage over the positive-displacement compressor. Because it is not a positive device, it can withstand a backfire through the intake system without

damage. A backfire on a turbocharged engine is no worse than on a naturally-aspirated engine. This is not so with a positive-displacement compressor. A small backfire can usually be handled by popoff safety valves mounted somewhere between the supercharger and the engine. A large backfire may remove the supercharger completely from the engine.

Because of the inherent high speed of the centrifugal-type compressor, the size and weight of the unit are considerably less than the positive-displacement type. A complete turbocharger system capable of enabling an engine to produce over 1,000 HP weighs only about 25 pounds.

Driving a centrifugal compressor would always be a problem except that a turbine is also a high-speed device. For this reason, we can couple them directly together without the use of gears. The turbine is driven by the exhaust gases of the engine, utilizing energy usually dumped overboard in the form of heat and noise. The exhaust gases are directed to the turbine wheel through nozzle vanes as shown in Figure 7.

Many people feel this exhaust-gas energy is not free because the turbine wheel causes back pressure on the engine's exhaust system. This is true to a certain extent, but when the exhaust valve first opens, the flow through it is critical. Critical flow occurs when the cylinder pressure is more than twice the exhaust-manifold pressure. As long as this condi-

tion exists, back pressure will not affect flow through the valve. After cylinder pressure drops below the critical pressure, exhaust-manifold pressure will definitely affect the flow and the higher cylinder pressure of the turbocharged engine during the latter portion of the exhaust stroke will still require some crankshaft power. When an engine is running at wide-open throttle with a well-matched high-efficiency turbocharger, intake-manifold pressure will be considerably higher than exhaust-manifold pressure. This intakemanifold pressure will drive the piston down during the intake stroke, reversing the process of the engine driving the gases out during the exhaust stroke. During the overlap period when both valves are open, the higher intake manifold pressure forces residual gases out of the clearance volume, scavenging the cylinder. Intake-manifold pressures as much as 10 psi higher than exhaust-manifold pressures have been measured on engines running at about 900 HP. Good scavenging can account for as much as 15% more power than calculated from the increase in manifold pressure of the naturally-aspirated engine.

Exhaust-gas temperature will drop as much as 300°F. (133°C.) when passing through the turbine. This temperature drop represents fuel energy returned to the engine by the turbocharger. In summary, for a given type of fuel, more power can be obtained from an engine by turbocharging than by any other method.

2 TURBOCHARGER DESIGN

The basic function of the turbocharger is essentially the same as the first one designed by Alfred Büchi many years ago, although the mechanical design is more simple. The size for a given output is much smaller and in spite of the trend towards higher prices for everything, the price of a turbocharger per horsepower increase is much less now than it was 20 years ago.

Until 1952 most turbochargers used ball or roller bearings and an independent oil system including a built-in pump. In addition, they were water-cooled. Today's units use floating-sleeve bearings lubricated by the engine's oil and pump. They are cooled by a combination of oil and air. Turbocharger design varies from one manufacturer to another but basically all have a compressor on one end and a turbine on the other, supported by bearings in between, See Figure 8. There are seals between the bearings and the compressor and also between the bearings and the turbine. This prevents high-pressure gases from leaking into the oil drainage area of the bearing housing and eventually into the crankcase of the engine. Seals are much better known for keeping oil from leaking into the compressor or turbine housing. How well they do this job often depends on the installation.

COMPRESSOR DESIGN

The centrifugal compressor consists of three elements which must be matched to each other for optimum efficiency: The impeller, the diffuser and the housing. The compressor impeller rotates at very high speeds and accelerates the gas passing through it to a high velocity by centrifugal force. The diffuser acts as a nozzle in reverse, slowing the gas down without turbulence. This causes it to increase in pressure and, unfortunately, in temperature. The housing around the diffuser is used to collect this high-pressure gas and direct it to wherever it is used. In some cases, the housing itself is also a diffuser. Over the years, the design of compressor impellers used in superchargers has varied considerably due to "state of the art" in the thermodynamic design of compressors and in manufacturing tech-





Figure 8-Cross section of typical turbo

Rajay turbocharger internal configuration is shown in this display cutaway.






Figure 9-Simple compressor impeller

niques. Figure 9 shows a simple straightbladed impeller with no curved inducer section. This shape is relatively easy to produce by die casting, permanent-mold casting, plaster casting, or even milling. It has not become too popular because of its relatively low efficiency caused by shock losses at the inlet. Figure 10 shows a similar impeller, but with curved inducer blades. The angle of curvature at the inlet of the inducer blades is designed so the air entering the impeller will be at exactly the same angle as the blade, thereby reducing inlet losses to a minimum. Originally, this type of wheel was rather expensive to cast because it required a separate plaster core for each gas passage. These cores were then pasted together by hand to make the final mold. In more recent years this type of compressor impeller has been cast by the investment or lostwax method. When a wheel is cast by this method, a die is made similar to that for die casting except that wax is cast into the die rather than metal. The wax is then covered with liquid plaster and after the plaster has hardened, it is heated to remove the wax by melting. The molten aluminum alloy is then poured into the cavity left after the wax is removed. This process makes smooth, high-strength impellers but is still expensive.

More recently foundries have been using a process called the *rubber-pattern* process. In this method, a die similar to the wax die is constructed but instead of being filled with molten wax, it is filled with a rubber compound which solidifies in the die. This rubber pattern is then covered with liquid plaster which is allowed to harden the same as with the




Figure 10-Impeller with curved inducer

wax pattern. At this point, the process differs in that the flexible rubber pattern can be removed from the plaster after it hardens. After the rubber pattern is removed from the plaster, it returns to its original shape and may be used again. This method of casting has made possible the use of compressor impeller shapes which were not considered economical from a casting viewpoint a few years ago.

In Figure 11 we see what is known as a backward-curved compressor impeller. In this design, the blade elements are not radial but actually curved backward from the direction of rotation. Wheels of this type produce very high efficiency but do not have as high a pressure ratio for a given diameter and speed as the 90° radial wheels. Strength is inherently less than that of the 90° radial wheel because the centrifugal force at high speed tends to bend the blades at their roots. Because of the lower pressure ratio for a given speed and the inherently lower strength of this type wheel, it is not normally used at pressure ratios above 2:1.





Figure 11-Backward-curved impeller

Figure 11A-Photo of backward-curved inducer



www.TechnicalBooksPDF.com

Figure 12 shows a shrouded impeller. This design is certainly the most expensive to manufacture and is the weakest of all the designs because the blades must carry the weight of the shroud as well as their own.

Maximum efficiency of a shrouded impeller is usually very high because there is minimal recirculation from the impeller discharge back to the inducer. The low strength, high cost and tendency for the shroud to collect dirt has just about eliminated the use of the shrouded impeller in automotive use.

In 1952, the turbocharged Cummins diesel-powered race car which ran in the Indianapolis 500 had to retire from the race due to dirt buildup on a shrouded impeller. In the late 1950's when shrouded impellers were used on construction equipment, the service manual included a preventive-maintenance procedure showing how to flush soapy water through the compressor to remove dirt buildup on the shroud.

Three types of diffusers are normally used with centrifugal compressors, and they may be used singly or in combination with each other. The simplest is the scroll-type diffuser, Figure 13. It consists of a volute or snail shape around the outside of the compressor impeller. In this design, the cross-section area of the scroll increases in proportion to the amount of air coming from the impeller. When designed correctly, it slows the gas down and converts velocity energy into pressure energy.

Figure 14 shows a parallel-wall diffuser which has an increase in area from the inside diameter of the diffuser to the outside diameter proportional to these two diameters, Figure 15. In other words if R_2 is twice as great as R_1 then A_2 is twice as great as A_1 . Assuming the gas were flowing in a radial direction, the velocity at R_2 would be half that at R_1 . The gas actually flows in a spiral rather than a purely radial direction but regardless of this, the gas velocity at the outer diameter of the diffuser is considerably less than at the inner diameter.

Figure 16 is a compressor with a vanetype diffuser. The vanes are designed so the leading edge will be in line with the direction of gas flow from the impeller. From this point, vane curvature will force the gas to flow and be slowed down to




Figure 12-Shrouded impeller





Figure 13-Scroll-type diffuser





favor a specific condition. Compressors with vane-type diffusers normally have a very high peak efficiency but frequently a narrower range than a vaneless diffuser. Broadness of range is the number of different size engines on which a given compressor may be used. In each case, the diffuser increases the static pressure of the gas in the compressor. The difference between static and total pressures is shown schematically in Figure 17. A static-pressure probe is not affected by the velocity of the gas. A total-pressure probe measures the static pressure plus the velocity pressure of the gas.

Figure 15—Area increase of parallel-wall diffuser




Figure 16-Vane-type diffuser






Figure 17-Static and total pressure



AiResearch TEO670 used on championship race cars. This design does not have mechanical seal on compressor end.






Figure 18A-Example of scroll diffuser

Figure 18B-Example of vane diffuser





Figure 18C-Example of parellel-wall diffuser



The surface of the compressor impeller, the diffuser and the compressor housing are made as smooth as is economically practical. Any roughness on these surfaces may cause some of the gas to detach itself from the surface causing eddy currents which reduce the overall efficiency of the compressor. Figure 18 shows examples of various types of compressor housings and diffusers.

As mentioned earlier in this chapter, a centrifugal compressor, even a good one, will always raise the temperature of the gas when it raises the pressure. The formula for this temperature increase at 100% efficiency is:

$$T_2 = T_1 \left(\frac{P_2}{P_1}\right)^{.283}$$

 $T_1 = Inlet temperature ^\circ R$

T₂ = Outlet temperature °R

°R= °F + 460

P₁ = Inlet pressure absolute (ABS)

= Usually barometric pressure

P2 = Outlet pressure ABS

= Usually gage pressure + barometer

Example: Assume inlet temperature of 70°F.

Then

 $T_1 = 70 + 460$

 $= 530^{\circ} R$

Assume inlet pressure is 0 psig

 $P_1 = 0 + barometer$

= 0 + 14.7 psia

= 14.7 psia

Assume outlet pressure is 17 psig

 $P_2 = 17 + barometer$

= 17 + 14.7 psia

= 31.7 psia

The Theoretical outlet temperature T2

will be $T_2 = (70 + 460) \times \left(\frac{17 + 14.7}{14.7}\right)^{.283}$ $T_2 = 530 (2.16)^{.283}$

 $T_2 = 530 \times 1.214$

 $T_2 = 657^{\circ} R$ (or $197^{\circ} F$.—a temperature rise of $127^{\circ} F$.)

This calculation assumed 100% adiabatic efficiency-about as obtainable as perpetual motion. Compressors referred to in this book are capable of putting out around 70% efficiency. Although this is

very commendable for compressor impellers of three-inches diameter, it tends to increase the temperature of the compressed air still further. At 70% adiabatic efficiency, the actual temperature rise is computed:

Ideal Temp. Rise
Adiabatic Eff.

In this case, the
$$\frac{127^{\circ}}{.7}$$
 = 181°F. Adding

this to the compressor inlet temperature, 70° + 181° = 251°F. In terms useful to the end user, a supercharger compressor producing 17 psi boost pressure at sea level on a 70° day will result in an intake-manifold temperature of 251°F.

This series of calculations may look like a lot of work but most of it can be eliminated by the use of Table 1.

With the table you can calculate discharge temperature directly with simple addition and multiplication. Assume the following conditions:

Pressure Ratio r = 1.9

Compressor Efficiency

$$\eta_{\rm c} = .65$$

From Table 1 where

$$r = 1.9$$
$$y = .199$$

Ideal temperature rise

$$\Delta T_{ideal} = T_X Y$$

= $(460^{\circ} + 80^{\circ}) \times .199$
= 107.5°

Actual temperature rise

$$\Delta T_{\text{actual}} = \frac{\Delta T_{\text{ideal}}}{\eta_c}$$
$$= \frac{107.5}{.65}$$
$$= 165.4^{\circ}$$

Compressor Discharge Temperature

$$T_2 = T_1 + \Delta T_{actual}$$

= 80 + 165.4
= 245.4° F.

This means if you start with 80° F. air, compress it to a pressure ratio of 1.9 with 65% efficiency, you will end up with air at 245.4° F. If this sounds bad, a rootstype blower with 45% efficiency will produce a temperature of 319° F.

The Y Chart in Table 1 is for demonstration purposes only. A more detailed table in the appendix has pressure ratios up to 10:1. A few years ago 3:1 pressure ratio was considered more than adequate but the farm-tractor boys now run manifold pressures of over 100 psig in the tractor-pulling contests. That is not a misprint. It is actually over 100 psig intakemanifold pressure!


TABLE 1

| ŀ | Υ | r | Y | r | Υ | r | Υ | |
|-----|------|-----|------|-----|------|-----|------|--|
| 1.1 | .027 | 1.6 | ,142 | 2.1 | .234 | 2.6 | ,311 | |
| 1.2 | .053 | 1.7 | .162 | 2.2 | .250 | 2.7 | ,325 | |
| 1.3 | .077 | 1.8 | .181 | 2.3 | .266 | 2.8 | .338 | |
| 1.4 | .100 | 1.9 | .199 | 2.4 | .281 | 2.9 | .352 | |
| 1,5 | ,121 | 2.0 | ,217 | 2,5 | .296 | 3.0 | .365 | |

r = pressure ratio

 $Y = r^{.238} - 1$

Figure 19-Compressor discharge temperature vs. pressure ratio



If this method of calculating intakemanifold pressure is still too complicated, it can be done easier yet without any calculations by using the chart in Figure 19 prepared by Don Hubbard of Crane Cams.

When discussing centrifugal compressors, the terms broad range or narrow range are often used. These terms could have several meanings, but in turbocharger work it is normally the width of the compressor map at about 2:1 pressure ratio. The width of a compressor map is taken from the surge line to the 60% efficiency line. Figure 20 includes examples of compressors with narrow, normal and broad ranges. The surge area on the left side of each map is a region of pressure and flow where the compressor is unstable. Depending on the compressor, this instability will vary from a sharp banging sound, to a slush-pump-like action, to no surge at all. Normally the narrower the range of the compressor, the sharper the surge. Why not design all compressors with extremely broad ranges? This would be fine except that as a general rule the broader the range, the lower the peak efficiency. Compressors designed to operate at only one flow have a very narrow characteristic and a very high peak efficiency such as that used on an industrial gas turbine. Turbocharger compressors, on the other hand, not only must work over the broad operating range of a reciprocating engine, but must be used on engines of many different sizes so that a different compressor need not be designed for each engine. To compromise, a turbocharger compressor will normally have a flow range of about 2:1. This means maximum useful flow at 2:1 pressure ratio will be twice the flow at the surge limit—a good compromise of peak efficiency and mild surge to keep the number of different sizes to a minimum.

TURBINE DESIGN

Textbooks on turbine design normally spend several chapters on the theory of turbines shown in Figure 21. This design, known as an axial-flow turbine, has been used for almost 100 years on large steam and gas turbines. Radial-flow turbines were either casually referred to or ignored completely. The radial-inflow turbine shown schematically in Figure 22 is used almost exclusively in turbochargers with capacities up to about 1,000 HP because it is economical to produce in small sizes.





Figure 20-Flow ranges of three different type centrifugal compressors

The axial-flow turbine is used in most cases where the radial wheel is too large to cast in one piece. The normal method of manufacture is to make the disk of high-strength material and attach the turbine blades to the disk either mechanically or by welding. Turbine blades are made of material with great heat and corrosion resistance. Stationary nozzle vanes direct the gases at an angle to make the turbine rotate.

The radial-flow turbine also has a nozzle to direct the flow of gases to the turbine wheel at the best possible angle, but the distance between the trailing edge of the nozzle vanes and the turbine wheel is not as critical as for the axial-flow turbine

Figure 21-Axial-flow turbine and nozzle



because the gases will continue on at approximately the same angle as directed by the nozzle vanes. This spiral flow of fluid-a free vortex-can be observed any time we watch water go down a drain. Because of this phenomenon, the number of nozzle vanes is not critical on a radialflow turbine. By designing the turbing housing in a scroll or volute shape as shown in Figure 23, only one nozzle vane is needed. This considerably reduces the cost of building a radial-inflow turbine, although it is necessary to change-turbine housings rather than nozzles when the turbine is used in different conditions, Changing turbine housings may be awkward but it is not expensive. A small turbine housing does not cost any more to manufacture than a small nozzle. This is not true with a large turbine, and large turbochargers usually have a separate nozzle with many vanes.

The nozzle area of either an axial-flow turbine or a radial-flow turbine with multiple nozzle vanes is the cross-section of a single nozzle opening multiplied by the number of nozzle vanes. In a turbocharger, the larger the nozzle area, the slower the turbocharger will run. Example: If a turbocharger has a 1.0 in.² nozzle and is putting out too much boost at a given condition, the nozzle may be changed to an area with 1.2 in.², slowing down the turbine and reducing the boost from the compressor. If this is not enough, the area may be increased still farther to 1.4 in.² which




Figure 22—Radial-flow turbine

Figure 23-Vaneless turbine housing





Figure 24-Vaneless turbine housing with larger R



will further reduce the speed and therefore the compressor boost.

Nozzle area is measured a little differently when the single opening or vaneless turbine housing is used. In this case, the area alone shown as A in Figure 23 will not necessarily determine the amount of gas flow into the turbine. However, area A divided by R-the distance from the center of the turbine wheel to the centroid of area A-will determine the flow of the gas for a given turbine wheel. If A is increased, the turbine will slow down in the same manner as one with a multi-vane nozzle. If a housing is used with a larger R, as shown in Figure 24, A must be increased to retain the same A/R Ratio. This is important to the turbine designer but not to the user since the variation in R from housing to housing are usually insignificant. Not all turbocharger manufacturers use the A/R method of sizing turbine housings. Schwitzer uses area A only and because of this, their turbine housing sizes are not comparable to those of AiResearch or Rajay. This ratio or area is usually east or stamped into the turbine housing by the manufacturer. The thing that is important to the user is if he has a turbocharger with a turbine housing A/R of .7 and he wants to run his turbocharger slower, he knows that a turbine housing designed to fit this same turbine wheel with an A/R of .9 will definitely cause his turbocharger to run slower. On the other hand, if he wants it to run faster, he knows a turbine housing with an A/R of .6 or .5 will cause the turbocharger to run faster and give it more boost. The same is true with area alone in the Schwitzer vaneless turbine housing or any turbocharger with a multi-vaned nozzle. This is discussed further in the chapter on sizing and matching and also in the chapter on kits and where to buy them. On most turbochargers, changing the turbine housing is a simple task involving a few bolts or a V-band clamp.

Turbine designers try to use the pulse energy of gases coming from the individual cylinders to increase the boost pressure at very low speeds. This is done on large axial-flow turbines by running a separate stack from each cylinder to the turbine nozzle. This is not practical on a radial-inflow turbine so housings are divided in 180° increments as shown in Figure 25. This makes some improvement at very




Figure 25-180° divided turbine housing





Figure 27-Contour relationship for different flows



low engine speeds but the gas does have a tendency to reverse its flow due to centrifugal force when there is no high-pressure pulse in the housing.

Turbine housings designed by John Cazier Patents 3,292,364 and 3,383,092, and D. H. Connor's 3,270,495 divide the turbine housing axially, Figure 26. This prevents the gas pulses from reversing and is used on engines where high torque is desired at low engine speed.

To use both turbine-wheel and compressor-impeller castings for more than one flow size turbocharger, different contours are machined on the wheels. Figure 27 shows three different contours on both turbine and compressor. Because the turbine is not as sensitive to flow changes as the compressor, it is common for a given turbocharger model to have many more compressor-impeller variations than turbine-wheel variations. Compressor maps usually specify both the blade-tip height and the inducer diameter so an impeller may be identified even if the part number has been obliterated.

Years ago, most turbine housings were made from ductile type Ni-Resist (R) cast iron which contained somewhere between 20% and 30% nickel. It is recommended where the engine is going to run continuously at extremely high temperature, as on a track type race car or an airplane. It is also recommended for marine use because it has better resistance to corrosion from sea water than other types of cast iron.

The high cost of nickel has made it almost prohibitive to use Ni-Resist (R) in diesel-engine turbochargers or those designed for intermittent use on passenger cars. For many years turbine housings for this type application were made from a cast iron similar to that used in exhaust manifolds of automobiles and diesel engines. This material worked fairly well, but about 1960 ductile iron became available at almost the same cost as gray iron. Most turbine housings are now manufactured from this material. Ductile iron not only machines well but it can be welded more readily than gray iron.

Some of the earlier automotive-type turbine wheels were made by machining the blades from solid forgings, and the curved or exducer portion was cast from a material such as Hastelloy (R) B and welded

to the turbine wheel. The turbine exducer assembly was then bolted to the shaft. This method was expensive and time consuming so better methods had to be evolved for mass production.

The first change was to cast the turbine wheel and exducer as a single unit. This would have been done earlier but materials suitable for high stress at the temperatures encountered were not available at reasonable prices until about 1955.

The next step was to braze the turbine wheel to the shaft rather than bolt it. This method worked well but quality control was a problem because it was difficult to determine whether the braze was satisfactory until the turbocharger was run on an engine. If the braze was faulty, it was a little late to be finding out.

Since that time, several very satisfactory bonding processes have been developed, such as inert-gas welding, resistance welding and electron-beam welding. The latest method is friction welding-the turbine wheel is attached to a heavy flywheel and rotated at a high speed. The rough-turned shaft is held in a vise and simultaneously, as the motor which rotates the turbine wheel is turned off, the shaft is jammed against a stub on the center of the turbine wheel as shown in Figure 28. This whole process takes only a few seconds, and the tremendous heat generated in both the shaft and the turbine wheel weld them together solidly. Once the process time is worked out for a given wheel and shaft, the repeatability is excellent, and a good weld is achieved every time.

Another method in current use is to cast the shaft and turbine wheel in one piece. In the early days when turbochargers were run on bushings pressed into the housing, it was necessary to have extremely hard journals on the turbine shaft to keep them from wearing out quickly. With the floating-type bearings used on today's turbochargers, there is almost no contact between the bearings and the journals, and it is not necessary to have journal hardness in the range of Rockwell C60. Shafts cast integral with the turbine wheel have a hardness of about Rockwell C35 and do not seem to wear out any faster than those with harder journals. Several materials have been used in the past for turbine wheels such as 19-9 DL, Stellite 31 (R) and Stellite 151 (R) but nickel-based super




Figure 28A-Friction welding

alloys such as GMR 235 ^(R) and Inco 713C ^(R) seem to be most popular. These alloys will not corrode or melt even under extreme conditions and will usually last until a nut, or bolt or valve goes through them or they have a bad rub on a housing due to a bearing failure.


BEARING HOUSING

The bearing housing is kind of a necessary evil between the compressor and the turbine to hold the whole thing together. Although bearing housings come in many shapes and sizes, they are basically all about the same. They have a bearing or

bearings in the bore and an oil seal at each end. Many years ago, bearing housings had internal water passages to keep the bearing temperature down because Babbitt was frequently used as a bearing material. If the engine was shut down from full load, heat soakback from the turbine wheel was enough to melt the Babbitt from the bearings unless there was a water jacket in the vicinity.

Turbochargers now use either aluminum or bronze bearings and heat soakback is not critical. Water jackets have been almost eliminated.








Figure 29-Cartridge assembly cross section

Figure 30-Cross section of T04 turbocharger




Figure 29 shows a turbocharger crosssection without the compressor or turbine housing in place. These components are usually referred to as a *cartridge* or *cart*ridge assembly.

Pressurized oil enters the oil inlet and flows over and through the bearings. The clearance between the bearing and bearing housing and the bearing and the journal is about the same. Oil flowing between the bearing and the bearing housing tends to damp out vibration caused by imbalance in the turbine rotor. This imbalance, if it were great enough, would cause the journal to rub on the bearing. But the bearing has a slight bit of give due to the oil cushion, and contact between the journal and the bearing is practically eliminated. Thus, the life of the turbocharger is considerably extended.

In Figure 30, the cross-section of an AiResearch TO4 Turbocharger, some of the oil also enters the thrust bearing where it is ducted to the two thrust surfaces to lubricate the space between the thrust bearing and the thrust shoulders. After the oil has passed through the bearing, it flows by gravity to the bottom of the bearing housing where it is carried by a hose to the crankcase of the engine.

Oil enters the turbocharger from the engine at about 30 to 50 pounds pressure. After it is mixed up with air in passing through the bearings, it flows from the turbocharger with no pressure and looks like dirty whipped cream. For this reason, it is not only important to have a much larger oil-drain line than oil-inlet line but also to be sure this drain line has no kinks or traps. This subject is covered in detail in the lubrication chapter.

When the turbocharger is doing its job, i.e., supercharging the engine, the gas pressure behind the turbine wheel and that behind the compressor impeller is much greater than the pressure inside the bearing housing. Seals must be placed between the bearing housing and the other two housings. This is relatively easy on the turbine end in spite of the higher temperatures encountered because pressure in the turbine housing is always positive. The main job is to keep hot gases out of the bearing housing. This is normally done by using a piston ring in a groove at the turbine end of the shaft, Figure 31. This piston ring fits snugly in the bearing housing and does not rotate. The piston




Figure 31—Piston-ring-seal detail




Figure 32-Labyrinth-type seal

ring is also a very close fit between the two walls of the piston ring groove and does a good job of preventing the hot gases from entering the bearing housing. Some turbochargers use a labyrinth-type seal on the turbine end. Here the hot gas is prevented from entering the bearing housing by a series of dams, Figure 32.

The seal at the compressor end is a slightly different problem. On a diesel engine at idle or at very low power, the compressor will be producing practically no boost. Pressure drop through the air cleaner, even if it is in good shape, will cause a slight vacuum behind the compressor impeller. This vacuum will tend to suck oil from the bearing housing into the compressor housing. Because the oil wets all the surfaces in the bearing housing, it is very difficult to prevent it from being in the area of the compressor end seal. Even a little oil leakage into the compressor housing makes things pretty messy in a hurry. The compressor end seal in Figure 33 is designed for use on a diesel engine and does a fairly good job. This seal has a piston ring and a small centrifugal pump built into the slinger which attempts to prevent oil from reaching the seal. This works fairly well on a diesel engine where the compressor-intake vacuum is in the order of a few inches mercury. However, when a carburetor for a gasoline engine is placed upstream of the compressor, it is possible to have almost total vacuum when the engine is running at high speed and the throttle is suddenly closed. A piston-ring type seal is not satisfactory under these conditions and




Figure 33-Compressor-end piston-ring seal





Figure 34-Mechanical face seal

will leak large quantities of oil into the intake manifold of the engine. It will work as long as the carburetor is downstream of the compressor.

Turbochargers designed to be used with the carburetor upstream of the compressor usually have a mechanical face seal similar to that shown in Figure 34. Rajay has chosen to make all their turbochargers with seals of this type while AiResearch usually uses mechanical face seals only on turbochargers specifically designed for use on gasoline engines. Schwitzer has chosen to stay with the piston-ring type seal for all applications. Crane Cams, which markets the Schwitzer Turbocharger for automotive use, recommends a second butterfly downstream of the compressor as used on the Ford-powered race cars. When properly connected to the carburetor butterfly, the second butterfly prevents the compressor housing from being subjected to a high vacuum, Figure 35.

As mentioned earlier in this chapter, the first automotive-type turbochargers had bearings which were pressed into the bearing housing in the same manner as a low-speed bushing. This type of bearing becomes unstable when used with a lightlyloaded, high-speed shaft. At extremely high speeds, the center of the shaft starts to move in its own orbit in the same direction of rotation as the shaft but at somewhere below half the shaft speed. This unstable condition, known as oil whirl or oil whip, usually occurs at a speed somewhere around the natural frequency of the shaft. This is often referred to as the critical speed. The motion becomes so violent that if the end of the rotor can be observed on a test stand, it will suddenly become a blur due to the violent excursion of the center of the shaft. It will sometimes appear to move as much as one sixteenth inch. This is impossible because the clearance between the journals and the bearing may only be three or four thousandths of an inch. Once this has occurred for any length of time, examination of the bearing and journals will show severe wear on both-indicating the center of the shaft was actually moving far more than was allowed by the clearance.

Bearings were designed with many different kinds of grooves and wedges to help stabilize the condition and prevent oil whirl from occurring. Nothing worked very well until floating bearings were



SHAFT

JOURNAL

BEARING

RETAINING RING


Figure 35-Secondary butterfly to prevent vacuum at compressor inlet

adopted. As mentioned earlier in this chapter, floating bearings have about the same clearance on the outside of the bearings as they do on the inside, Figure 36. Without putting any special grooves in the bearing, it does a great job of damping vibrations caused by rotor imbalance. It is almost impossible to determine the critical speed of the rotor because there is practically no difference in the vibration level of the turbocharger when running at the critical speed. When turbochargers with fixed bearings were run on a test stand equipped with a vibration meter, .001 inch displacement was considered normal. When floating bearings were introduced, the vibration level dropped so low that the limits of acceptability were changed to about .0002-inch peak-topeak displacement.

Because these bearings are loose in the housing, they are free to rotate and are kept from moving axially either by a snap ring or a shoulder in the bearinghousing bore. This rotation causes two problems-possible oil starvation and

bearing-housing wear. Because the bearing is rotating at approximately half the shaft speed, it will rotate at about 50,000 RPM when the rotor is turning at 100,000 RPM. In spite of the fact the bearing may only have a wall thickness of about 1/8 inch, holes through the bearing walls used to supply oil to its inner surface, will act as a centrifugal pump. At 50,000 RPM the pressure differential between the inner surface of the bearing and the outer surface of the bearing may be enough to overcome the oil pressure applied from the engine. If this should occur, no oil will flow through the bearing to the journal and rapid failure will occur.

Ways have been devised to prevent this, as shown in Figure 37, a cross-section of the Schwitzer Model 3LD Turbocharger. The area of the bearing where the oil enters has a thinner wall than the rest of the bearing, thereby minimizing the pumping action. In addition, holes in this area are relatively large compared to the wall thickness, making it a very inefficient pump. In Caterpillar (R) Patent 3,058,787



E. R. Bernson attacked the problem in a different way. The oil passage which supplies the bearing has a wedge-shaped groove. This tends to increase the oil pressure as the oil is rotated from the oil-supply hole to the hole in the bearing, Figure 38.

The other problem—bearing-housing wear due to the rotating bearing—is partially solved by making the bearing housing from cast iron. Some bearing housings using full-floating bearings have been made from aluminum but they were equipped with a hardened steel sleeve in the bore. The cost of manufacturing and assembling a steel sleeve makes the use of an aluminum bearing housing prohibitive.

When floating bearings first came into general use in turbochargers, it was assumed they had to rotate, so all the units were made in this manner. Because oil flowing around the outside of the bearing does the damping rather than the rotation of the bearing, the semi-floating bearing, Rajay Patent 3,043,636 (Hugh MacInnes) is used by some manufacturers. It is kept from rotating by pinning a flange on the end of the bearing or matching the flange to an irregularly-shaped pocket in the bearing housing or the oilseal plate, Figure 39. The flange prevents the bearing from rotating and also prevents it from moving axially. The wall thickness at the end of the bearing can be used for a thrust surface. Oil which passes through the bearing then passes between the shoulders on the shaft and the ends of the bearing to lubricate the thrust bearings.

Because the bearing does not rotate, it is possible to operate turbochargers of this type with very little oil pressure. Extremely low oil pressure is not a recommended procedure, but a turbocharger which will operate under adverse conditions has certain advantages. This type bearing works very well in an aluminum bearing housing—as it does not need a hard surface on the bore of the bearing housing.

Another design feature worth mentioning is some manufacturers press or shrink the compressor impeller on the shaft while others prefer a looser fit. If the turbocharger rotates counter-clockwise viewed from the compressor end, a right-hand nut on the compressor impeller will tend to tighten during operation of the turbocharger. If the turbocharger has a clockwise rotation, a right-hand nut will





Figure 38-Bernson patent


Figure 39-Semi-floating bearing



tend to loosen during operation. Clockwise-rotation turbochargers with righthand nuts must be assembled with the nut very tight—even to the point of stretching the shaft.

Small turbochargers are all basicallysimple, rugged devices and when treated properly, will last as long as the engine. Jack Lufkin has run turbocharged cars at the S.C.T.A. Bonneville Salt Flats Speed Trials for many years, used the same turbocharger for six years without disassembling the unit. The turbo still works fine but the car was retired. On the other hand, a turbocharger which is not treated properly may only last ten seconds.

CHOOSING THE ENGINE 3




Mazda RX-3 dyno engine at AiResearch.


One of the first questions usually asked by a person interested in doing turbocharging is, "Can I turbocharge my engine?" The answer is, of course, "Yes, regardless of the make or age of the engine." The next question is usually, "How much power can I get from it?" The answer to this one—"As much as the

engine will stand." And this one is usually followed by, "At what speed will I start to get boost?" The answer here often startles the unknowledgeable, "At whatever speed you want."

The fact is, any automobile or motorcycle engine from about 30 CID (500cc) can be turbocharged with presently available units, but results will depend on how strong the engine is and how well the installation is made. There isn't an engine built today which cannot be turbocharged beyond its physical capabilities. Turbochargers have already been staged to produce intake-manifold pressures above 100 psig and this could be increased without




AiResearch turbo on 170 CID Falcon. Note special distributor, Corvair air cleaner. Split-scroll control at turbine inlet keeps boost pressure from exceeding preset levels.




Reeves Callaway's A/SR SCCA road racer. The Alex Dearborn "Deserter" dune-buggy chassis is powered by a turbocharged Corvair engine with a Porsche 911 cooling fan. Rajay turbo is fed by a Crown-adapted Weber 45DCOE carburetor with Crown water injection. Corvairs are especially easy to turbocharge because stock and special equipment is readily available. Corvair engine hotrodding and chassis modifications are detailed in "How to Hotrod Corvair Engines," an H. P. Book.

Datsun 510 with Rajay turbo and LPG carburetor.



Rajay turbocharged a 1971 Vega to interest Vega owners in performance improvement at minimal cost.




exceeding the capabilities of existing turbochargers.

Where and when maximum boost is achieved is covered in the chapter on Sizing and Matching. This should be done after it is decided what the use of the vehicle is going to be and how much time and money is to be invested. Because any engine can be turbocharged, it is not necessary to narrow the choice down to one or two models, although it is certainly easier to turbocharge an engine where a bolt-on type kit is available. However, the kit may not be designed to produce maximum horsepower at the speed you want for your application. Most kits are designed for street use and must be modified for such things as drag racing and/or track racing.

For someone turbocharging an engine for the first time, an in-line four-cylinder or six-cylinder engine presents the least problems. Those with the intake and exhaust manifolds on the same side of the head simplify the installation still further. When turbocharging an opposed or V engine, there's a problem in ducting half of the exhaust gases to the other side of the engine. Most V-6 Engines are too small to consider the use of two turbochargers but two small or medium-type turbochargers work very well on a V-8. A few years ago fours and sixes were more desirable than the eights from a cost viewpoint, because they usually had a low-compression ratio while the eights almost invariably had high-compression ratios up to 10:1. This has all changed recently because a low compression ratio is one of the ways the engine manufacturers have reduced emissions. The effect of turbochargers on engine emissions is covered in Chapter 19. When engines had high compression ratios they were designed to run well on 100octane fuel. This limited the amount of power which could be gained easily with the addition of a turbocharger. Ak Miller's rule of thumb says, "The octane requirement of an engine goes up one point with each pound of boost from the turbocharger." For example, if an engine with 8:1 compression ratio runs well on 90octane gasoline, it will require 98-octane to run with eight pounds of boost and no detonation. Anything above this may require water injection.

Because just about all production



Bruce Crower has destroked a small-block Chevy to 205 CID and added two TO4B's.


Who says you can't turbocharge a Buick straight eight? Charles Seabrook of Seabrook, New Jersey did.



engines available in the mid-70's have low compression ratios, the choice of engines which can be highly turbocharged without any major modification is unlimited.

Flathead engines disappeared with the advent of the high-compression overhead-valve engines—probably because the extra volume of the combustion chamber did not lend itself to very high compression ratios. Most of these engines had crankshafts with only one main bearing for

every two throws, and therefore, are not recommended for a big horsepower increase. It would be interesting, on the other hand, to see the results of a turbocharged flathead engine compared to an overhead-valve engine of the same displacement. It would not be surprising if the flathead engines were able to produce about the same horsepower per cubic inch with the same amount of boost pressure because turbochargers tend to be equalizers with respect to the breathing ability of the engine.



Toyota has taken their 1600 twin cam, which was originally an optional engine for the Celica (domestic market), stretched it to 1800cc's and is now offering it in three stages of tune: One with dual 44mm Solexes, one fuel injected and then the full route with a turbocharger. With the dual Solexes they claim 145 HP. Fuel injection runs it up about another ten ponies, but they won't say what they get out of the turbocharged unit.

Bob Dunham photo.

Bill Reiste says the performance of his 292 CID Chevy powered Toronado is great and he gets 21 MPG over the road. Because the front end has torsion bars, adjusting the front height for the lighter engine was no problem.

Choosing between an air-cooled and a liquid-cooled engine is not much of a problem because most engines are liquid-cooled. The VW engine takes very well to turbocharging and a 100% power increase is possible with no other engine modifications.

The biggest single problem with turbocharging air-cooled engines is keeping the heads cool. If the heads are allowed to get too hot, pre-ignition will occur which will destroy the engine in a matter of seconds. It is advisable to use a head-temperature indicator on a turbocharged aircooled engine with some kind of a buzzer or light to provide a warning before preignition occurs. Corvair Spyders had such a warning device.

The Wankel Engine has been turbo-

charged with good and bad results, the same as with reciprocating engines. In this case, detonation is to be avoided because of the detrimental effect on the apex seals.

TRANSMISSIONS


Modern three- and four-speed manual transmissions have resulted from many years of development and seem to stand up well under the increased torque produced by a turbocharged engine. It doesn't take long to find out that the turbocharged engine requires different shift points than the naturally-aspirated engine, and the manual transmission doesn't seem to care one way or the other.

Automatic transmissions are another story. These are frequently designed to accept the torque of the naturally-aspirated engine with gears and bearings strong enough to put up with considerably more horsepower. However, the shifting mechanism—internal clutches and brake bands—do not always have enough surface area to work without slipping when extra torque is available at the shift points.


A symptom of this problem occurs during a full-throttle acceleration where slippage occurs at each gear change. Slippage will get worse rather than better with time until the transmission will not even transmit the engine torque at road load. On a super highway at cruising speed, the car will suddenly slow down while the engine will speed up. One of the ways to prevent this is to tighten up the clutches and brake bands, after which a fullthrottle shift becomes a real boot in the tail. This can sometimes be overcome by changing the shift points. The problem here is the naturally-aspirated engine/ transmission combination is designed to shift, if possible, where the torque delivered before and after the shift is equal. When this is done, the shift point is almost imperceptible. The turbocharged engine, however, is a different story. Assume the engine has revved up to say 4,500 PRM before the shift and the turbocharger is putting out seven pounds boost pressure. Then if the engine drops to 3,000, the turbocharger will still be producing at least seven pounds boost instantaneously. This boost at low RPM really produces a lot of torque and causes the transmission shifting mechanism to do things it was not designed to do.

When and how the transmission shifts is usually controlled by the mechanical linkage to the carburetor and a vacuum line to the intake manifold. In addition, the transmission has a governor to sense shaft speed. Any one or perhaps all may have to be modified when the engine is turbocharged. If these changes are done by a transmission expert, and if the transmission is capable of handling the extra power, it is possible to have a very responsive setup with outstanding performance.

If it runs, it can probably be turbocharged. But as with hopping up naturallyaspirated engines, some become considerably more popular than others because the parts are available and some engines can stand a lot more overload than others. Small-block Fords, Chevys and Chrysler V-8's are all popular.



Art Nolte and Steve Hogg fielded this radical gas dragster during 1974-75. 302 CID small-block Chevrolet with two AiResearch turbos produced 1,000 HP on gasoline. Car ran best elapsed time of 7.97 seconds for the quarter mile at terminal speed of 175 MPH.



Art Nolte of Scottsdale Automotive was testing this 465 CID big-block Chevrolet with alcohol fuel as we went to press. Power development was just getting started with 1,500 HP at 7,500 RPM. Engine is equipped with 10.5 c.r. pistons. Injection is by Crower. Four Ai-Research turbos are used.

4 CHOOSING THE RIGHT TURBOGHARGER FOR THE APPLICATION

TABLE II

TURBOCHARGER APPLICATIONS

| | Category | Engine Speed Range For Maximum Torque | Duration of Power Burst | Maximum Boost Pressure psi | Fuel |
|----|-------------------------------------|--|----------------------------------|-------------------------------|---|
| 1 | Street machine As great as possible | | 10 seconds maximum | 10 | Gasoline or Propane |
| | Truck or bus | Medium to high | Continuous | 10 | or i ropane |
| | Sport fishing boat | High | Continuous | 10 | |
| П | Road racer | As great as possible | Some short, some long | 20 | Gasoline or Propane |
| | Drag racer | Medium to high | 10 seconds maximum | 1 20 | or i ropane |
| | Short-course racing boat | High | Off and on but almost continuous | 20 | |
| | Drag racing boat | High | 10 seconds maximum | 20 | |
| ш | SAME AS II AE | BOVE | | 30 | Gasoline with water-alcohol injection |
| IV | Oval track racer | Medium to high | Almost continuous | 45 | Methanol |
| | Long-course racing boat | High | Continuous | 45 | |
| | Drag-racing boat | High | 10 seconds maximum | 45 | |
| V | Farm tractor- pulling contest | Medium to high | 2 minutes | 40 | Diesel |
| VI | Farm tractor- pulling contest | Medium to high | 2 minutes | 110 | Diesel |



Author MacInnes holds a Rajay turbocharger for automotive use. These tiny 14-pound units can easily double the HP output of an engine, but it is important to select the unit with the correct compressor flow size for the engine. Matching the turbine housing to the engine is the other essential to get good performance, as explained in this chapter. MacInnes directed the design efforts at TRW where this line of turbochargers was originally created. He subsequently joined Rajay Industries as Chief Engineer where he developed the Rajay Die-Cast Bearing Housing, Patent No. 3941437. As this book went to press, he was Vice President and Chief Engineer of Roto-Master, a subsidiary of Echlin Co. This firm manufactures replacement turbochargers and parts.


Using the correct turbocharger on an engine creates more power than by any other means. However, putting any turbocharger on an engine does not guarantee good results. If a turbocharger is a good match for a 200 CID Engine at 4,000 RPM, it will probably not be a good match for a 400 CID Engine at 4,000 RPM. Some people have the notion that by running the turbocharger twice as fast, it will work on an engine twice as large. It just isn't so. A look at any of the compressor maps in the appendix of this book will show you the turbocharger speed lines are relatively horizontal in the operating range, and increasing the speed of the turbocharger increases the pressure ratio rather than the flow. Turbocharger speed is varied by changing the turbinenozzle size but if the compressor is not sized correctly to the engine, changing

the turbine nozzle will not help. This process was described in my earlier H. P. Book, How To Select and Install Turbochargers. However, it is apparent from talking to many hot-rodders that they don't feel confident in doing it by this method. Therefore, I've included a selection of turbochargers to be used on most of the popular engines for different applications. It's at the end of this chapter. If your engine is not listed, pick the closest size available—you'll find it will be a good match.

For the sake of those willing to go through the process of choosing the right size turbocharger for their engine, it is covered in detail in the next few pages similar to that in the previous book but presented in a manner which should make it easier to follow. Don Hubbard of Crane Cams suggests that turbocharged

engines be classified by application because the user will want to achieve maximum torque and horsepower at an engine speed dependent on the application as shown in Table II.

Table II is very useful in matching the correct compressor to the engine and takes into account whether the engine is to be run at steady power as in an offshoreracing boat or on-and-off as in a roadracing machine. This information is important when choosing the turbinenozzle size or deciding whether or not to use a waste gate or other controls. Table II points out the engine-speed range necessary for various applications and the power-burst duration. The engine speed selected, plus the required intakemanifold pressure are the key factors in choosing the compressor for the engine. Figures 40 and 41 have been included so



John Goddard's 1928 8-liter Bentley resides in a 3.5-liter chassis. Antique engines are not ordinarily selected for turbocharging because components are not capable of handling high HP outputs. Two Ai-Research turbos with seals on the compressor side suck fuel from SU carburetors. "Blower Bentleys" are famous, but this is the only turbocharged one.





Figure 40—Naturally-aspirated volume flow for 4-cycle engines. Dotted line is for a 350 CID engine at 5000 RPM, See text.





volume flow at the peak conditions may be calculated with the least effort. For example, start with 350 CID engine in Application II, running on gasoline with a 7:1 compression ratio at 18 psi boost, It is desired to meet these conditions at 5,000 PRM. On Figure 40, start at 350 CID as shown on the dotted line and draw a line vertically to intersect the 5,000-RPM line. At this point, draw a horizontal line left to intersect the volume-flow scale. In this case the engine will flow 410 CFM. This chart has been compensated for a volumetric efficiency of 80%, a good round figure for average engines. Figure 41 is Compressor Density Ratio vs. Pressure Ratio for Air. Because the turbocharger compressor squeezes-the air down considerably from ambient conditions, this chart is necessary to determine the amount of air entering the compressor. All centrifugal-compressor maps are based on inlet conditions. To use the chart, it is first necessary to convert boost pressure to pressure ratio. Assuming the engine is to be run at approximately 1,000-feet altitude where the ambient pressure is 14.3 psia (Appendix page 173), the pressure ratio is computed:

Ambient Pressure + Boost Pressure

Ambient Pressure = Pressure Ratio $\frac{14.3 + 18}{14.3} = 2.26$

Most of the running done on turbochargers available today will be between 60% to 70% compressor efficiency, and only these two lines are shown on the chart. Draw a vertical line from 2.26 pressure ratio until it intersects one of the efficiency lines. In this case, we will split the difference and bring it up to about 65%. From this point, draw a horizontal line to the left to intersect the density-ratio scale, The density ratio is 1.62. Going back to Figure 40, the naturally-aspirated volumeflow chart where we obtained 410 CFM, multiply 410 by 1.62 density ratio to get 664 CFM at 2.26 pressure ratio. Looking at the Rajay Model 300E Map, Figure 42, we see this point is off to the right of the map. Any point falling below 60% compressor efficiency is to be avoided. However, if two turbochargers were used on this engine with 332 CFM each at 2.26 pressure ratio, this point looks very good on Rajay 300F map, Figure 43, where it

Figure 42-Rajay Model 300E compressor map





Figure 43-Rajay Model 300F compressor map









Figure 44-Schwitzer Model 4LF556 compressor map





Typical 159 CID Offenhauser engine with AiResearch turbocharger and waste gate.








Figure 47-Schwitzer Model 3LD305 compressor map





Figure 48-Schwitzer Model 3LD279 compressor map







Figure 49-Schwitzer Model 3LD198 compressor map

Figure 50-AiResearch TO4B V-1 Trim compressor map

Chuck Sarson started with a car like Tom Keosababian's, but with a different aim in mind. Chuck's Corvair held the AHRA National Record for Formula I R/Stock at 12.60 seconds and 114.79 MPH for the quarter-mile drags. Chuck built his own waste gate (page 81 in Controls chapter) and his own water-injection system.





falls in an area of better than 68% efficiency. Plotting this point on the Schwitzer Map, shows a single Schwitzer Model 4LE556—Figure 44, or 4MD459—Figure 45, or 4LE444—Figure 46, would all work very well. The 4LE444 is probably the best match because the point is well away from the surge line but still in a highefficiency area. The 3LD-305 in Figure 47 would be borderline and anything smaller in the three-inch size could not be considered as a single unit. Here again if we decide to use two turbochargers where only 332 CFM is required per turbocharger, all the Schwitzer four-inch sizes shown here would be too large. The operating point would fall on the surge line of the 3LD279-Figure 48. In this case, the 3LD-198-Figure 49 would be ideal for a dual installation.

If the AiResearch T04B Model is used, the V-1 trim, Figure 50 is borderline for a single installation. However, an S-3—Figure 51 or E-1—Figure 52 trim will work very well on a dual installation.

What this points out is: More than one model or make of turbocharger will frequently do a good job for a specific application and the engine builder is not limited to one particular size and is not forced to compromise and choose a turbocharger which is not a good match for the engine.

Another decision to be made is whether to use one or two turbochargers. If the engine is a small in-line four, it is easy to decide on one. Even an in-line six looks good with one unless the desired output is very high. When it comes to a V or opposed engine other factors must be considered. If one unit is to be used, you have to pipe the exhaust gases from one side to the other, or at least join the two exhaust manifolds. Because the exhuast pipes get considerably hotter than the rest of the engine, they will expand more and unless some sort of flexibility is built in, they will eventually crack and leak exhaust pressure. Using two smaller units eliminates this problem because the system need be connected only on the compressor side. In addition to this, it is often easier to fit two small turbochargers under the hood than one large one.





Figure 51—AiResearch TO4B S-3 Trim compressor map Figure 52—AiResearch TO4 E-1 Trim compressor map



Besides installation problems, the inertia of the rotor should also be considered. One of the standard complaints about the turbochargers is, "They lag behind the engine." This can occur due to poor carburetion or ignition timing but reducing rotor inertia is a step in the right direction.

As soon as the throttle is opened there is a sudden increase in exhaust-gas volume and the turbocharger accelerates rapidly. Total time required to reach maximum speed is a function of overall turbocharger efficiency and the polar moment of inertia of the rotating group. Moment of inertia is the resistance of a rotating body to a change in speed, represented by the letter I

$$I = \mathbf{K}^2 \mathbf{M}$$

where K is the radius of gyration and M is the mass of the body. Radius of gyration is the distance from the rotating axis to point where all the mass of the body could be located to have the same I as the body itself. In other words, a turbine wheel one foot in diameter might be represented by a ring with a diameter of 7 inches. In this case, K = 3.5 inches, Figure \$3.

For good rotor acceleration it is essential to have the lowest possible moment of inertia. Turbine wheels are designed with a minimum of material near the outside diameter to reduce K because the moment varies as the square of K.

Because of this, it is often advantageous to use two small turbochargers rather than one larger one. As an example, a 3-inch diameter turbine weighing one pound with a K of 1-inch will have a moment of inertia

$$I = K^2 M$$
$$= K^2 \frac{W}{G}$$

were G is the acceleration of gravity and W is the weight

$$I = 1 x \frac{1}{386}$$

= .00259 in. lb. sec.²

If one larger turbocharger is used instead of two small ones, it may have a turbine diameter of 3.5 inches and a rotor weight of about 1.5 lbs. Assuming a radius K of 1.25 inches, the moment of inertia will be




Figure 53—Turbine wheel and representative ring with same moment of inertia

$$I = K^{2} \frac{W}{G}$$

$$= \frac{1.25^{2} \times 1.5}{386}$$

$$= \frac{1.56 \times 1.5}{386}$$

$$I = .00607 \text{ in. lb. sec.}^{2}$$

This is about 2 1/2 times as great as the smaller turbocharger. Where turbocharger acceleration is important, I recommend you use two small units instead of one large one.

One of the toughest applications is that of the road racer. There are times when the car is making a turn with the throttle closed and the turbo running at low RPM. The throttle will then be opened wide and the engine will immediately demand, for example, 100 CFM of air. As shown on the compressor map in Figure 54, this will happen with no boost. The turbocharger will immediately accelerate but will not catch up with the engine until steady-state conditions are achieved, which may not occur if the

time between maximum acceleration and shut-off is very short.

The fact that the turbocharger is not mechanically connected to the engine and must overcome inertia has some advantages as well as disadvantages. Many applications, including drag racing, require gear shifting. This time we will look at the path on the compressor map Figure 55, which represents this application.

The vehicle will be on the line with no boost and start out similar to the previous illustration. When the shift is made, the engine speed will drop off while turbocharger speed remains constant. Because the compressor puts out more boost at the lower flows, there will be an immediate increase in manifold pressure. This occurs at each shift point and gives the car a noticeable push. Dotted lines parallel to the turbocharger speed lines are drawn to show how much boost increase will occur at each shift point. These curves are general and the actual amount will depend on the engine/turbocharger/gear combination.

Sizing and matching a turbocharger for a short-duration application must take into account both the maximum boost desired and turbocharger acceleration. A bus or truck engine must be matched so the engine can live with the maximum boost which will occur when climbing a long hill. A drag-race engine has to produce full power for only a few seconds, and the turbocharger must be matched not only for a higher boost but for the acceleration lag as well.

There is no set rule on how to arrive at a perfect match, and each application must be matched either by "cut and try" or experience. This is where the selection chart at the end of this chapter will prove very useful. The fellows who supplied the information have done it based on actual experience. The main thing is to know which way to go after some results have been obtained.

The first requirement is to find out how much air will flow through the engine at maximum speed. This leads to the question: What is the maximum speed? In general, the cam will determine the best engine speed and the turbocharger is matched to increase output at that speed. One comment along this line is that a turbocharged engine does not always require as much valve overlap as a naturally-aspirated engine. Too much overlap can actually reduce the output by cooling down the exhaust gases, which in turn will slow down the turbine and therefore produce less boost.

As mentioned earlier in this chapter, many turbocharger enthusiasts don't like the idea of going through a lot of calculations to determine which size unit to use for their particular application. For those who are interested, the following example goes through the whole process longhand and I used this kind of calculation to derive the charts at the end of the chapter.

First of all, we must start with some known quantities:

Engine Size 250 CID
Four Stroke Cycle
Maximum Speed 5,000 RPM
Maximum Boost Pressure 10 psig
Ambient Temperature 70°F. (530°R)
Barometer 29.0 in HG





Figure 54-Path followed during extreme acceleration

Figure 55-Path followed during upshifting



Start by converting the displacement to cubic feet per revolution.

$$\frac{250 \text{ cu. in.}}{1728 \text{ cu. in./cu. ft.}} = .145 \text{ cu. ft.}$$

Next calculate the ideal volume flow through the engine.

$$\frac{.145 \text{ cu}}{\text{Rev.}} \frac{\text{ft.}}{2} \times \frac{5,000 \text{ RPM}}{2} = 362.5 \text{ CFM}$$

Speed is divided by 2 because this is a four-stroke-cycle engine. This engine should flow 362.5 CFM if the volumetric efficiency (η_{vol}) is 100%.

Because of restrictions through the ports and residual gases left in the clearance space between the piston and the head, this engine will probably flow only about 80% of its theoretical capacity, known as .8nvol.

362.5 CFM x .8
$$\eta_{vol}$$
 = 290 CFM Actual

Because air entering the intake manifold will not be at standard conditions (29,92) in. Hg and 60°F.), it is necessary to compute the actual density to determine air flow through the turbocharger compressor. All compressors are rated on inlet flow so the outlet flow (engine flow) must be multiplied by the density ratio across the compressor to determine the inlet flow. It would be nice if we could just multiply the outlet flow by the pressure ratio but unfortunately the temperature rise which accompanies the pressure rise makes the gas less dense than it would be if the temperature remained constant. This is discussed in detail in the chapter on Intercooling.

Assuming 65% compressor efficiency, calculate the density of the intake manifold air:

Pressure Ratio =
$$\frac{\text{Manifold Pressure Abs}}{\text{Inlet Pressure Abs}}$$

$$= \frac{10 \text{ psig} + \text{Barometer}}{\text{Barometer}}$$

$$= \frac{(10 \times 2.03) + 29.0}{29.0}$$

$$= 1.7$$
From Table I Page 17
Where $R = 1.7$
 $Y = .162$
Ideal Temp. Rise ΔT_{ideal}

$$= Y \times T_{t}$$
Because inlet temp. is $70^{\circ}F$.

 $\Delta T_{\text{ideal}} = .162 \text{ x } (70^{\circ} + 460^{\circ})$

It is necessary to add 460° to the temperature because this calculation must be in absolute temperature; i.e., degrees Rankine.

 $\Delta T_{ideal} = 85.9^{\circ}$

Actual Temp. Rise,

$$\Delta T_{actual} = \frac{\Delta T_{ideal}}{Comp. Eff.}$$
$$\Delta T_{actual} = \frac{85.9}{65}$$

 $\Delta T_{\text{actual}} = 132^{\circ}$ Intake-manifold Temp.

= compressor inlet temp. + Tactual

$$= 70^{\circ} + 132^{\circ}$$

 $= 202^{\circ} F.$

Air in the intake manifold will not actually get this hot because fuel has a cooling effect. Hopefully, there will also be some heat loss through the ducting.

Comparing this to the air at the compressor inlet will result in the density ratio.

Density Ratio

$$= \frac{\text{Comp. Inlet Abs. Temp.}}{\text{Comp. Outlet Abs. Press}}$$

$$\times \frac{\text{Comp. Outlet Abs. Press.}}{\text{Comp. Inlet Abs. Press.}}$$

$$= \frac{70 + 460}{202 + 460} \times \frac{20.3 + 29.0}{29.0}$$

$$= \frac{530}{662} \times \frac{49.3}{29.0}$$

Density Ratio

= 1.36

Comp. Inlet Flow

= Comp. Outlet Flow (Engine Flow)

x Density Ratio

 $= 290 \text{ CFM } \times 1.36$

= 394.4 CFM

If you are using a compressor map scaled in Lbs./Min. rather than CFM it is necessary to convert by multiplying by .069 to obtain the correct flow because most Lbs./Min. compressor maps are run at 85°F, and 28.4 in, Hg.

For convenience reasons, all the maps in this book are scaled in cubic feet per minute.

The above calculations show 394.4 CFM flowing through the compressor at 1.7:1 pressure ratio. It would be desirable to have this point on the right (high-flow) side of the map because it will occur at maximum engine RPM. Try plotting this point on several maps to determine which is best. No doubt any one of several will do the

job so the user will have a choice. Starting in alphabetical order, the AiResearch TO4B V-1 trim looks very good because it will produce this flow and pressure ratio at about 73% compressor efficiency.

A Rajay 300E flow will also work well with airflow to spare.

Schwitzer's 3LD-279 is a little on the small side, but the 4LE-556 should work very well.

This is not an attempt to limit the user to these makes of turbochargers but it is very difficult to match one to an engine without a compressor map or from previous experience with another engine.

It is best to start with a large turbine housing A/R or nozzle area because one too small might overboost on the first run and destroy the engine. If the housing is too large, the boost pressure will be low but at least the engine will be intact.

If the engine is operated with the largest possible carburetor and the lowest possible exhaust restrictions, it will have a wide-open-throttle acceleration line like the solid line on the compressor map in Figure 56. This leaves something to be desired at the mid-range but if a smaller turbine nozzle is used, the engine will be overboosted at maximum RPM. This can be overcome by using a control device such as a wastegate but these are expensive and hard to come by. Controls and their application are covered in Chapter 9.

It is possible to have a more desirable wide-open-throttle operating line, as shown by a dotted line in Figure 56, without using a movable control. Any one or a combination of the methods described here will improve the mid-range torque without over boosting at maximum engine speed.

CARBURETOR VENTURI SIZE LIMITATION

If a carburetor is used which has a pressure drop of about 4 in. Hg at the 5,000-RPM point, the depression at the compressor inlet will make it necessary to use a smaller turbine housing of perhaps A/R. 8 to achieve the original boost level of 10 psi. This carburetor will have a lower pressure drop at the lower speeds and the smaller turbine housing will still deliver adequate boost. This arrangement would follow a speed line similar to the dotted line on Figure 56. The use of a smaller A/R turbine housing will cause more

back pressure on the engine, which might raise exhaust-valve temperature. This is only critical when the engine is used for steady-state high-output.

EXHAUST MUFFLER RESTRICTION

A similar result may be obtained by restricting the turbine exhaust, causing a back pressure on the turbine of about 4 in. Hg at maximum speed. Although a turbocharged engine is relatively quiet without the use of a muffler, this will result in an even quieter running engine.

VALVE TIMING AND DURATION

A valve cam profile which favors a certain engine speed naturally aspirated, will have the same tendency turbocharged. Our theoretical engine will reach peak boost at 5,000 RPM but if the cam and valve train are designed to favor 4,000 RPM, it is possible to match the turbine housing so the boost again will follow the dotted line on the compressor map, Figure 56.

One of the measures of overall turbocharger performance is the amount of positive differential across the engine. This differential occurs when intake-manifold pressure is higher than exhaust-manifold pressure and it is extremely beneficial to the engine. In the case of a diesel engine, when both intake and exhaust valves are open, this positive differential blows cleanrelatively cold—air through the clearance area over the piston and drives out any unburned exhaust gases which might still be there. As a result, it cools the engine and provides extra air-which in turn allows more fuel to be burned without increasing exhaust-gas temperature. This contributes to longer turbo life. No raw fuel is ever blown into the exhaust system because all diesels have cylinder-type fuel injection.

Gasoline engines, on the other hand, seldom have cylinder injection. Almost all gasoline and LPG engines have either carburetors or port injection.

Either of these systems work well with a moderately turbocharged engine because the combination of intake and exhaust restrictions and the fact that most turbocharging takes place only under extreme acceleration conditions causes the exhaust-manifold pressure to be higher than intakemanifold pressure at all times.

If steady-state conditions of high-pressure turbocharging occur with a carburetor





Figure 56-300 CID engine on compressor map

Sid Cook turbocharged his 390 CID Ford engine in a motorhome. Hobbs switch at left side of carburetor senses manifold pressure. Fuel is supplied directly from pump into venturis under boost. See page 51 for more details on this method.



and exhaust system having a very low restriction—and a high-overlap cam—it is possible to blow a mixture of air and fuel through the clearance space into the exhaust manifold. This can cause either of two things-or both! This mixture can be ignifed by the hot exhaust manifold and explode intermittently and/or it can burn continuously. If it explodes, it may cause a power loss and possibly harm the engine and turbocharger. If it burns continuously, it is possible to have turbineinlet temperatures of 2,000°F., which will definitely shorten the life of the turbo and exhaust valves. If the valve overlap can be reduced without losing power, the tendency to blow raw fuel into the exhaust manifold will also be reduced.

Reducing the size of the turbine wheel to one of lower capacity may also help if it is large enough to handle the gas flow at maximum engine RPM with a little higher back pressure.

The final matching of a turbine nozzle size to obtain best overall performance is often done on a dynamometer. If the end product is to be used on a truck, sportfishing boat, or other steady-state application, this is undoubtedly the best way to go. There are a couple of drawbacks for most of us, namely cost and the application is not steady-state. The larger engine manufacturers have dynamometers which can be programmed to simulate acceleration conditions. These are not usually available to the average hot rodder and even if they were, the cost would be prohibitive.

They say, "Necessity is the mother of invention," so naturally somebody has come up with an accurate method of measuring horsepower in the vehicle and depending on the amount of information desired, this can be a simple or rather elaborate set-up. In either case, it is far less costly than a programmed dynamometer. I call it the Griffin System because Dick Griffin was the first to tell me how to do it.

The basic idea is to mount a reliable accelerometer in the vehicle and use the weight of the vehicle to resist the acceleration. An aircraft-type accelerometer won't work because the divisions are too small. The maximum scale reading should not be greater than 1 G. and most readings will be below .3 G if the vehicle is a street machine.

Horsepower measured by this method is wheel horsepower or that actually delivered to the road. Many enthusiasts don't go for the method because it doesn't give as high a reading as a dynamometer with a needle which reads horsepower directly. The method often used is to rev the engine and catch the needle at the end of its swing. This gives great power readings but they are less than reliable. Even when reliable readings are made at the rear wheels, there is a tendency to add 30% or more for "power train losses." Having run the same engine on a dynamometer and in a car with manual transmission, I found only about 4% difference in the output. Even with an automatic transmission, losses are not as great as some would like us to believe. Passenger cars are rated fairly honestly these days but a few years ago, the 210 HP car you bought only put out about 117 at the rear wheels. Because we liked to believe the higher horsepower, we charged the loss against the drive train. It just wasn't so! That 210 HP engine never saw much more than 150 HP at the flywheel-even with the fan disconnected!

The point here is, don't be disappointed if your rear-wheel horsepower is not as great as you expected but if the power obtained after the turbocharger has been added is twice as much as before, the increase is 100% no matter how you measure it.

A few years ago when we turbocharged a 4,000-lb. Oldsmoble with an automatic transmission and were able to turn the quarter at better than 103 MPH on factory tires, charts showed this required almost 400 HP. We never measured more than 275 HP at the rear wheels.

This is how it is done:

- 1. Weigh the car and occupants accurately.
- 2. Install a tachometer.
- 3. Calibrate the speedometer.
- 4. Install an accelerometer.

The car and occupants may be weighed at any public scale. The tachometer can be calibrated by a strobe light or a revolution counter. The speedometer is easy to calibrate by driving at a constant speed on any highway equipped with mile posts. A stopwatch is used to measure the exact time for a given distance. The longer the distance, the more accurate the calibra-

tion. The actual speed is obtained by dividing the distance by the time.

After all the calibrations have been completed, the same two people included with the weight of the car will run the tests. Many tests will have to be run to obtain a power curve but we will go through the process completely for only one because the rest will be done in the same manner.

To find maximum horsepower at 4,000 RPM, first determine the road speed necessary to obtain that engine speed in high gear. If it is above the legal limit, drop down a gear.

Starting at a speed well below that required, open the throttle all the way. The driver keeps one eye on the speedometer and when it reaches the required speed, he calls out mark or some other predetermined word. The other occupant then reads and records the reading on the accelerometer. After a speed of about 5 MPH above the required speed is reached, the driver puts the transmission in neutral and starts coasting. When the speed again reaches the required MPH he again calls out mark. This time the deceleration is read and recorded. The second reading is taken to measure windage and road loads. The two readings are added to determine the total acceleration delivered by the tires to the road.

These readings will be accurate so long as there is no change in grade or wind direction during the interval between the readings. It is desirable to make several runs and average the readings.

If the road-load-horsepower readings are to be done regularly and extreme accuracy is desired, it will be worthwhile to invest in some additional equipment as shown in the accompanying photo.

In this case, a surplus 16mm movie camera was mounted in the car to photograph the instruments during acceleration runs. Film was viewed on a small screen used for editing. Instruments used measured compressor inlet and outlet pressure, turbocharger speed, time in 1/100 seconds, acceleration, engine speed and road speed. The turbocharger tachometer is very expensive and not required except in turbocharger-development work. The rest of the instruments are commercially available and the results obtained will be as good as from a high-quality recorder at considerably less cost.

Figure 57-Road horsepower





Figure \$8-Turbo matched for high RPM



An 8 mm camera is not recommended because the definition is not sharp enough to read the dials accurately without eyestrain. Super-8 cameras may work, but I've never tried them,

The biggest single advantage of the camera method over direct observation is that the camera will not slant readings in the direction desired by the observer. Everyone who is making modifications to his engine has the tendency of reading higher figures than actually occur.

The next step is to make use of the readings. To do this, it is necessary to go back to a couple of formulas from high-school physics.

If the accelerometer readings are in G units which is

Acceleration of Vehicle
Acceleration of Gravity

F = Weight x Accelerometer Reading

This force is the actual effort applied to the road by the tires. If the speedometer reading is converted to ft./sec., horsepower can be calculated directly.

Velocity (ft./sec.)
= Velocity (MPH) x
$$\frac{5280}{3600}$$

Because 1 horsepower equals 550 ft.ib./sec., the road horsepower is then:

$$HP = \frac{Force \times Velocity}{550}$$

A small calculation shows how simple this is:

Weight of car and occupants
Corrected road speed
Engine speed
Full throttle acceleration
Neutral deceleration
Total acceleration
.18G
.06G
.18G

$$F = MA$$
= $\frac{3650 \times .18 \times 32.2}{32.2}$

$$F = 657 \text{ lbs.}$$




Figure 59-Turbo matched for low RPM




Figure 60-Turbo matched for broad speed range

TABLE III
Suggested turbochargers for low-boost (10 psi Maximum) V-8 engines

| | | CFM @ 1.4 | SCHV | VITZER | | AIRESE | ARCH TO4 |
|-----|------|-----------|-----------|---------|----------|--------|----------|
| | | PRESSURE | | TURBINE | RAJAY | | TURBINE |
| CID | RPM | RATIO | MODEL | AREA | MODEL | TRIM | A/R |
| 283 | 5000 | 430 | 2-3LD-279 | 1.10 | 2-375F70 | 2-E-1 | 069 |
| | | | | | | 0 | r |
| | | | | | | 1-V-1 | P81 |
| 305 | 5000 | 462 | 2-3LD-279 | 1.25 | 2-375F80 | 2-E-1 | O81 |
| | | | | | | 0 | r |
| | | | | | | 1-V-1 | P81 |
| 327 | 5000 | 496 | 2-3LD-279 | 1.79 | 2-375F90 | 2-E-1 | 096 |
| | | | | | | 0 | r |
| | | | | | | 1-V-1 | P96 |
| 350 | 4000 | 425 | 2-3LD-279 | 1.10 | 2-375F90 | 2-E-1 | 081 |
| | | | | | | 0 | r |
| | | | | | | 1-V-1 | P96 |
| 400 | 4000 | 484 | 2-3LD-279 | 1.25 | 2-375E80 | 2-S-3 | 081 |
| 396 | 4000 | 482 | 2-3LD-279 | 1.25 | 2-375E80 | 2-S-3 | 081 |
| 427 | 4000 | 520 | 2-3LD-279 | 1.79 | 2-375E90 | 2-S-3 | 096 |
| 454 | 4000 | 551 | 2-3LD-305 | 2.00 | 2-375E90 | 2-S-3 | 096 |
| 500 | 4000 | 609 | 2-3LD-305 | 2.45 | 2-375E10 | 2-S-3 | O96 |

Velocity =
$$60 \times \frac{5280}{3600}$$

V = 88 ft./sec.
HP = $\frac{657 \times 88}{550}$
HP = $105.1 \text{ @ } 2800 \text{ RPM}$
Engine torque can then be calculated from HP = $\frac{T \times RPM}{5250}$
or T = $\frac{5250 \times HP}{RPM}$
= $\frac{5250 \times 105.1}{2800}$
Torque = 197 lbs. ft.

Results of several speeds can then be plotted to let us look at the horsepower and torque curves, Figure 57.

If possible, readings should first be taken and plotted in the naturally-aspirated condition so a base line can be established before the engine is turbocharged.

After the installation has been made and the necessary settings have been established for idle speed and ignition timing, the acceleration test should be rerun to determine if there has been a power gain and how much.

If the power curve looks like Figure 58, it means the compressor is the right size, but the turbine housing has been matched for increase in power at the top end only.

Using a turbine housing with a smaller A/R should give more boost at the low-speed end, Figure 59.

Too small a turbine housing may push the boost out of sight at high speeds. This is often fatal to engines and should be avoided. One of the various types of restrictions mentioned previously should be used. When this is done correctly, an HP curve similar to Figure 60 can be established. Please remember these curves are for comparison only and do not represent a specific engine. An increase of 100% in road horsepower with a broad speed range is not only possible, but has been demonstrated many times.

This method of matching is fine for cars and trucks which are to be used on the street but is impractical for road or track racers.

After the size of compressor has been established, the turbine housing should be matched to the track conditions just as final gear ratios are matched. Changing turbine housings on turbochargers takes about five minutes, including disconnect-

ing and connecting the inlet and outlet ducting. Asbestos gloves are recommended. If "V" band inlet and outlet connections are used along with quick disconnects on the oil supply and drain, the whole turbocharger can be replaced in less than a minute.

To summarize, the compressor should be picked which will flow air or air-fuel mixture in the area of the map between the surge line and the 60% efficiency line. The turbine housing A/R should be matched to produce the required boost at the required speed and if necessary, means should be provided to prevent overboosting at maximum engine speed.

If boost pressure is too high, use a turbine housing with a larger A/R. Tuning the installation with the correct turbinehousing A/R is essential to make the turbocharger work correctly. Novice installers of turbos have nearly always blamed the unit for producing too much or too little boost when all they had to do to make it right was to change the turbine housing. Because the information has not been common knowledge in the past, this part of making the turbocharger installation work has been completely overlooked unless the tuner was able to get help from someone with turbo experience. Thus, it is important to buy your turbo from an organization which has the various turbine housings in stock and will agree to work with you by swapping turbine housings until the installation is exactly right.

As mentioned at the beginning of this chapter, a good percentage of potential turbocharger users will look over this method and say, "But how do I know which turbocharger to use for my application?"

The people who sell turbochargers for special applications are anxious to make money so they have gone through the process for just about any engine or application they could imagine. These men, Don Hubbard of Crane Cams, Paul Uitti of Rajay Industries, and Chuck McInerney of AiResearch Industrial Division have all spent years matching turbochargers to engines. They have contributed information on matching turbochargers to various engines depending on the application. This is shown in Tables III, IV, V, VI and VII.

TABLE IV
Suggested turbochargers for moderate-output (20 psi Maximum) V-8 engines

| | | CFM @ 2.3 | SCHW | ITZER | | AIRESE | ARCH TO4 |
|-------|------|-----------|-----------|---------|-----------|--------|----------|
| | | PRESSURE | | TURBINE | RAJAY | | TURBINE |
| DISPL | RPM | RATIO | MODEL | AREA | MODEL | TRIM | A/R |
| 283 | 7000 | 822 | 2-3LD-279 | 2.00 | 2-375F80 | 2-S-3 | 081 |
| 305 | 7000 | 883 | 2-3LD-279 | 2.45 | 2-375F80 | 2-S-3 | 081 |
| 327 | 7000 | 935 | 2-3LD-279 | 3.02 | 2-375E70 | 2-S-3 | 096 |
| 350 | 6500 | 936 | 2-3LD-279 | 3.02 | 2-375E70 | 2-S-3 | 096 |
| 400 | 6500 | 1078 | 2-3LD-305 | 3.02* | 2-375E80 | 2-V-1 | P81* |
| 396 | 6500 | 1068 | 2-3LD-305 | 3.02* | 2-375E80 | 2-V-1 | P81* |
| 427 | 6500 | 1148 | 2-3LD-305 | 3.02* | 2-375E10* | 2-V-1 | P96* |
| 454 | 6500 | 1212 | 2-3LD-305 | 3.02* | 2-375E10* | 2-V-1 | P96* |
| 500 | 6500 | 1349 | 2-3LD-305 | 3.02* | 2-375E10* | 2-V-1 | P96* |


^{*}Boost control required

TABLE V
Suggested turbochargers for high-output (45 psi Maximum) V-8 engines

| | | CFM @ 2.7 PRESSURE | SCHV | VITZER TURBINE | RAJAY | AIRESE | ARCH TO4 |
|-------|------|-----------------------|-----------|-------------------|----------|--------|----------|
| DISPL | RPM | RATIO | MODEL | AREA | MODEL | TRIM | A/R |
| 283 | 7000 | 822 | 2-3LD-305 | 3.02 | 2-375E10 | 2-V-1 | P96 |
| 305 | 7000 | 883 | 2-3LD-305 | 3.02 | 2-375E10 | 2-V-1 | P96 |
| 327 | 7000 | 935 | 2-3LD-305 | 3.02 | 2-375E10 | 2-V-1 | P96 |
| 350 | 6500 | 936 | 2-3LD-305 | 3.02 | 2-375E10 | 2-V-1 | P96 |
| 400 | 6500 | 1078 | 2-3LD-305 | 3.02 | 2-375E10 | 2-V-1 | P96 |
| 396 | 6500 | 1068 | 2-3LD-305 | 3.02 | 2-375E10 | 2-V-1 | P96 |
| 427 | 6500 | 1148 | 2-3LD-305 | 3.02 | 2-375E10 | 2-V-1 | P96 |
| 454 | 6500 | 1212 | 2-3LD-305 | 3.02 | 2-375E10 | 2-V-1 | P96 |
| 500 | 6500 | 1349 | 2-3LD-305 | 3.02 | 2-375E10 | 2-V-1 | P96 |

No doubt, someone will ask why such and such a Schwitzer or AiResearch turbocharger is not shown on the list. Both manufacturers make many models of turbochargers but only certain ones are readily available, so if you have a model not on these tables and it needs overhaul, you might have trouble finding parts. Those shown on the tables are available and repairable.

If you cannot find your engine among those on the tables, one of the same size and method of valving will normally take the same size turbocharger.



Small diesel turbo was seen on a Buick-powered competition roadster in Flint, Michigan in 1962. Two large 4-bbl. carbs mounted on a "trunk" manifold to the compressor inlet. Diesel-type turbo had no seals to protect against gasoline flowing through compressor into turbo bearing, so turbo bearing failure resulted. Junction box connected right and left exhaust manifolds next to turbo. This is another example of mismating — in the turbo sizing and construction — and in carburetion requirements.


TABLE VI
Suggested turbochargers for 4-cylinder engines (one turbo per engine)

| | | SCH | NITZER | | AIRE | SEARCH | T04 |
|--------------|-----------------|---------|---------|--------|------|--------|-------|
| | | | TURBINE | RAJAY | | TURBI | NE |
| VEHIC | LE CID | MODEL | AREA | MODEL | TRIM | A/R | |
| Chevrolet V | ega 140 | 3LD-198 | 1.25 | 375860 | E-1 | 069 | |
| Dodge Colt | 98 | 3LD-168 | .87 | 377B25 | J-1 | N58 | |
| Ford Pinto | 98 | 3LD-168 | .87 | 377B25 | J-1 | N58 | |
| Ford Pinto | 121 | 3LD-198 | 1.25 | 377B40 | E-1 | 069 | |
| Alfa Romeo | 96,120 | 3LD-168 | .87 | 377B40 | E-1 | 069 | |
| Audi | 103,114 | 3LD-168 | .87 | 377B40 | E-1 | N58 | |
| Austin Heale | ey Sprite 67,78 | 3LD-168 | .68 | 377B25 | J-1 | N32 or | N58 |
| BMW | 108,121 | 3LD-198 | 1.25 | 377B40 | E-1 | N58 | |
| Datsun | 79,87,97,108 | 3LD-168 | .87 | 377B25 | J-1 | N58 or | N50 |
| Ford | 91,103 | 3LD-168 | .87 | 377B25 | J-1 | N58 or | N50 |
| Honda 750 | 46 | 3LD-168 | .68 | 377B25 | J-1 | N58 or | N32 |
| Mercedes | 121 | 3LD-168 | .87 | 377B25 | J-1 | N58 | |
| Mercedes | 134 | 3LD-168 | .87 | 377B25 | E-1 | 069 | |
| MG | 78,99,110 | 3LD-168 | .87 | 377B25 | J-1 | N58 or | N32 |
| Opel | 66 | 3LD-168 | .68 | 377B25 | J-1 | N32 | 4 |
| Opel | 91,103,116 | 3LD-168 | .87 | 377B40 | E-1 | N58 or | N50 |
| Porsche | 96,121 | 3LD-168 | .87 | 377B40 | E-1 | N58 | |
| Renault | 96,101 | 3LD-168 | .87 | 377B25 | J-1 | N58 | |
| Saab | 104,121 | 3LD-198 | 1.25 | 377B40 | E-1 | N58 | |
| Toyota | 71,86 | 3LD-168 | .87 | 377B25 | J-1 | N32 | |
| Toyota | 97,120 | 3LD-168 | .87 | 377B25 | E-1 | N58 | |
| Triumph | 70,79,91 | 3LD-168 | .87 | 377B25 | J-1 | N58 or | N32 |
| VW | 78,91,97,102 | 3LD-168 | .68 | 377B25 | J-1 | N58 or | N-,32 |
| Volvo | 108,121 | 3LD-168 | .87 | 377B40 | E-1 | N58 | |

TABLE VII
Suggested turbochargers for 6-cylinder engines (one turbo per engine)

| | | | SCH | NITZER | | AIRESE | ARCH TO4 |
|-------------------------|----|-----------|---------|--------------|--------------|--------|----------|
| | | | | TURBINE | RAJAY | | TURBINE |
| VEHICLE | | CID | MODEL | AREA | MODEL | TRIM | A/R |
| Am. Motors | 19 | 9,232,258 | 3LD-279 | 1.79 | 375E80 | S-3 | O81 |
| Chevrolet | | 230,250 | 3LD-279 | 1.79 | 375E80 | S-3 | 081 |
| Chevrolet | | 292 | 3LD-305 | 2.00 | 375E10 | V-1 | P96 |
| Ford | | 144,170 | 3LD-198 | 1.79 | 375F60 (144) | S-3 | 069 |
| | | | | | 375F70 (170) | S-3 | 069 |
| Ford | | 200,250 | 3LD-279 | 1.79 | 375E80 | S-3 | 081 |
| Ford | | 240 | 3LD-279 | 1.79 | 375E80 | S-3 | 081 |
| Ford | | 300 | 3LD-305 | 2.00 | 375E10 | V-1 | P96 |
| Dodge, Plymouth 170,225 | | 3LD-279 | 1.79 | 375F70 (170) | S-3 | O81 | |
| | | | | | 375E70 (225) | S-3 | 081 |
| GMC | | 270,302 | 3LD-305 | 2.00 | 375E10 | V-1 | P96 |
| Aston Marti | in | 244 | 3LD-279 | 1.79 | 375E80 | V-1 | P81 |
| Austin Heal | ey | 178 | 3LD-198 | 1.79 | 375F80 | S-3 | 081 |
| BMW | | 182 | 3LD-198 | 1.79 | 375F80 | S-3 | O81 |
| Datsun | | 146 | 3LD-198 | 1.25 | 375F60 | S-3 | O58 |
| Ford V-6 | | 155 | 3LD-198 | 1.79 | 375F70 | S-3 | 069 |
| Jaquar | | 151 | 3LD-198 | 1.79 | 375F60 | S-3 | 069 |
| Jaquar | 21 | 0,231,258 | 3LD-279 | 1.79 | 375E80 | V-1 | P81 |
| Porsche | | 143 | 3LD-198 | 1.79 | 375F60 | S-3 | 069 |
| Toyota | 12 | 1,137,156 | 3LD-198 | 1.79 | 377B40 (121) | E-1 | N58 |
| | | | | | 375B60 (137) | E-1 | N58 |
| | | | | | 375F60 (156) | S-3 | O58 |
| Triumph | | 122,152 | 3LD | | 377840 (122) | S-3 | O58 |
| | | | | | 375F60 (152) | S-3 | O58 |

CARBURETION & FUEL INJECTION 5



McLaren CanAm car with a 465 CID big-block Chevrolet aluminum engine. Two AiResearch TEO-670 turbos with wastegated exhaust produces 1,200 HP at 60 inches Hg manifold pressure. Lucas timed mechanical fuel injection with 2,25-inch throttle bores has blow-off valves for closed throttle manifold-pressure relief. Photo by Bill Howell.

The purpose of a carburetor or fuelinjection system is to add fuel to the air
entering the engine at the correct ratio
so it will burn efficiently in the combustion chamber and, at the same time, not
create too hot a fire which would cause
early destruction of the engine. The duty
is the same for a naturally-aspirated or
turbocharged engine except in a turbocharged engine one more problem is added,
that of the supercharged condition where
the intake-manifold pressure is higher
than ambient.

Modern carburetors differ in the way they do their job but, in general, all have systems to cover the following modes of operation:

- An enriching system to enable the engine to start and run when it is cold. This is the choke system.
- An idle system to provide the correct air-fuel ratio to the engine when it is idling with no output.
- A main fuel system which is in operation at cruise.
- A power system which enriches the fuel air mixture under extreme power or acceleration conditions.
- An accelerator pump which gives an extra shot of fuel to the mixture each time the throttle is opened so there will not be a lag between the idle circuit and the main circuit or the main circuit and the power circuit.

These carburetor circuits-duplicated in a good fuel-injection system-have been developed over the past 75 years to a point where the average carburetor is a very reliable device needing little attention. Progressive carburetors such as the two-barrel type used on the Pinto and Vega and the four-barrel type used on just about every V-8 built are basically the same as the single barrel except that the secondary barrels are added to reduce the pressure drop at extremely high engine speeds so the engine can achieve its maximum power. The secondary barrels will usually only contain as many systems as necessary for their operation. For instance, the secondaries ordinarily do not have a choke circuit, and may not





Figure 61-Side draft Rochester with external manifold-pressure sensing line

Figure 62—Carburetor power circuit, showing power valve open



include a power system, accelerator pump or idle system.

The main problems with carburetors and fuel-injection systems are: They were invented before the turbocharger became readily available for gasoline engines, and, therefore, do not take into account the fact that it is necessary to run richer when the intake manifold pressure is above 15 psia than it is on a naturally-aspirated engine where this condition cannot occur.

Looking back over the years when the Corvair was first turbocharged, Chevrolet used a carburetor (Carter YH) which was already available because it had been used on an early-model Corvette. This carburetor did not have any way to sense intakemanifold pressure so two things were necessary to keep the engine out of trouble when the boost went up to about 7 or 8 psig. One thing was to choose a metering rod and jet which resulted in an overrich condition at full throttle. The other was to put a pressure-retard diaphragm rather than a vacuum-advanced diaphragm on the distributor. This diaphragm actually retarded the spark about 10 crankshaft degrees when the intake manifold pressure reached 2 psig. The system worked fairly well but was a compromise and never had the feel desired by many hot rodders.

At the same time Oldsmobile was developing its Jetfire, a turbocharged version of its 215 CID V-8 F85 Cutlass Engine. Oldsmobile's approach was quite different in that they started with a highcompression ratio engine, but they did develop a carburetor particularly for this application. This carburetor had two features which were in the right direction for a turbocharged engine. First the power piston was not connected to the downstream side of the butterfly but had an external line which enabled it to be connected to the intake manifold of the engine downstream of the turbocharger. See Figure 61. With an ordinary carburetor, where the power piston or diaphragm senses pressure immediately downstream of the throttle, it is possible to have a partially closed throttle plate creating a good vacuum at the power-valve port while the turbocharger is turning this vacuum into pressure and the engine sees pressure above atmospheric. When this happens, the engine will run lean and probably

detonate. The other thing Oldsmobile did was add anti-detonant fluid to the carburetor when the engine ran in the supercharged condition. It was necessary to add this anti-detonant because of the engine's high compression ratio. This same system works well with a low-compression-ratio engine where the anti-detonant can be added at a much higher manifold pressure.

Because we have to live with carburetors designed for naturally-aspirated engines, several things can be done to modify them to do a better job on a turbocharged engine. Figure 62 shows the power circuit of a typical carburetor. Note the sensing line, as described previously, senses pressure just downstream of the throttle valve. If this sensing line, normally a drilled internal passage, is plugged up and a new line connected to the power diaphragm, it can be routed to the intake manifold with a short length of copper tubing. On some carburetors there is enough material in the wall to drill and tap for a tube fitting. On others it is necessary to drill a hole about the size of the tubing and then epoxy the tubing in place. This modification only solves one problem, that of giving the correct signal to the carburetor power system when operating with a turbocharger downstream of the carburetor. It does not, however, do anything for enriching the fuel/air mixture when the intake manifold is above atmospheric. There are several ways to do this without redesigning the carburetor. The device in Figure 63 can be added to the carburetor with the least effort. I have run this system on a turbocharged Corvair with good results. Get the Hobbs pressure switch at an automotive parts supply house for a nominal price. These come in various pressure ranges but mine has a 0-4 psi range. The actual point where the switch closes is adjustable with a small screw driver. The solenoid valve may be a little harder to come by but should be available at a recreational-vehicle outlet. Make sure the valve seat is made from a gasoline-resistant material. The size of the orifice which adds the extra fuel to the carburetor will vary with the engine but I have found .040" works pretty well in my case. The use of this fuel-enriching device allows the carburetor power valve to be set at a fuel/air ratio which would be too lean for a supercharged engine. As soon as the intake manifold pressure reaches





Figure 63-Pressure-sensitive enriching device

In early 1961, General Motors styling asked TRW to turbocharge a Corvair engine for a show car. A Solex carburetor allowed easy jet changes during development. After two warmup runs to calibrate the carburetor and set the ignition timing, this engine produced 155 HP. One year after the first run, the Corvair Spyder was introduced.







Figure 64-Modulating pressure-sensitive enriching device

Figure 65-M. Goudard device Patent 2,290,610



about 2 psi, extra fuel is sprayed into the carburetor, cooling the engine down and preventing detonation. Because it is possible to drive all day without ever reaching the supercharged condition, this modification is also a good fuel-saving device. It is an off-and-on system, so it is also a compromise where the engine will still be running too rich at 2 or 3 pounds boost pressure and too lean at 8 to 10 pounds boost pressure. It can be carried one step further by building a system shown in Figure 64. In this case, added fuel is controlled by a diaphragm which senses intakemanifold pressure. This system which will modulate the added fuel can be designed to enrich the mixture gradually as a function of the intake-manifold pressure. Although it can be made to do a better job than the pressure switch and solenoid, it will require considerably more development.

Just to make sure we don't think we are inventing the wheel again, Figure 65 shows a device patented by Maurice Goudard in 1942, Patent 2,290,610. This device was designed for an aircraft engine but not exclusively limited to one.

Even before that, two Englishmen, Fedden and Anderson designed a method of introducing anti-detonant to a supercharged engine. A schematic drawing of British Patent 458, 611 issued in 1936 is shown in Figure 66. These are shown for historical reasons but point out that supercharging had the same thermodynamic problems 40 years ago as it does today.

If a progressive two-barrel or fourbarrel carburetor is used, the problem can be approached in a completely different manner. The power-valve modification is still valid but the extra fuel enriching can be done completely in the secondary. When a progressive type of carburetor is used, the primary barrel or barrels have all the systems necessary to run the engine and, as mentioned before, the secondary is used to get the maximum out of an engine at very high RPM. This problem does not exist on a turbocharged engine because any pressure drop through the carburetor within reason can be made up by the compressor of the turbocharger. On a naturally-aspirated engine if the ambient pressure is 30 inches Hg, the engine can only put out $\frac{30-4}{30}$ or 87% of

its potential. When the secondaries of a progressive carburetor open and drop this restriction down to practically nothing, the engine can then achieve its full potential as far as breathing capacity is concerned. The case is quite different with a turbocharged engine because it is possible to have even 8 inches drop through the carburetor and still have a manifold pressure of 10 or 15 psig. The point I am making is, the use of a progressive carburetor on a turbocharged engine is not significant from a power viewpoint. But, its two separate fuel/air systems can be utilized very well to give the correct fuelair ratio to the engine under both naturallyaspirated and supercharged conditions. Secondary butterfly/s on a progressive carburetor can be actuated by several different methods. A simple mechanical linkage can start to open the secondary when the primary is three-quarters open or the secondaries may be diaphragmoperated using the vacuum drop through the primary venturi as a vacuum source. These carburetors usually have an interlock to prevent the secondaries from opening at part load. This type of actuation as used on the Holley 4150 Series carburetors lends itself to modification, Figure 67. The modification is as follows: The interlock between the primaries and secondaries was removed completely. The diaphragm assembly was taken apart and the spring moved to the opposite side of the diaphragm. The linkage was reworked so that pressure on the diaphragm would open the secondary while the spring would tend to close it. When a carburetor is modified in this way, there is no mechanical linkage between the primary and the secondary butterflies. All modes of engine operation take place using the primaries only until the intakemanifold pressure overcomes the spring in the diaphragm and opens the secondary butterflies. Because this can only occur in the supercharged condition, it is possible to select main and power jets for the primary to give the ideal air-fuel ratio at naturally-aspirated conditions. The jets in the secondary system can be sized for a rich condition which is more compatible with high intake-manifold pressures. If the diaphragm were connected to the intake manifold without any other modifications, the secondaries would not close when the






Figure 66-Fedden and Anderson anti-detonant, British Patent 458,611

Figure 67-Schematic of progressive carburetor with pressure-operated secondary





Author's twin turbocharged Corvair engine before it was installed shows diaphragm actuator for secondary throttles rearranged to open them with manifold pressure rather than primary vacuum.

driver's foot was removed from the accelerator pedal; the engine would continue to run in the supercharged condition on the secondaries alone. To prevent this from happening, a small three-way Mead valve was placed in the sensing line and mounted on the side of the carburetor so the valve actuated only when the primaries were fully opened. As soon as the primaries close, the Mead valve vents the secondary diaphragm to the atmosphere causing the secondaries to close immediately. This Mead valve is the same size and shape as a standard Microswitch and is actuated in the same manner.

This carburetor set-up gives a different feeling to the car than the standard set-up because the secondaries will not open until manifold pressure has reached about 1 psig. When this happens, there is not only a sudden jump in the manifold pressure but a definite feeling of being pushed from the rear.

Ever since turbochargers have been available for use on carbureted engines, the question as to whether it is better to suck or blow through the carburetor comes up. There are advantages and disadvantages either way and before we start knocking one or the other remember excellent results have been obtained with both methods. The biggest advantage of blowing through the carburetor is that it requires the least modification to the engine intake system. Fuel lines, choke mechanism and accelerator linkage may all be left as is. Some people say that blowing through the carburetor makes the turbocharger more efficient but this is not so. The efficiency of the turbocharger is a function of the design of the turbocharger and cannot be changed by carburetor location. If the peak adiabatic efficiency of a compressor is 75%, it will be 75% regardless of whether the carburetor is upstream or downstream of it. When people say this, I think they actually mean capacity rather

than efficiency. Because there will always be a pressure drop through the carburetor, a turbocharger compressor downstream of the carburetor sees air below atmospheric pressure. Because the centrifugal compressor is a CFM device, the maximum flow which it can handle will be the same but the maximum pounds per minute will be greater when the intake conditions never go below ambient. Saying this in a different way, a slightly higher capacity compressor is needed when sucking through the carburetor to achieve the same maximum horsepower. If a large enough carburetor is used, this size difference is insignificant.

One big advantage of blowing through the carburetor is it is not necessary to have a positive seal on the compressor end of the turbocharger. If a turbocharger is scrounged from a farm tractor or a piece of construction equipment, chances are it will have a piston-ring seal on the compressor end. This type of seal is not recommended for use downstream from a carburetor because it will not seal oil much beyond 5 inches Hg, vacuum. Because it may have to see vacuum as high as 29 inches Hg, an engine with this type turbocharger sucking through the carburetor will have a lot of blue smoke come out of the exhaust. In addition, it won't take long to use up all the oil in the crank case. Don Hubbard suggests adding a second butterfly downstream of the compressor as was done on Schwitzer Turbochargers used on Indianapolis-type race cars. This second butterfly is linked to the main butterfly so the compressor seal never sees a high vacuum.

Getting back to the advantages of blowing through the carburetor, the people who designed the original engine, in the case of a passenger car, did a pretty good job of designing the intake manifold to conduct the air fuel mixture from the carburetor to the cylinders. When this system is left intact, the distribution remains about the same. If this system is changed, as when the carburetor is removed from the intake manifold and a turbocharger placed between the carburetor and the manifold, the connections from the compressor to the intake manifold become very critical. The fuel/air mixture comes out of the compressor discharge in a swirl which must be broken




Figure 68-Method of ducting compressor outlets when using two turbochargers

up before it enters the intake manifold. This is usually done by having a squarecornered plenum at the junction of the compressor-discharge pipe and the intake manifold. If two turbochargers are used, as on a V₁8, the square plenum chamber is not only important, but in addition the compressor discharges should be mounted to enter the plenum head-tohead rather than tangentially. Looking at Figure 68, the left sketch shows two compressors mounted with their discharge entering the plenum tangentially. When this happens, some of the cylinders will run lean while others will run rich. This situation can cause the engine to fail by burning holes in some of the pistons while the spark plugs are fouled from an over-rich condition in other cylinders. In one case when this happened, the inlets were changed to the configuration shown in the right sketch and no further distribution problems were encountered.

Similar problems have occurred where only one turbo was used. Duke Hallock's 289-CID Ford installation directed the turbo outlet into a *doghouse* atop the intake-manifold carb flange. A plate with 1/4-inch holes had to be added to restore turbulent flow for equal mixture distribution. An intercooler or a slightly longer tube between the turbo and the manifold might have accomplished the same end result. Any device between the turbo and

the engine which will break up swirts or laminar flow into turbulent flow is definitely recommended.

Cast manifolds usually have enough sharp bends to promote turbulence but fabricated intake manifolds must be carefully designed to prevent some fuel separation. Tuning the inlet system with individual runners of specific lengths to get a ram effect at a certain engine RPM is not recommended. The turbocharger conpressor should provide all the air needed. Chances are a tuned system will work well at one speed only and could be a detriment at other speeds. Most turbochargers are designed to be run with the shaft horizontal. Because of this, a sidedraft carburetor is ideal for mounting purposes. There are, however, a few drawbacks to using them. For every sidedraft built there must have been a million downdrafts. By sheer numbers, the average downdraft carburetor is further developed, easier to procure and easier to service. There are a few exceptionally good sidedraft carburetors, but they are usually quite expensive. "One drawback with most U.S. passenger-car downdraft carbs is that they are subject to mixture changes due to G forces in one direction or another," says Ted Trevor. He developed kits to adapt the Weber 40 and 45 DCOE sidedraft carbs to Rajay turbos. Trevor claims only a little effort is required to get the Webers to provide

correct mixtures under G loads imposed by slaloms, road racing, hill climbs—or even the fast manuevering required for evasive action in everyday driving. As you will note from some of the accompanying photos, both Trevor and David Inal! have made good use of Weber and SU-type sidedraft carburetors in various turbocharged applications.

Another advantage to blowing through the carburetor is all carburetors on passenger cars have some method of warming to prevent icing conditions. It is usually accomplished on an in-line engine by bolting the exhaust manifold directly to the intake manifold underneath the carburetor. On some in-line engines, a water-heated spacer is placed between the carburetor and the intake manifold, or the intake manifold is heated by jacket water.


On a V engine, the two exhaust manifolds are often connected by a heat-riser passage, through the intake manifold to allow hot exhaust gases to heat the intake manifold in the carburetor area. Some V engines have jacket water passages in the intake manifold to keep it warm and some have both a heat riser and a water jacket. When the turbocharger compressor is placed between the carburetor and the intake manifold, it is possible for the carburetor to "ice up" and also for fuel to condense in the compressor housing. Some turbochargers have been designed


with water-jacketed compressor housings, but most are designed to keep the compressor housing as cool as possible to increase the volumetric efficiency. To prevent carburetor icing, a spacer should be placed between the carburetor and the compressor similar to Figure 69. A drilled or cored passage through the spacer should be connected in series with the heater to allow hot water to flow through the passage. If the carburetor-discharge temperature remains about 60°F., neither icing nor condensation will normally take place.

If a downdraft carburetor is used, a water passage should be drilled or cored on the bottom of the elbow, Figure 70. If fuel is allowed to collect anywhere in the induction system, a liquid slug will be carried into the cylinder when the throttle is opened. This can cause anything from stalling to overspeed.

One of the disadvantages of blowing through the carburetor is fuel pressure. The average fuel pump will not produce more than about 5 psig fuel pressure to the carburetor. This is fine on a naturallyaspirated engine but will not work on a blown carburetor. If the turbocharger is delivering 10 psi to the carburetor, it is impossible for fuel to flow. One way to overcome this problem is to add a highpressure electric pump in series with the engine-driven pump, but located between the mechanical pump and the carburetor. Otherwise, the mechanical pump will act as a regulator. This will deliver enough fuel pressure when the engine is supercharged but will also deliver high pressure at part load. If the additional pressure is great enough to overcome the buoyancy of the inlet valve float, fuel will pour through the carburetor and flood the engine. In some cases the exhaust pipe will act like a blow torch.

Duke Hallock, former high-performance coordinator and test-lab supervisor for AiResearch, has been driving the same 1937 Ford pickup since it was new. 292 CID engine with AiResearch T-7 turbo is one of many engines he has installed in the chassis over the years. A plate perforated with 1/4-inch holes is used at the original manifold flange to get turbulent flow and good mixture distribution.





Overpressure can be prevented by operating the electric fuel pump with a pressure switch. The switch should be set to start the pump only when the manifold pressure goes above atmospheric. This will work but it costs money, adds another potential source of trouble, and does not control the fuel pressure smoothly.

The high-performance Holley electric fuel pump has a remote regulator which is mounted near the carburetor. One side of this remote regulator is vented to atmospheric pressure through a setscrew factory-set to give 6 psi outlet from the regulator. The pump itself is factory-adjusted to give 12 psi through the fuel line to the regulator. The regulator vent can be hose-connected to the duct which feeds air to the carburetor from the turbo so that any boost pressure will automatically raise the outlet pressure by the amount of the boost. In the normally aspirated condition, the fuel pressure will remain at 6 psi, Because the Holley pump produces 12 psi pressure, the maximum boost that can be accommodated with the pump/regulator combination is 6 psi. At any boost above 6 psi, the effective fuel pressure will be reduced by the amount that the boost exceeds 6 psi. For example, 8 psi boost will lower the fuel pressure to 4 psi. However, these pumps and regulators can be used with boost pressures in excess of 6 psi by reworking the pump to operate at a higher pressure.

Looking at the cross section of a typical fuel pump in Figure 71, it is apparent the rocker shaft, operated by the engine cam, serves only to compress a spring which is the force used to pump the fuel. The fuel pressure will remain constant as long as the flow is less than pump capacity. The pressure can be increased by putting in a stiffer spring; but, as in the case of the electic pump, it will deliver the higher pressure even when not needed.

Figure 72 and Figure 73 are cross sections of Corvair and Volkswagen fuel pumps. The Corvair pump has its operating spring located on the top side of the diaphragm. In this case, if a fitting is attached to the vent hole and a line connected to the compressor discharge, the spring will be assisted by the compressor-discharge pressure and will always deliver standard pump pressure plus supercharge pressure. The pump in effect becomes a pressure regulator.




Figure 69—Sidedraft carburetor adapter with built-in heater

Figure 70—Downdraft carburetor adapter with built-in heater




Figure 71-Typical automotive fuel pump




Figure 72-Corvair fuel pump






Figure 73-Cross section VW fuel pump



TRW made this installation on a 1963 Corvair with a prototype Rochester fuel-injection system. Performance was phenomenal but high cost kept this one out of production.




V-6 Ford turbocharged by engineer Eric Fuchs of Ford's Advanced Vehicle Operations. This is a blow-through-the-carburetor installation. Photo courtesy Ford of England.





Car & Driver magazine staffers turbocharged this Opel and wrote an article on it. Turbo is a Rajay unit. Note how neatly everything works together, even with all of the emission controls kept intact. Pat Bedard photo.

Nova V-8 installation by Chevrolet Engineering. Air-cleaner pressure adjusts Holley fuel-pressure regulator to maintain fuel pressure greater than air-cleaner pressure. Air-cleaner pressure also activates switch to turn on Holley electric fuel pump to supply fuel pressures greater than 3 psi as required. 1 — Pressure line from air cleaner. 2 — Pressure-actuated switch. 3 — Relay. 4 — Holley fuel-pressure regulator. 5 — Holley electric fuel pump. 6 — By-pass line for fuel when Holley pump is not running.

Chevrolet Engineering Photographs.








Dyno-test set-up at M & W gear with blow-through carburetor and water-cooled turbine housings on Ford 302 CID V-8 for marine use.

Figure 74-Diaphragm-type fuel pump with rod seal



The Volkswagen fuel pump has the spring on the bottom of the diaphragm but the rocker arm is driven by a push rod, which is in turn driven by the engine cam. The push rod fits loosely in a plastic guide. If the push rod is replaced with one which fits snugly in the guide, the lower chamber of the pump may be pressurized by connecting an air line from the compressor discharge and will always deliver adequate fuel pressure. The rod can also stick in the up position, causing the pump to cease operating. However, when running supercharged, pressure will tend to prevent sticking if the rod is very smooth.

This method may be used on any fuel pump where the spring chamber can be sealed from the crankcase, Figure 74, but will not work on a fuel pump where the spring chamber is essentially open to the crankcase. It is neither practical nor safe to supercharge the engine crankcase on a four-cycle engine.

After all these problems have been solved, it may still be impossible to pressurize a carburetor because the design of the carburetor may not lend itself to being sealed. In this case, it will be necessary to build a box around the carburetor and run the linkage through a seal in the box.

Don Hubbard has done quite a bit of turbocharging by blowing through the carburetor and makes the following suggestions: The carburetor needs to be inspected to make sure that all float bowl and other vents are vented into the airhorn area so that air or air fuel mixture cannot be blown outside the carburetor if the carburetor is to be pressurized from the air-cleaner flange. The next thing needed is to get a foam-plastic or Nitrophyl float. Brass floats with flat sides may collapse under pressure or accidental back firing and then sink and flood the engine. A brass float can have a small hole drilled in it and the plastic foaming liquid poured in. After the plastic foam has hardened, the hole can be resealed. Many modern carburetors come with foam floats or replacements are available. Brass SU cylindrical floats are usually strong enough to withstand boost pressure. Don then suggests sealing the throttle shafts. The choke shaft only leaks dry air so it needs no seal. If the throttle shaft has no linkage required on one end, it can be shortened and a plug pressed into the end of the bore. Mechanical seals are not the best way to seal a throttle shaft because of friction. The best way is an air seal. Take dry air from above the venturi and duct it into the throttle shaft boss. The air pressure above the venturi is slightly higher than that below so some dry air leaks out. But also, some leaks into the throttle bore carrying the fuel/air mixture with it. This also creates no extra friction. Some carburetor castings can be merely drilled while some may require drilling and pressing in small tubing connected with flexible tubing, Figure 75.

Don also suggests another method of sealing the carburetor throttle shafts by machining a special adapter flange, Figures 76, 77, and drilling holes through the bottom of the carburetor flange directly into the throttle shaft. In a two-shaft carburetor—four barrel or staged two-barrel—be sure to balance the drilled hole areas so that one hole will not rob pressure from the other holes.

Turbocharging a fuel-injected engine has many of the same problems as blowing through a carburetor because the injection nozzles are always on the pressure side of the compressor. Port fuel injections such as used on the Chevrolet Corvette Engines have aspirated nozzles. This is done mostly to prevent vacuum from sucking fuel from the nozzle at idle or very low load conditions. When engines with this type fuel injection are supercharged, pressurized air is forced out through the nozzle preventing the fuel from entering. To eliminate this problem, the aspiration vents must be connected to the compressor discharge, Figure 78, suggested by Don Hubbard. In addition to this, it is necessary to increase the fuelinjection pressure to ensure good fuel flow at supercharged conditions.

One of the modifications made to carburetors in an effort to reduce air pollution is a vent from the fuel bowl to a charcoal canister. This same canister is usually connected to the fuel tank to capture gasoline fumes from that source, too. The fellows who invented this system did not have turbocharged cars in mind—or at least those which blow through the carburetor—because pressure from the compressor will supercharge the float-bowl chamber. And, unless a check valve is placed in the vent line to the charcoal canister, it will also supercharge the




Figure 75-Air-sealed throttle shaft




Figure 76—Adapter for carburetor-flange air seal




Figure 77—Adapter for 4-barrel carburetor flange




Figure 78—Fuel injection aspiration venting

Figure 79—Compressor impeller with chopped-up blades

canister and the fuel tank. A simple blowoff line which opens at 1/4-pound pressure and connected to the air cleaner should do the job.

In general, a high-output turbocharged engine requires the same or even less CFM carburetion capacity than a high-output naturally-aspirated engine. As an example, when Rajay turbocharged a 1971 Oldsmobile 350 CID engine which normally aspirated had a 725-CFM Quadra-jet, they got best results with a single Holley 600-CFM double-pumper. Crown Manufacturing's Datsun 240Z installation uses only one of the two SU-Type carburetors provided on the engine, yet gets near 100-MPH performance in the 1/4 mile.

Some people think an air cleaner is a waste of time and power on a high-performance engine. The compressor impeller in Figure 79 is a good example of what can happen when an air cleaner is not used. Ted Trevor says, "There may be instances where an air cleaner is not desired-like a boat which never comes to port-or an airplane which never lands. All other applications of internal combustion engines need air cleaners." A small rock of a piece of metal such as a screw or nut will wipe out a compressor impeller. Parts of the impeller will then pass through the engine, perhaps causing extreme damage.

Carburetor butterfly screws should be staked in place to prevent them from backing out. This should be done very carefully using a backup anvil on the opposite side of the shaft so there will be no chance of bending the shaft.

Table VIII was compiled to show the advantages and disadvantages of blowing and sucking through the carburetor. As you can see neither method is perfect but, on the other hand, either method will do a good job when done correctly.




TABLE VIII

Advantages and disadvantages of blowing or sucking through the carburetor

| PROBLEM | BLOW THROUGH | SUCK THROUGH |
|---------------------------------------|---|--|
| Location of carburetor and linkage | No change | Must be moved |
| 2. Fuel pump | Requires either extra pump or one compensated for com- pressor discharge pressure | No change |
| 3. Positive crankcase ventilation | Must be moved to compressor inlet | No change |
| 4. Fuel evaporation system | Must be equipped with check valve to prevent supercharging fuel tank | No change |
| 5. Carburetor leakage | All holes and shafts must be sealed or complete carburetor boxed | No change |
| Distance from carburetor to cylinder | No change | Much longer |
| 7. Carburetor float | Might collapse if not made from Nitrofil | No change |
| 8. Turbocharger oil seal | Nothing special required | Must have positive seal on compressor end |
| 9. Compressor surge | Can be a problem on deceleration | Not ordinarily a problem |
| 10. Compressor size | Inlet pressure always atmospheric so maximum capacity always available | Inlet pressure below atmos- pheric so slightly larger physical size is required in some cases |




Porsche's Turbo Carrera coupe was introduced to the world market in 1975 and became available in the U.S. in 1976. Car is a true race-bred machine which offers outstanding appeal to the motoring enthusiast.

Engine for the Turbo Carrera is a flat-six with an Eberspacher turbocharger pumping pressurized air to the fuel-injection system. Wastegate allows turbo response to be much quicker than would be the case if exhaust/intake restrictions were used as a control for boost pressure.



Schematic of exhaust and intake plumbing on the Porsche Turbo Carrera six-cylinder engine.



6 ICNITION

The ignition system for a turbocharged engine is not much different than that for a high-performance naturally-aspirated engine. It has to make a spark at the right time to fire the charge and the things going on outside the combustion chamber are about the same in either case, although higher pressures inside the combustion chambers create a few extra problems for the turbocharged engine.

When sparkplugs are cleaned by sand blasting, there is usually a little chamber in the machine where the sparkplug can be inserted and pressure applied to see if it will fire under pressure as well as at atmospheric conditions. This chamber has a little glass window so the actual spark may be observed. A little experimentation will show as the pressure in the chamber is increased, the spark gap on the plug must be decreased to make it fire. This same problem exists in a turbocharged engine. The combustionchamber pressure at the time of ignition will be considerably higher than on a naturally-aspirated engine of the same compression ratio and, therefore, it is necessary to reduce the spark gap to ensure positive ignition when maximum boost is developed. The recommended gap on most naturally-aspirated passenger cars is around 0.035 inches. It is a good idea to reduce this to 0.025 inches when adding a turbocharger.

Plug heat range—as in a naturally-aspirated engine—is determined by the use of the engine. However, even in ordinary street use, one range colder than production is recommended. Don't go too cold or you will have the same plug-fouling problems on a turbocharged engine as you would have on a naturally-aspirated engine.

Some ignition cables consist of cotton or similar material impregnated with carbon. This is done to reduce radio and TV interference and the wires are called TVR. On a typical passenger car where the plugs are changed maybe once a year, the cable could last the life of the car. In the hands of a hot rodder or enthusiast, it's a different story. The whole harness might be removed and replaced dozens of times. This will cause flexing of the cables and possibly an increase in the resistance. In one instance, an engine was missing badly for no apparent reason. After trying everything else, it was decided to check the resistance of the spark-plug leads. The resistance was supposed to be 20,000 ohms but one lead had 200,000 ohms. The whole wiring harness was replaced and the engine ran without missing.


TVR-type wires should be replaced with steel-core wires or with the MSW Magnetic-Suppression Wire. The MSW type should be installed if the vehicle is radio-equipped or if there is any reason to be concerned about radio/TV interference. It has all of the advantages of the resistance-type wire with none of the disadvantages. In addition, it should be noted that resistance-type wire cannot be used with capacitive-discharge ignition systems. These systems will quickly destroy the TVR wire.

Ignition systems on present day passenger cars are equipped with several mechanisms to prevent spark advance any time when such advance might increase NO_x in the engine exhaust. These devices vary from car to car but, in general, they consist of no vacuum advance in the lower gears, no vacuum advance until the engine has come up to temperature and no vacuum advance


before a preset engine speed. Some also have spark retard during deceleration and at engine idle.

As bad as these things sound, a turbocharger may be applied to an engine with these ignition devices and still get very good performance. A turbocharger is one of the few ways of getting a large increase in engine performance without disturbing the emission-control devices,

When turbocharging an older engine not equipped with these emission devices, the spark curve should be adjusted to get the maximum out of the engine either in the naturally aspirated or the turbocharged mode. Because a turbocharged engine is normally a low-compressionratio engine running on high-octane gasoline, it is able to accept extremely advanced timing at the lower speeds when no turbocharging takes place. This was done on the Corvair Spyder where the distributor was set with an initial advance of 24° BTDC. This 24° advance gave pretty good performance until about 2,000 RPM when the engine reached crossover at wide-open throttle. Crossover is when the intake manifold pressure goes above ambient. At this point, the pressureretard device-used instead of a vacuumadvance device on the distributor-retarded the spark approximately 10 crankshaft degrees at 2 psig boost. At 3,800 RPM the engine was able to stand more spark advance even with the high intake-manifold pressure. The centrifugal advance of the distributor came into effect at this speed and advanced the spark another 12 degrees by 4,500 RPM. This combination of centrifugal advance and pressure retard was worked out on the dynamometer and, at the time, seemed to be the best compromise to get maximum power from the



Corvair Spyder distributors used a pressure-retard unit instead of a vacuum-advance unit. Spark retards when manifold sees boost, partially opposing the effects of centrifugal advance. Initial distributor setting is 24° BTDC. Curves show advance/retard production tolerances of the centrifugal and pressure-retard mechanisms.



Magnetic-suppression wire construction details.




Figure 80 - Vacuum-advance sensing line location

engine without detonation problems. As mentioned in the carburetion chapter, the carburetor used on this engine had no provision to add extra fuel to the mixture when the engine was running in the turbocharged condition. Using either a fuelenriching device or some type of water or water/alcohol injection eliminates the need for the pressure-retard device and good results have been obtained with a vacuum-advance device although it is recommended to attach the vacuum line to the intake manifold where it will sense manifold pressure rather than pressure at the spark advance port, for the same reason the power valve sensing line of the carburetor should be connected to the intake manifold instead of sensing butterfly pressure, Figure 80.

The pressure-retard diaphragm from the Corvair Spyder fits other four- and six-cylinder distributors used by General Motors from 1962–74.

The centrifugal-advance curve and pressure retard for the Corvair may not necessarily be the best for another engine and the best spark curve must be worked out either on a dynamometer or on the road. For example, in the case of 1,600cc Volkswagen, the engine seemed to operate best at 26° spark advance at 4,000 RPM. When the spark was advanced beyond this, the exhaust temperature cooled down, result-

ing in lower boost pressure and less horsepower. On the other hand, with less than 26° spark advance, boost pressure went up a little but the engine lost power due to the late ignition. Retarded timing also caused a sizable increase in head temperature.

Bill Reiste has had good success with some of the newer combination vacuum-advance/vacuum-retard mechanisms used on emission-controlled engines. He connects one port to the intake manifold and the other to the carburetor, Figure 81. By doing this he can have retard at idle, advance at part load and retard when supercharged.

Liquid-cooled engines do not seem to be as sensitive to spark timing and can usually stand more advance at less than 3,800 RPM.

As in the case of naturally-aspirated engines, there is no best ignition timing for all turbocharged engines and the ideal timing for any engine will probably be the result of a lot of cutting and trying.

The difference between a transistorswitched ignition and the ordinary distributor and coil type is that with the conventional type of ignition, whenever the points are closed, the primary on the spark chil receives a charge of current from the battery. When the points open, this charge is immediately discharged through the condenser causing a high voltage in the secondary which fires the spark plugs. The faster the engine runs, the less time the coil has to build up a charge and if the engine speed gets too high, the secondary voltage will not be great emough to fire across the spark plug. In the transistor system, the points are used merely as a trigger of a highvoltage electronic device which steps up the battery voltage before it enters the coil and therefore does not need as much time to build up a charge in the coil. Some ignition systems have been built with the higher voltage going through the points but this has a tendency to burn out the points very quickly. As long as the points are used only as a low-voltage, low-current triggering device, they should last a long time. In a breakerless ignition system) the triggering device is magnetic or optical rather than a mechanical switch. Starting and stopping of the current flow is accomplished by a solid-state diode.

Some turbocharged engines running at high speed and high boost pressures will suddenly backfire for no apparent reason. This is sometimes caused by too lean a mixture but can be the result of not enough secondary voltage. A good solid-state ignition system is sometimes the answer when this problem occurs.

To summarize, ignition does not pose any more difficult problems on a turbocharged engine than on a naturally-aspirated engine but the timing is quite different and enough effort should be spent on this item or the results might be disappointing.





Figure 81-Bill Reiste's double-acting diaphragm

EXHAUST SYSTEMS 7



Fastest stock-block-based engine ever to run at Indianapolis. Smokey Yunick's small-block Chevrolet qualified for the 1973 race at 190.8 MPH; best finish was 13th in 1975. Photo by Herb Fishel.

On a naturally-aspirated engine, the exhaust system gets combustion products from the engine to the rear of the vehicle and reduces the noise level. At the same time it is desirable to create as little back pressure as possible on the engine. On a racing car, exhaust stacks from the individual cylinders are sometimes cut to a certain length to make use of the pulses and cause a vacuum to be created at the exhaust port at the instant the exhaust valve is opened. In either case, the exhaust system is designed to rob the engine of as little power as possible.

Turbocharged engine exhaust systems are different. They duct the hot, high-pressure, high-velocity gases from the engine

to the turbocharger without reducing its temperature, pressure or velocity if possible. As mentioned in the chapter about turbocharger design, a turbine housing increases the exhaust-gas velocity to somewhere around 2,000 feet per second. This is necessary because the tip speed of a three-inch-diameter turbine wheel rotating at 120,000 RPM is about 1,600 feet per second. If the exhaust gas comes out of the exhaust port of the engine at about 300 feet per second, we don't gain very much if we slow it down to 100 feet per second just so we can speed it up to 2,000 feet per second in the turbine housing. For this reason, an extremely large-diameter exhaust manifold is not recommended.

The area of the exhaust port is about right for the manifold.

There is nothing wrong with smooth flowing exhaust headers with beautiful swerving bends, but in the case of turbocharged engines, their use is more esthetic than power-increasing. This is evident when comparing turbocharged and non-turbocharged race cars. Turbocharged engines have relatively simple exhaust systems while the naturally-aspirated or mechanically supercharged engines usually have exhaust headers designed to eliminate all back pressure if possible.

One of the drawbacks of most V-8 engines is they have 90° crankshafts. This causes two adjacent cylinders on each bank to fire 90° apart. This overlap of





Figure 83-Typical slip joint for exhaust.

DFRE sent this drawing to show how simple it is to fabricate a turbo installation without a kit. Manifolds and piping can be made from flanges and readily available tubing. Ford Cortina components are illustrated here.



exhaust pulses is not important unless the engine is used for all-out racing. To obtain maximum performance, the gases from the two ports should be ducted separately, rather than through a collector.

The problem is easily solved by using a 180° crankshaft if you can stand the vibration—and the cost of having one specially made.

On some engines, particularly V-8 engines with one turbocharger, it is desirable to have a slip joint in the exhaust duct between the two heads. Don Hubbard suggests the joint shown in Figure 83. This type has been used on aircraft engines for many years and surprisingly little leakage takes place because the inside pipe always gets hotter than the outside, causing the joint to become very tight. Don suggests 0.004 to 0.005-inch diametral clearance for mild steel and 0.005 to 0.008-inch on stainless steel.

It is not uncommon to insulate an exhaust pipe on a turbocharged engine as a means of keeping as much heat as possible in the exhaust gases. This insulation can cause other problems.

When a pipe is insulated, it becomes considerably hotter and may even get hot enough to burn out. Even if the pipe does not burn out, it tends to grow longer because of the higher temperature. If the ends of the pipe are restrained, this tendency to grow longer will put excessive stress on any bends and may cause the pipe to crack. This problem is particularly evident with the Volkswagen type exhuast.

Many passenger cars today do not have gaskets between the exhaust manifold and the head. This is not important as far as engine power is concerned although a leak could be dangerous to the passengers. A small leak at this joint on a turbocharged engine could cause a considerable boost loss. The effect is double because the turbine will slow down, not only from the lower volume flowing through it due to the leak, but also because the compressor will now be putting out less pressure due to the lower turbine speed making less pressure available to the turbine as well.

A good sandwich-type metal asbestos gasket should be used if available. The next best thing to use is a gasket cut from asbestos material backed with perforated metal. Straight asbestos-compound material is not satisfactory and will blow out in a short time. Embossed stainless

steel gaskets work well if both surfaces are very flat but are not recommended for use with stamped-steel flanges.

Even the best gaskets will not work if the exhaust manifold is warped. Check the mating surfaces for warpage and if any is evident have them machined to restore flatness.

When two or more turbochargers are used on an engine, best results can be obtained only if all of the turbochargers put out the same boost pressure. For this reason, it is desirable to use some type of balance tube between the two manifolds. A V-8 engine ordinarily has a heat riser which passes through the intake manifold to prevent fuel condensation in the manifold and ucing in the carburetor. The heat riser should be left open because it will ensure equal pressures in both exhaust manifolds. If a heat riser is not available, exhaust manifolds should be joined with a balance tube of not less than 3/4-inch diameter.

In-line engines with intake and exhaust manifolds on the same side of the head ordinarily have a hot spot in the intake manifold over an opening in the exhaust manifold. It is used for the same purpose as the V-8 engine heat riser. Because minor exhaust leaks are not important on a naturally-aspirated engine, the joint between the exhaust and intake manifold may not be perfect and will allow exhaustgas leakage if used on a turbocharged engine. Figure 84 shows how the opening in the exhaust manifold can be blocked by welding a plate in place and machining it flat so it will not interfere with the intake manifold.

Spent exhaust gases coming out of the turbocharger ideally should be flowing axially but actually will be rotating like a helix, Figure 85. The reason for this is the turbocharger is used over a broad range of engine speed and power and therefore the exhaust gases will sometimes be going faster than the turbine-wheel exducer-and sometimes slower. When they are going faster than the turbine wheel they will rotate in the opposite direction from the rotation of the turbine. When they are going slower than the turbine wheel they will rotate in the same direction as the turbine. In either case, the path for the exhaust gases will be considerably longer than if they were coming out axially. For this reason, it is desirable




Figure 84—One way to close off in-line engine heat riser


Figure 85—Turbine discharge with rapid expansion to convert swirl to turbulent flow

to break up the swirl and change the gases to turbulent flow as soon as possible after they leave the turbine housing. One way to do this is to have a sharp diffuser angle on the turbine housing, Figure 85. This requires a large-diameter exhaust pipe from the turbine housing. Once turbulent flow is established, it is not important for the exhaust pipe to be that big and after about eighteen to twenty-four inches, a smooth reduction in the cross section of the exhaust pipe will not create much additional back pressure and will help quiet exhaust noise. In some cases it will do such a good job that a muffler will not be required.

When a muffler is used, don't be misled by the amount of noise you hear at the back of the vehicle. The original Corvair Spyder muffler was extremely quiet but added very little back pressure to the system. When comparing one muffler to the other it is best to have a pressure gage between the turbine exhaust and the muffler.

Sometimes installation considerations cause the turbocharger to end up with the exhaust very close to an obstacle such as the engine-compartment firewall. When this happens, there may not be enough room to get an elbow between the turbine outlet and the exhaust pipe. Figure 86 shows a banjo-type turbine discharge sometimes used in close quarters.

Actual exhaust-pipe diameter used on a turbocharger system often depends on



Exploded parts drawing of Car Corp. Pinto 2000cc kit components with cast exhaust manifold. Simple exhaust design is all that is required for the turbo. Free-flowing or "tuned" headers are not necessary and sometimes actually detract from the performance of the engine. Turbo Systems now makes this kit.





Figure 86-Banjo-type turbine discharge.




Duke Hallock wrapped the exhaust pipe coming from the turbine to reduce underhood temperature.


the application. Even on an all-out racing engine it may not be desirable to use as large an exhaust pipe as possible because a slight restriction in the exhaust pipe will be much more effective at high engine speeds than at lower speeds. This can be used as a fail-safe method of limiting manifold pressure without paying any power penalty at low and medium engine speed.

A leak in the engine-exhaust system large enough to cause considerable loss of boost may not be detectable to the ear because it will not necessarily leak at idle conditions, and at high engine speed everything makes so much noise even a


large leak between the engine and turbine is hard to find. The can be very aggravating because the turbocharger will not produce full boost and maximum power. The easiest way to check this is to block off the turbocharger exhaust completely while the engine is idling. If the engine continues to run, the leak is too big. When an engine does not deliver full power, the turbocharger will always be blamed. If the turbine and compressor wheels are intact and the shaft can be rotated, chances are 100 to 1 there is a leak in the exhaust system leading to the turbo.



Gary and Jerry Mallicoat held B-Gas-Supercharged record in 1965-66 with this turboed 327 CID Chevy in a 3000-pound 1941 Willys coupe. 139 MPH quarter-mile speed with 10.18-second ET's. Two AiResearch turbos with seals on compressor side were fed by twin four-barrel carbs. Rochester FI manifold distributed the mixture. Engine produced 590 HP at 7200 RPM with Roots blower; 714 HP at 7000 with turbos. Photo courtesy Mallicoat Brothers.



TRW put this turbocharger in a 1962 Chrysler 300 with a Solex two-barrel progressive side-draft carburetor. Special turbine housing simplified exhaust connections to center-mounted turbo.





Mallicoat Brothers' 2400-pound glass-bodied BB Altered Gas class car turned 172.45 MPH at an 8.31-second ET in 1971. Chrysler hemi 467 CID engine produced 843 HP with a fully blueprinted Roots-type blower; 1,130 HP at 7000 RPM with two AiResearch TE06 turbos. Car was 10 MPH faster in turbocharged form. Note simple exhaust manifolding. Intake manifolds and injectors are Hilborn units.





Experimental Oldsmobile 350 Cutlass installation by Rajay had new outlet welded onto each stock exhaust manifold. Aluminum foil on turbine inlet reduces heat loss so turbine operates with best efficiency. Wrapping the turbine housing and outlet pipe is done for safety and to reduce heating of the engine compartment. Two turbos were used in this installation.




Ak Miller displays his Pinto kit exhaust manifold, Manifold locates turbo so battery must be moved to left side. Gasoline and LPG kits are available.

Bill Fisher photo.





1963 Pontiac Grand Prix with 389 CID V-8 engine used single TRW turbocharger with custom-made two-barrel side-draft Rochester carburetor with progressive linkage. Air cleaner drew cold air from area ahead of windshield. Specially made turbine housing simplified exhaust connections to single center-mounted turbo.



OIL SHOULD DRAIN INTO CRANKCASE ABOVE THE OIL LEVEL

Figure 87-Right and wrong way of draining oil from turbocharger

Turbocharger bearing and seal design was covered in Chapter 2, Turbocharger Design, but that is only half the story. A means must be provided to get clean lubricating oil to the bearings, and just as important, to get the spent oil back to the engine crankcase.

All turbochargers described in this book are designed to use engine lubricating oil. The actual type and viscosity will be dictated by the engine but, in general, a turbocharger will operate well on any oil that will work in the engine.

It is not necessary to install a special oil filter in the turbocharger oil line if the engine is equipped with an oil filter which passes particles of 30 microns or less. If an engine is not equipped with a full-flow oil filter, then a filter is definitely recommended in the oil-inlet line and it should be of the type with a built-in

bypass so oil will still get to the turbocharger even if the filter is clogged with dirt. It is not uncommon for a turbocharger to fail from lack of oil because the user has not serviced his oil filter. On the other hand, the life of a turbocharger running on dirty oil can be measured in hours.

It is usually safe to draw oil for the turbocharger from the opening where the low-oil-pressure light or pressure gage is normally connected. A tee should be placed in the line at the turbocharger end and the switch or pressure gage connected there. If there is a restriction at the point where the oil was taken off the engine, this will show up as low oil pressure as soon as the engine is started. Another test which should be made to ensure adequate oil to the unit is to disconnect the oil line from the turbocharger while the


engine is idling and measure the oil flow by running it into a bucket. At least .5 gallon per minute are required for each three-inch turbocharger and about 1.0 gallon per minute for each three and one half or four inch turbocharger.

Quarter-inch OD tubing is sufficient for a three-inch turbocharger while at least 5/16-inch OD tubing should be used for a three and a half or four-inch turbocharger. These tubing sizes are adequate if the engine is running on hot oil with at least 30 psi pressure. If the oil viscosity in the engine is too high for the ambient temperature conditions, no oil will flow to the turbocharger when the engine is first started. Here again, the low-oil-pressure switch or pressure-gage connection at the turbocharger will show this. If the engine is started and driven off under power before oil gets to the turbocharger,






280 HP from 122 CID was produced by turbocharged and fuel-injected BMW 2002cc engines. Cars ran successfully in European road-race events during 1969-70. Automotive News for October 4, 1971, quoted BMW's top engine man on that firm's plans for retaining their sporting image and meeting increasingly tough emission requirements. Alex Von Falkenhausen said that the turbocharger helped to reduce NO_X emissions and, combined with fuel injection, made it "seem possible to meet hydrocarbon standards for the foreseeable future using U.S. test cycles." Note large drain line from turbo to sump.



BMW 2002cc engine uses Kugelfischer fuel injection and Eberspaecher "EBO" Turbolader (turbocharger). Electronic ignition triggers precisely from flywheelposition sensor. Photos courtesy Bayerische Motoren Werke.



the bearings can be wiped out in a matter of minutes. Never use a screen or restrictor orifice in the turbocharger oil-supply line. Either will clog quickly and cause early turbocharger failure. If the oil pressure is so high the added flow causes drainage problems, it is better to place a pressure-reducing valve in the line than an orifice.

Oil entering the turbocharger from the engine is relatively air free but after passing through the bearings running as high as 130,000 RPM, it looks like dirty whipped cream. For this reason, it is necessary to have a much larger drain line on the turbocharger than on the oil-intake line. It is also necessary to have the line slant downward at all points without any kinks or sink traps. The drain line must dump oil to the crankcase above the oil level in the crankcase. Looking at Figure 87, the sketch on the left shows the oil line entering the crankcase below the oil level. This causes foamy oil to build up in the line and back up into the bearing housing of the turbocharger. The only place it can go from there is out through the seals. Many people have torn down turbochargers to replace leaking seals only to find they appeared as good as new. Chances are they were as good as new.

Before the days of emission-control devices on engines, the crankcase was normaily equipped with a breather to prevent pressure from building up in the crankcase. This pressure is caused by blowby which occurs in all engines and is the result of high-pressure gases leaking by the piston rings of the engine. The breather allowed the blowby gases to escape but contained some kind of a filter element to prevent dirt from entering the engine. These breathers should be serviced regularly or they will become partially clogged and pressure will build up in the crankcase, preventing a free flow of drain oil from the turbocharger.

All passenger-car engines built today are equipped with a positive crankcase ventilation (PCV) device. The PCV design will vary with the engine but usually it will have one line going from the valve covers to the air cleaner and another line from the valve covers to the intake manifold. The line to the intake manifold is normally equipped with a PCV valve. This valve is designed to restrict flow from the crankcase when intake-manifold

vacuum is high and blowby is low. On the other hand, it has low restriction at full power when the intake manifold vacuum is low and the blowby is high. If the PCV valve is not serviced regularly, it will stick and cause pressure to build up in the crankcase. This, of course, will prevent the oil from draining properly from the turbocharger and cause leakage through the seals.

If your turbocharger shows signs of leaking oil into either the turbine housing or the compressor housing, be sure to check all these points before tearing it down only to find nothing is wrong.

When installing a turbocharger on an engine-particularly if it is part of a bolton kit-most people do not want to remove the engine from the vehicle unless absolutely necessary. Attaching the oil drain to the pan is rather difficult unless the pan is removed from the engine. In many cases, this can only be done by removing the engine from the vehicle. Because of this, it is desirable to find some other place to drain the oil back to the engine. If the turbocharger or turbochargers are mounted high enough, the oil may be drained back to one or both of the rocker-box covers. This will work on some engines but not on others because some have a problem of getting rid of the small amount of oil used to lubricate the rocker arms. Additional oil coming from the turbochargers can flood the rocker housing and back up into the turbocharger. On in-line engines, the plate which covers the valve push rods is often a good place to drain the turbocharger oil. Some V engines have either a hole through the intake manifold into the valley between the heads or, at least, has a place in the intake manifold which has neither an air or water passage which can be drilled for draining oil back to the valley.

If the turbocharger is mounted so low it is not practical to drain the oil back to the engine, a scavenge pump must be used. This is often the case on an airplane engine where the only practical place to mount the turbocharger is beneath the engine. Remember the scavenge pump must have a much greater capacity than the amount of oil used by the turbocharger because of the air which gets mixed with the oil as it passes through the turbocharger. A scavenge pump for a


three-inch turbocharger should have a capacity of 1.5 gallons per minute. Aviaid Metal Products Company manufactures a scavenge pump specifically for turbocharged engines. This mechanical unit literally sucks the oil out of the turbocharger and pumps it into the engine sump. They are made in several sizes.

Most engines have an oil pump with enough capacity to handle a turbocharger as well as the engine. As mentioned earlier, if the oil-pressure gage at the turbocharger has a low reading, it is probably because of a restriction at the oil source rather than lack of oil-pump capacity. If it is established that there is no restriction on the oil supply and the oil pressure is still low, then a larger oil pump should be used. High-capacity pumps interchangeable with stock pumps are available for many engines but chances are one won't be necessary.

Innumerable high-capacity oil pumps available for Volkswagen engines are usually advertised for the purpose of lengthening the life of the crankshaft. Many turbocharged Volkswagens have been driven for what would be considered a high number of miles on a naturally-aspirated engine without excessive crankshaft wear. These engines were equipped with an oil filter which was probably more important than the high-capacity pump.


A turbocharger running at design speed will add about 80°F, to the oil as it passes through the bearings. Because the turbocharger is idling most of the time it is on a passenger car, this additional heat occurs only occasionally and the oil does not run much hotter than it would if the engine was naturally aspirated. This is not necessarily true on a truck, bus or a motorhome where the turbocharger may be used for extended periods. On any of these applications I recommend installing an oil-temperature gage on the engine. If the oil temperature goes above 250°F, install an oil-cooler. These come in many shapes and sizes depending on the engine and the application but the important thing is to keep the oil cool to prevent oxidation.

A turbocharger lubricated with clean oil at engine pressure can be run for many years without any visible signs of wear on the bearing journals. On the other hand, if dirty oil or no oil at all is supplied to the turbocharger even for a short period of time, the chances are the unit will be short-lived.




Turbocharged Offenhauser engine undergoing dyno test with AiResearch TE0659 unit. Fuel-injection pioneer Stuart Hilborn barely got into this photo. Waste gate plumbed to underside of header does not show clearly in this photo. Hilborn is changing the "pill," a jet in the fuel-return line which establishes mixture.

9 CONTROLS



George Spears, provided these photos of two controlled turbocharger installations. The top photo is a Porsche 911 with fuel injection. An Impco control is used to regulate boost to 11 psi for about 300 HP. Rajay 375E.7 turbo. Installed by Bob's Automotive in Lawndale, California. Lower photo of an MG Midget controls boost by the carburetor size and exhaust restrictions. Original rear-wheel HP was doubled to 70 HP with 11 psi boost. Rajay 301B.25 turbo installed by Shelby-Spearco.



Given enough time and money, it is possible to design a turbocharger engine combination to match the operating conditions—assuming they are known and achieve optimum performance without any movable controls. The problem is, most of us do not have either the time or the money to do this and unless some type of control is used, the turbocharged engine will have to be a compromise and not achieve either maximum available horsepower or peak response. For street use or perhaps even for a Bonneville-type racer, a turbocharger can be matched to an engine without the use of controls and still give excellent performance.

This is not necessarily true in the case of a racing engine, whether it be for track, drag or boat racing. As an example, when a race driver is qualifying his car, he must get maximum horsepower from the engine but is not particularly concerned with durability. After the qualification is over and the race is run, then horsepower and reliability are equally important. If an adjustable control were not used here, then it would probably be necessary to use a different turbocharger for qualification than for the race. A similar situation could occur with a drag racer or a drag boat where adjustment of the maximum boost available could be made easily for maximum overall engine performance. It certainly would not be practical to change turbine-housing sizes between each run.

Another advantage of a turbocharger control is that it allows the turbocharger to be run at or near its maximum speed without bursting so long as the control works properly.

Turbocharger controls can generally be divided into two categories. Those which limit the speed of the turbocharger to prevent it from destroying itself; and those which limit the compressor-outlet pressure to keep it from destroying the engine. Because modern turbochargers will normally produce more pressure than the engine can stand, most controls are designed to limit compressor-outlet pressure.

The blowoff valve in Figure 88 is the simplest and also the least precise method of sensing turbocharger speed and controlling it at the same time. Although the valve itself might be either a poppet or flapper type, it will be subject to flutter-




Figure 88-Turbocharged engine with simple exhaust-blowoff valve

ing unless a damper is attached. The valve will be opened by turbine-inlet pressure only, and although this will have a relationship to compressor-discharge pressure and rotor speed, neither will be exact. If flutter does occur, the valve will destroy itself in a short time.

It is possible to locate a blowoff valve on the compressor-discharge duct, Figure 89, but this is only recommended on a fuel-injected engine or where the compressor blows through the carburetor. This again is not an exact control and is subject to flutter. This type control has been tried as a manifold-pressure-limiting device by some racing officials, but racers are smart people and it did not take long for them to figure out it could be fooled by

using a larger compressor. When the flow of the compressor is much larger than the valve capacity, the valve no longer limits manifold pressure.

Figure 90 shows a compressor-inlet-controlled system. This system places a butterfly between the carburetor and the compressor. The valve reduces the air flow to the compressor and limits the manifold pressure. It has the advantage of the valve being on the cold end. The disadvantage is the manifold pressure is limited while the rotor speed might increase. It is not a good way of controlling maximum turbocharger speed. This higher speed also results in higher intakemanifold temperature while the pressure is being controlled.





Figure 89-Turbocharged engine with compressor-blowoff valve


Figure 90—Compressor inlet-control system

From a performance and efficiency standpoint, a variable-area nozzle as shown in Figure 91 is the best way to control turbocharger speed. With this method, all the gas goes through the turbine at all times and none is dumped overboard. The nozzle is opened and closed by an actuator controlled by the sensor. This method is often used on air turbines but is too expensive and unreliable for turbochargers because of the hot inlet gases. The mechanism must be made from materials which have good strength and corrosion resistance at elevated temperatures. Even then, combustion products will tend to jam the vanes and prevent reliable operation.


The most popular method of controlling turbocharger speed is with a wastegate or turbine-bypass valve. It can be either a butterfly—Figure 92; or poppet valve— Figure 93. The valve may be operated manually, Figure 94, by intake-manifold pressure, Figure 95, or by a servo motor, Figure 96. The servo in turn may be controlled manually or by a device which senses turbocharger speed, pressure ratio, gage pressure, absolute pressure, density, or air flow.

Figure 91-Turbine with variable-area nozzle







Chuck Sarson built his own waste-gate valve.



Chuck Sarson waste-gate valve disassembled.









Figure 94-Manually-operated waste-gate valve






Figure 95—Waste gate controlled by intake-manifold pressure

Figure 96—Waste-gate valve controlled by servo motor




Figure 97—Pressure-ratio sensor

COMPRESSOR DISCHARGE ATMOSPHERIC PRESSURE (PC₂)

SERVO
VALVE

DIAPHRAGM

Figure 98-Differential-pressure sensor

Figure 99-Absolute-pressure sensor





Figure 100-Density sensor



Turbocharger speed can be sensed by an electronic device and through the use of proper amplifiers operate a wastegate to control turbocharger speed. Because this requires not only an electric power source but rather elaborate electronic equipment, turbocharger speed is normally sensed by means of a pressure-ratio sensor because the pressure ratio on any specific installation is a direct function of speed. A pressure-ratio sensor is shown in Figure 97. This type sensor was used extensively years ago when turbochargers were run at the physical limits of the compressor impeller. If an engine equipped with a turbocharger were moved from sea level to some higher altitude, the turbocharger speed would increase if it were not controlled. The pressure-ratio sensor prevented this speed increase and allowed the engine

to be operated at high altitudes without requiring any changes in the engine or turbocharger.

A differential-pressure sensor in Figure 98 will sense the pressure differential across the compressor if PC₁ is connected to the compressor inlet and PC₂ is connected to the compressor outlet. If, however, PC₁ is vented to atmosphere, then it becomes a gage-pressure sensor, the most popular type used on engines operated mainly at one altitude. This type sensor connected to a wastegate will start dumping exhaust gas when a preset intakemanifold pressure is reached and will hold this pressure constant as the engine speed and power increases as long as the capacity of the wastegate is adequate.

An absolute-pressure sensor shown in Figure 99 is similar to the differential-

pressure sensor except that the volume around the spring is enclosed in a bellows evacuated of air. This vacuum not only gives an absolute-pressure reference but is not affected by air-temperature changes. This sensor type is desirable when the engine is to be used at many different altitudes such as an airplane engine. It has the big advantage of limiting the intakemanifold pressure to the same absolute value regardless of altitude of barometric conditions.

A density sensor, Figure 100, must be placed in the discharge-air stream of the compressor because it senses compressor-discharge temperature as well as pressure. It is a little fancy for the type of control we are talking about here and normally would not be used in a racing type of application.

A flow-control sensor, Figure 101, senses compressor-inlet flow by the differential pressure across the venturi. This type of control would be used where maximum torque is required at relatively low speed and it is possible with this type of control to have a higher boost pressure at low and medium speeds than at maximum engine speed. An engine equipped with this type of control would have a tremendous torque increase as the engine is slowed down.

Recently, a rather simple device has become available which can be placed between the compressor outlet and engine on an existing installation. It is called the IMPCO TC2 Turbocharger Pressure Control Valve and is shown in a typical installation in Figure 102.

Figure 103 is a cross-section. Operation is self-explanatory and the operating pressure may be changed simply by changing the spring.

Figure 104 is an exploded view of the valve.

This valve should be very reliable because it is on the cold side and has only two moving parts. However, it could cause the compressor to surge if the operating line were too close to the surge line. This is a rather remote possibility and probably will not occur on a passenger-car installation.




Figure 101-Waste-gate valve controlled by flow sensor




Figure 102—Chevrolet big-block 454 CID boat engine with high-boost installation by Gale Banks. Note intercooler housing atop intake manifold. Two holes in end of intercooler are for water inlet/outlet. Arrows indicate IMPCO pressure-limiting valves described in text.





Figure 103—TC2 control valve has spring-loaded piston/sleeve valve in an enclosed housing. Spring pressure keeps piston/sleeve valve in open position as shown. This allows full pressure from turbo to flow through.



As pressure from the turbo increases, it works against the coneshaped face of the piston. When pressure reaches the predetermined control point the spring will be compressed as shown. Piston/sleeve valve can move to close passage almost completely. This type of valve also limits RPM as it reduces volume of mixture supplied to engine.




Figure 104-Exploded view of IMPCO valve





Figure 105-Waste gate operated by hydraulic servo

Figure 106-"Part-throttle open" waste gate valve



The combination of a device which senses intake-manifold gage pressure and a poppet-type wastegate valve is the most common method of controlling turbo-charger speed. Where ambient conditions are not likely to change abruptly, such as a racetrack, this type device is simple and fairly reliable. If the ambient conditions will change considerably such as the Pike's Peak Hill Climb, Ted Trevor has found the gage-pressure sensor is not adequate and suggests using an absolute-pressure sensor if one is available.

Most wastegates of this type use the intake-manifold pressure to open the waste gate against the force of a spring, Figure 95 A more exact method is shown in Figure 105 where the intake-manifold pressure operates a small hydraulic valve which allows engine oil pressure to flow through the wastegate servo and open the valve. This system has two advantages over the direct-operating wastegate in that it can use a smaller diaphragm on the wastegate because the oil pressure is usually much higher than the intake manifold pressure to be controlled. Also, since the oil is incompressible, the possibility of the wastegate valve chattering is eliminated.

On the other hand, the added complication of the hydro-pneumatic-servo leaves something else to go wrong. It can be made fail-safe by being spring-loaded. If the oil-pressure line fails, the valve will move to the full-open position.

When an engine such as that used in a passenger car is equipped with a free-floating turbocharger system which will not overboost the engine even at maximum conditions, back pressure on the engine at ordinary road loads is often less than that with a normal muffler system. To make a wastegate effective, it is always accompanied by a smaller turbinehousing area. This smaller turbine housing will cause more back pressure on the engine, particularly at road load. For this reason, automobiles equipped with a wastegate will ordinarily get poorer fuel mileage than one without wastegate. It is desirable to have the wastegate open at all conditions except when the turbocharger is needed for extreme acceleration or top speed. The part-throttle-open valve shown in Figure 52, Patent 3257796, invented by Stanley Updike, does this and without complicated linkage. Looking at


Figure 106, notice that the upper diaphragm is connected solidly to the valve stem while the lower diaphragm is free to slide on the stem. A snap ring on the valve stem causes the lower diaphragm to open the valve but this diaphragm cannot close the valve. The chamber above the upper diaphragm is connected to the compressor inlet where it senses the pressure drop through the carburetor. The chamber below the lower diaphragm is connected to the intake manifold and senses both vacuum and pressure. At cruising power, the pressure drop through the carburetor will create a vacuum in the upper chamber which overcomes the spring and causes the valve to open when the pressure drop to the carburetor is greater than three inches Hg gage. During acceleration and at very high vehicle speeds, there will be little or no drop through the carburetor and the upper spring will cause the wastegate valve to remain closed. When the maximum desired manifold pressure is reached, the pressure underneath the lower diaphragm will overcome both the lower and upper springs and open the wastegate to maintain a relatively constant intake-manifold pressure. This type control has the same good low-end performance as a simple wastegate when connected to a small turbine housing and still prevents the engine from being overboosted at high engine speed. Because the turbine is bypassed at normal cruising speed, the engine has very little back pressure and will get better fuel mileage. Another advantage of the PTO Valve is it opens and closes every time the engine is accelerated and goes from the full-close to the full-open position every time the engine is started. An ordinary wastegate, on the other hand, may be operated for weeks without opening if the engine is never pushed hard enough to reach maximum intake manifold pressure. This inactivity is frequently the cause of a wastegate valve sticking.

The use of a control not only improves the low-end performance of a turbocharged engine but makes the job of choosing a carburetor and tailpipe much easier. The carburetor can be much larger because it will not be used to limit boost pressure. Duke Hallock has found when a large carburetor is used in conjunction with a wastegate control turbocharger, he uses a



Chevy small-block V-8 installation in a Ford Ranchero used exclusively for speed runs at Bonneville Salt Flats. Cragar machinist Bill Edwards owns the car and made the installation of two AiResearch TE0659 turbos with waste gates. Note plenums, Bosch fuel injection.

Setup similar to that on Chevy II on author's 230 CID Chevelle. Carburetor venturi was enlarged to 1-1/2-inch diameter and the waste-gate diaphragm diameter was increased for more positive actuation. Car was driven over 70,000 miles without removing the head.





A. J. Foyt's use of the AiResearch turbocharger and controller (waste gate) on Ford racing engine was a trendsetter because standard "wear" on these engines had previously been another make turbo. Photo made at Ontario Speedway — 1971 California 500 — by Duke Hallock.

compressor with 10% to 15% less flow capacity than he would use with a free-floating turbocharger. One of the reasons for this is the smaller turbine nozzle A/R normally used with a wastegate system could drive a compressor into surge which would never occur with a free-floating system. This problem would be remote in a light sports car but could definitely happen on a heavy vehicle climbing a long hill.

Charles McInerney has found that a turbine housing which works best on a dynamometer will nearly always be about 10% too large for driving. This means about 1 A/R ratio.

For any given turbine as the A/R ratio decreases, the turbine speed increases up to a point. If the A/R is too small, it will cause a large drop in the efficiency of the turbine and the added back pressure on the engine may cause more losses in power than the added intake-manifold pressure achieved. If this condition should occur, it is advisable to use the next smaller size turbine wheel and go back to a larger A/R.

Bob Keller of Accel has come up with a neat idea called a priority valve, Figure 107. This device, when assembled with the Accel Turbo-Module in Figure 108, allows the engine to run naturally aspirated until the compressor has a positive discharge pressure. At this point the priority valve closes the bypass between the carburetor and the intake manifold causing the air-fuel-mixture to pass through the compressor and become supercharged. This device allows the engine to act as if it were naturally aspirated until the throttle is open far enough to ask for help from the turbocharger compressor.

Bill Reiste and Jim Deatsch have come up with a similar device except the valve is a free-floating flapper actuated by the pressure differential inside the carburetor box.

As a general statement, I would say a free-floating turbocharger engine combination, Figure 109, can give low-cost performance to an engine which is outstanding for the amount of work required. However, for the ultimate in performance, whether it be a dragster, a track racer, sports car, boat or airplane, some type of control is necessary and is worth the added expense.







Figure 109-Boost pressure limited by fixed restrictions

This experimental set up by AiResearch uses one turbo at low engine speed and two at high speed. (This arrangement is NOT recommended for amateurs.)






Non-adjustable AiResearch waste gate is actuated by boost pressure from intake manifold. Valve typically opens less than 1/8 inch to bypass sufficient exhaust to reduce turbine speed and boost pressure. Arrow indicates connection for control piping. Adjustable waste gates have a screw in the cover to adjust the spring height, which adjusts the boost pressure. Racing mechanics often refer to this as a "horsepower screw." Screw it down and more HP — and perhaps a scattered engine — will result.



AiResearch T-5 turbocharger used on Oldsmobile 1962 Jetfire. Compressor housing was heated with engine jacket water. Turbine inlet is at bottom center and outlet at Left. Disc-shaped part at right is waste-gate-diaphragm housing.

INTERCOGLING 10





Air-to-water intercooler for turbocharged gasoline marine engine by Harrison Division of GM. Used on Daytona Marine engines and numerous marine conversions.

Whenever a group of engine men get together and someone brings up the subject of intercooling, invariably someone else says you mean aftercooling or if someone discusses aftercooling, someone else says intercooling. In any case they are usually referring to cooling the air or air-fuel-mixture somewhere between the compressor discharge and the engine. Many engineers use the all inclusive term charge-air-cooling.

The charge is cooled by ducting it to a heat exchanger which may use ambient air, ice water, sea water, or engine jacket water as a cooling medium, Figure 110. The temperature drop of the charge air passing through the heat exchanger will be a function of several factors. It will vary with heat-exchanger size, the temperature of the cooling medium and the available flow rate of the cooling medium. There will always be a pressure drop of the charge as it goes through the heat exchanger and the amount of the pressure drop must be weighed against the temperature drop as there would be no advantage to lowering the charge temperature say 100°F, and then lose half the pressure. If the charge air passing through the heat


Figure 110-Turbocharged engine with intercooler






Modine air-to-water intercooler bolts into intake manifold of Caterpillar 0336-V8 diesel engine. Two are used to cool charge air approximately, 150°F, using engine jacket water as the cooling medium.

Typical air-to-water intercooler made by Harrison Division of GM. This unit is used on some International Harvester engines.





Modine air-to-air intercooler allows cooling charge air to within approximately 20°F of ambient temperature. Air that can be ducted to such an intercooler reduces the charge temperature more than a water-to-air unit because a greater temperature difference can usually be achieved than provided by 180°F jacket water.

exchanger does not become considerably more dense, then the heat exchanger is doing only half its job, As a rule of thumb, 1°F, decrease in intake-manifold temperature will result in 1°F. drop in exhaust temperature. For example, if an engine has an exhaust temperature of 1500°F. and through the use of an intercooler we are able to reduce the intake manifold temperature by 100°F., we will also lower the exhaust temperature to 1400°F, at the same time. This not only makes it easier on the exhaust valves, but cuts down on the heat-rejection requirement of the engine unless jacket water is used as the cooling medium.

Besides reducing the heat load on the engine, the higher charge density will allow more mass of air per minute to flow through the engine at any given intakemanifold pressure. This means more fuel can be burned and the engine can produce more horsepower. As an example, suppose a 151 CID engine running at 10,000 RPM with an absolute intake-manifold pressure of 120 inches Hg Abs produces 900 HP. The intake-manifold temperature, assuming 65% compressor efficiency will be 487°F., and the mass air flow through the engine will be about 900 pounds per hour.

If a heat exchanger is placed between the compressor discharge and the engine with only 50% effectiveness on a 100°F. day, the intake-manifold temperature will be reduced to 293°F. and even if the intake-manifold pressure is lowered to 100 inches Hg Abs, mass flow will increase to 941 pounds per hour. In addition, for the same horsepower and air/fuel ratio, exhaust temperature will be reduced by approximately 194°F.

The advantages to the engine are twofold. First the overall operating temperature of the engine will be reduced and secondly the combustion-chamber pressure for a given BMEP will also be reduced, lessening stress on the engine.

If we had a perfect heat exchanger, the temperature of the charge air could be reduced to that of the cooling medium without any drop in pressure. This, of course, is not possible because there will always be a pressure drop through the heat exchanger and it is not possible to lower the charge temperature to the cooling-medium temperature.

If the charge-air temperature is 200°F. and the cooling-medium temperature is 100°F. and we are able to lower the charge temperature to 150°F., the heat exchanger has an effectiveness of 50%.

$$\frac{200^{\circ} - 150^{\circ}}{200^{\circ} - 100^{\circ}} = \frac{50}{100} = .5$$

If a better heat exchanger is used which can drop the charge temperature to 130°F., the effectiveness is 70%.

$$\frac{200^{\circ} - 130^{\circ}}{200^{\circ} - 100^{\circ}} = \frac{70^{\circ}}{100} = .7$$

Seventy-percent effectiveness is a reasonable value and will be used for examples in this chapter.

Assuming a compressor-discharge temperature of 250°F, and an ambient temperature of 75°F, a 70% effective air-to-air heat exchanger will reduce the charge air temperature (250 - 75) x .7 = 122.5°F. The charge temperature leaving the intercooler will be 250 - 122.5 = 127.5°F.

If jacket water is used at 180°F., the drop in temperature will be (250 - 180) x .7 = 49°F. This will result in a charge-air temperature of 201°F. This small decrease makes it impractical to use jacket water unless the compressor-discharge temperature is at least 300°F.

Using a low-temperature liquid such as sea water at 75°F, will result in the same charge-air temperature (127.5°F) as an air-to-air heat exchanger but the air-to-liquid type will be much smaller and will not require a fan to circulate the cooling medium.

A drag racer or a Bonneville-type car can carry enough low-temperature liquid to cool the charge in much the same way that a tank of liquid is used to cool the engine. The tank could contain ice-water or acetone or alcohol with chunks of dry ice. Caution should be used with cooling media below 32°F, because the charge side might become clogged with ice on a humid day. Tom Keosababian used a Freon spray on one of his intercooler installations.

Let us start with a 300 CID engine turbocharged to 30 in. Hg gage boost at sea level with a 30 in. Hg Barometer and 80°F, ambient. The engine is run on a dynamometer and produces 350 HP at some speed. Assuming a compressor efficiency of 70%, the compressor-discharge temperature can be calculated. The





"Turbo Honker" Dodge with 7:1 compression ratio hemi engine assembled by Bud Faubel and George Weiler in 1966. Two ice-water-cooled intercoolers, one in each front fender and two T18 free-floating AiResearch turbos were used. Car turned 160 MPH in the quarter mile. Alex Walordy photo.

compressor pressure ratio is:

Comp. Out Absolute Press.

Comp. In Absolute Press.

$$=\frac{30+30}{30}=\frac{2}{1}$$

Refer to Table 1.

When r = 2. Y = .217

Ideal Temp. Rise = $(80 + 460) \times .217$

 $= 540 \text{ x} .217 = 117^{\circ} \text{F}.$

Actual Temp. Rise = Ideal Temp. Rise

Comp. Eff. = $\frac{117^{\circ}}{7}$ = 167° F.

Compressor Discharge Temp.

 $= 80^{\circ} + 167^{\circ}$

 $= 247^{\circ} F.$


Now if a 70% effective air-to-air heat exchanger is placed between the compressor discharge and the intake manifold, it will lower the charge temperature.


$$(247^{\circ} - 80^{\circ}) \times .7 = 167 \times 7^{\circ} = 117^{\circ} F.$$

The temperature entering the engine will now be $247^{\circ} - 117^{\circ} = 130^{\circ}$ F.

Because the heat exchanger is not ideal, there will be a loss of pressure through it. To be conservative, assume a 2-inch Hg loss. Using these figures, the increase in density with the heat exchanger will be

$$\frac{247 + 460}{117 + 460} \times \frac{30 + 28}{30 + 30} = \frac{707}{577} \times \frac{58}{60} = 1.18$$






Jim Kinsler installed a 327 CID Chevrolet in a Maserati chassis in 1965. Large plenum with modified Rochester fuel injection used Chevrolet heater core as an intercooler. Liquid silicone cooled with dry ice circulated through the intercooler. Small photo shows intercooler and plenum details. Carbureted installation with two Quadrajets was used for street operation. Turbos are E-flow Rajays.

Bill Edwards' 327 CID Chevrolet equipped with AiResearch turbos in a free-floating configuration. Bosch fuel injection is used. Intercoolers mount in housings fabricated by Edwards. Engine is used for Bonneville Salt Flats high-speed attempts.





As a result, the intercooled engine can put out 18% more power at the same speed with 2 inches less manifold pressure. There is, however, a catch to this. In some cases, the exhaust temperature and pressure will drop in proportion to the intakemanifold conditions. When this happens, the turbocharger will slow down, further reducing the intake-manifold pressure. When this occurs, it is necessary to use a smaller turbine housing to maintain the same boost pressure.

Engines which run on gasoline are sensitive to charge temperature because of both pre-ignition and detonation limits. The octane requirement for a given engine output can be reduced substantially by intercooling. The tendency for a combustion chamber to develop a hot spot and ignite the charge before the plug fires is also reduced by intercooling.

It is possible to cool the charge below the temperature of the cooling medium by compressing it further with a secondary compressor, cooling it and expanding it through a turbine used to drive the secondary compressor, Figure 111. This method is used on some large stationary diesels with good success but it is rather complicated for a small engine.

Things aren't quite so bad as they were a few years ago as to procuring heat exchangers. Tom Scahill makes a liquid-to-air heat exchanger available as a bolt-on item for big-block Chevy Engines. This is designed for marine use but would work well on either a drag racer or a Bonneville Streamliner with a water reservoir.

It is possible to connect turbochargers in series and obtain intake manifold pressures of over 100 psig if heat exchangers are used between the compressors as well as between the second compressor and the engine. This method is discussed in detail in Chapter 15, Tractor Pulling.

1971 Olds 350 Cutlass turbocharged with two Rajay units was initially equipped with two special Rochester sidedraft carburetors. Turbo outlets oppose each other in connector above manifold opening. Carturned 105.41 MPH at 13.82 seconds ET at Orange County Raceway.





Figure 111-Turbocharged engine with air-cycle charge cooling





454 CID big-block Chevy in Southwind jet boat. Gale Banks engine. High boost with over-transom exhaust produced 873 HP on dyno using Av-gas, Rajay turbos and a single 4-barrel.

MARINE ENGINES 11

In some ways, marine engines are a lot easier to turbocharge than automobile engines and in other ways, they pose problems not encountered in automobile engines. In an automobile engine, even those equipped with a torque converter, engine speed at full throttle is limited by the instantaneous automobile speed and the gear ratio. An engine mounted in a boat driving a propeller can be accelerated until it is near its maximum speed long before the hull of the boat reached its maximum speed. In the case of a jet boat, the engine can be revved up to peak speed while the boat is still tied to the dock. For this reason, power available from the engine can only be fully utilized when it coincides with the power required by the hull. Figure 112 illustrates this for a non-planing hull. The shape of these curves will differ for each hull but the situation is about the same.

Except in the case of a drag boat, it is obvious that the extra power available at low hull speeds is of little use as long as the engine can approach full speed regardless of hull speed. As an example, supposing a boat is cruising at 20 knots and 2200 RPM and the throttle is opened fully. If the engine then accelerates to 4400 RPM immediately and remains there when the boat reaches 30 knots, then the extra torque available at 2200 RPM is of no value.

Turbocharging a marine engine makes it possible to produce a power curve which matches the engine closer to the hull requirement. Looking at Figure 113, the power available from the engine comes closer to the hull requirement and results in a more efficient system.

In Figure 114, available power curves are plotted for both naturally-aspirated and turbocharged engines in the same hull. Propellers are matched to the engines to make each power curve cross the hull-




Figure 112—Engine power available compared to hull requirement with a naturallyaspirated engine

Figure 113—Engine power available compared to hull requirement with a turbocharged engine







Figure 114—Naturally-aspirated and turbocharged engines matched to same hull with same maximum engine speed






M & W turbo kit mounted crosswise on a four-cylinder 181 CID Chris Craft engine.



M & W turbo kit on six-cylinder Mercruiser (Chevrolet engine).

Experimental M & W installation on 351 CID Ford.



requirement curve at the same engine speed. This is done by using a higher-pitched propeller on the turbocharged engine. When the boat is slowed down to cruising speed, the turbocharged engine will be running slower than the naturally-aspirated engine, resulting in better fuel consumption and longer engine life. Where high boat speed is required, the turbocharged engine will drive the hull considerably faster than the naturally-aspirated engine without resorting to a higher maximum engine speed.


This has been demonstrated many times in long ocean races where the turbocharged engines running at somewhere around 4500 RPM were able to outlast the naturally-aspirated engines which had to run up to 7000 RPM to achieve the same power. A few years ago, turbocharged Daytona Engines so dominated the ocean racing scene that turbochargers were banned as being unfair. More recently, they have been reinstated but the turbocharged engine must take a penalty in cubic inch displacement.

The Pacific Offshore Powerboat Racing Association has six classes for engine sizes as follows (as of 1975):

| Class | CID Naturally Aspirated | CID Turbo |
|-------|----------------------------|--------------|
| 1 | 0 - 300 | None |
| 11 | 300 - 400 | 0 - 300 |
| III | 400 - 600 | 300 - 400 |
| IV | 600 - 800 | 400 - 600 |
| V | 800 - 1000 | 600 - 800 |
| VI | | 800 - 1000 |


This seems fair enough and should stir up some good competition between the old bore and stroke school and the newer "Push more air into it" practice.

Because of the difference in torque requirements, matching a turbocharger to a marine engine is somewhat different than on an automobile engine. Instead of trying to get a broad torque curve, the turbocharger is sized to obtain maximum compressor efficiency at maximum engine speed and the turbine housing sized accordingly. Except on rare occasions where the hull requirement has a hump in it, supercharging will only be required at high speed. When this occurs, Figure 115, the turbocharger must be sized to allow the engine to produce enough power to accelerate the hull through the hump. The turbocharged engine in Figure 115 Curve



Ford 460 CID boat engine turbocharged by Gale Banks is used as a drop-in powerplant by many V-drive and jet-boat manufacturers.

Gale Banks turbo kit for 454 Chevrolet boat engine includes everything that's required, including water-cooled exhaust elbows. Boost is adjustable from 5–15 psi by use of two IMPCO controllers.



1, has plenty of power at the top end but it will never be used because the hull will never reach planing speed. Curve 2 shows the turbocharger matched to give a little more power at the low end to get the hull over the hump. If this becomes critical and maximum speed is most important, it may be necessary to employ a wastegate to permit the use of a smaller turbine housing for more boost at low speed with-

out overboosting at maximum speed.

Tom Scahill has solved this problem in a different manner. He has modified an automatic transmission and placed it between the engine and Vee drive. The torque converter has been replaced with a solid coupling and he only uses two forward speeds and reverse. Tom says, "A lot of heads turn when they hear me shift!"

Figures 116 and 117 are compressor maps with power curves superimposed to show how the different requirements of automobile and marine engines are met.

In the case of the automobile engine, the high-speed end of the power line extends into the lower efficiency region of the compressor. This allows the engine to produce higher torque at mid-range. On the marine engine, the high-speed end goes through the center of the highest efficiency island of a larger compressor because there is rarely any high-torque requirement at mid-range. Starting with the same engine size and the same maximum speed, the marine-engine application will normally use a larger compressor than the automobile engine.

On a racing boat with dry exhaust manifolds, the correct turbine-housing size can be predicted without difficulty because the exhaust energy available will be similar to an automobile engine. This is not true of a pleasure boat with a watercooled exhaust system. To begin with, the water jacket around the exhaust manifold will reduce the exhaust-gas temperature at least 200°F., thereby reducing the volume flow available to the turbine. These engines usually have a water trap after the turbine to prevent sea water from backing into the turbocharger when the engine is not running. This causes back pressure on the turbine. In addition, engine-cooling water dumped into the exhaust pipe after the trap adds still more back pressure to the turbine. To compensate for this, a smaller turbine housing is used, depending on the conditions encountered for the particular installation.

Because of the availability of water, intercooling is very practical on marine engines. In some cases, engines have been set up to run turbocharged on regular-grade gasoline. This might appear silly at first but premium gas is not always available at marinas. Intercooling, discussed in Chapter 10, reduces the octane requirement of a turbocharged engine and with 70° to 80°F, water available, intercooler size is small enough not to increase the overall envelope of the engine.

Now that Tom Scahill has made intercoolers available to whomever wants to buy them, they should become less of a curiosity and more of a useful tool in getting the most out of an engine. Inter-




Figure 116—Full-power curve of turbocharged automobile engine showing compressor requirement

coolers, however, are not without problems of their own, particularly on a marine engine. One of the largest uses of turbocharged marine engines in the past has been sport-fishing boats. The fellows who own these boats like to get out to the fishing grounds fast, do their fishing at leisure, and get back home fast. The out and back are no problem but it is the leisurely fishing which gives the trouble. Suppose the engine is idled down to trolling speed for a half hour or so where the

manifold vacuum will be very high and obviously no supercharging takes place. The air-fuel mixture will already be quite cool when it reaches the intercooler, which in turn will cool it still further with nice 70° or 80° F, water. This will cause some fuel condensation in the intake manifold and after a while, a puddle of fuel will actually collect underneath the heat exchanger.

All of a sudden, one of the fishermen gets a strike and hollers for full power






Figure 117—Full-power curve of turbocharged marine engine showing compressor requirement

but when the engine throttles are opened, all it does is die on the vine. This can be very annoying, particularly if you lose a big fish as a result. Ted Naftzger had this problem and solved it by making two changes in the installation. First, he added a water jacket to the bottom of the carburetor box and allowed engine jacket water to warm the carburetor much the same as is done on an automobile engine. In addition, he added a bypass valve around the inter-cooler so during the

long periods of idling, he could shut off the water and prevent fuel from condensing in the intake manifold. Ted used a manual valve in his installation but it would be possible to have it diaphragmoperated which would allow water to flow through the heat exchanger only when the manifold pressure was above ambient.

Water-heated carburetor adapters are now available from Ak Miller, Tom Scahill and Accel.





Single Rajay turbo is used to add HP to this 180 CID Chevrolet four-cylinder engine in a Mercury outdrive installation. Intake duct from carburetor to the turbo is much larger than necessary.




Figure 118-Exploded view of M & W Mt-5 turbocharger kit for Mercrusier 165

M & W Gear Company has been making bolt-on turbocharger kits for farm tractors since 1962. There's no doubt they make good ones because they have sold around 50,000. In 1974, they entered the marine field with bolt-on kits for four- and six-cylinder Chevrolet engines. Figure 118 is an exploded view of their kit for the Mercruiser 165 Engine. The basic engine is a Chevrolet. It is obvious from this illustration and accompanying photos that Jack Bradford, their chief engineer, has done a thorough job on this as on their high-quality diesel kits.

Because these kits do not contain heat exchangers, they are for a 20% to 25% increase in power and are not designed for racing. They are honest-to-goodness do-it-yourself bolt-on units.


M & W has additional kits for the small-block Ford and Chevrolet V8's.

The turbocharger division of Accelformerly Turbonics—offers both partial and complete turbocharger kits for marine engines utilizing the priority-valve discussed in Chapter 9 on Controls.

Gale Banks has been making custom installations on marine engines with excellent results. His big problem is obtaining jet drives strong enough to absorb the power he gets from the engine. He has had no problem producing 850 HP from a big-block Chevy at 4500 RPM.

A few years ago, David Inall of Australia tried turbocharging a ski boat for a friend but the hull was a bit small and became airborne when the throttle was opened. He put the engine in a larger hull and proceeded to tear up the Vee drive. He has been able to obtain fantastic outputs from the big-block Chevies and has been specializing in one-off installations at Teterin Engineering.

It won't be long before turbocharged marine engines become common in closed-course and drag racing as well as the off-shore type. Skip Cooley has been building up some Allison V1710 Engines for unlimited hydroplane racing and gets about 4000 HP at 4000 RPM. This probably does not stress the engine any more than the gear-driven supercharged models with considerably less useful output. The blocked-off supercharger housing can be seen on the accompanying photographs.




Race-Aero conversion of 454 CID big-block Chevrolet with an 850 CFM Holley carburetor and intercooler produces about 700 HP on gasoline. This type installation is popular with off-shore boat racers.







Tom Scahill installation on a 454 CID Chevrolet includes his own aftercooling equipment which he sells to other marine enthusiasts. Kits include carburetor box, intercooler, Rajay turbochargers and AiResearch waste gate.




Don Markland installed this M & W kit on his 302 CID Ford and had to buy a new speedo for his boat because the old one only went to 50 MPH.




John DeMaio of Stonybrook, Long Island decided his 36 foot Bertram Off-shore Cruiser didn't have enough go. So he turboed the two 350 CID Chevys with 375F Rajays and his boat runs 60 MPH at 5500 RPM and 12 psi boost.





Performance First Marine converted 460 CID Ford for jet ski boat use. Two Rajay 370E10 turbochargers provide 7 psi boost. Air box on intake manifold is a water-cooled fabricated-aluminum unit. 780 CFM Holley with an electric choke is mounted on a heated box supplied with water from the water-cooled exhaust elbows. Water-cooled exhaust system features 4-inch wet pipes to provide quiet operation and avoid burning ski ropes.



18-foot jet ski boat is Performance First Marine's test bed. Stock 455 CID Oldsmobile engine and a stock jet pump provide baseline references for Rick Mack's turbo testing.

12 TWO-STROKE ENGINES




Figure 119-Simple two-stroke-cycle engine

When discussing the hows and whys of turbocharging, we normally think of the standard passenger-car engine, racing engine, marine engine or even an aircraft engine but two-stroke engines cannot be ignored because they are used in motorcycles, snowmobiles, all-terrain vehicles, boats and recently even in airplanes. Two-stroke engines can and have been successfully turbocharged although the conditions are quite different than on a four-stroke engine. Therefore, many of the problems

have to be attacked in a different way. Except for the Wankel Engine, all four-stroke engines are about the same when it comes to valve location and combustion-chamber shape. Two-stroke engines are manufactured with many different types of porting and scavenging. These various methods must be treated differently when it comes to turbocharging.

Figure 119 shows the simplest of the two-stroke engines, often referred to as a *cross-flow crankcase-scavenged* type

because the fresh charge enters one side of the cylinder from the crankcase while the exhaust leaves the other.

In Figure 119A the engine has just started its power stroke and both the inlet and exhaust ports are covered by the piston. The crankcase port is open. In Figure 119B the engine has completed its power stroke and the exhaust port which is slightly higher than the inlet port has allowed cylinder pressure to drop to atmospheric. When the inlet port becomes




Figure 120-Simple two-stroke engine with a turbocharger

uncovered, the pressure in the sealed crankcase forces the air-fuel mixture into the cylinder. The crankcase port is covered, preventing the charge from escaping back to the carburetor. In Figure 119C the piston is near the end of its compression stroke. The crankcase port has just been uncovered and the partial vacuum in the crankcase causes air-fuel mixture to be drawn into the crankcase through the crankcase port.

The haffle on the top of the piston

prevents most of the charge from being blown out through the exhaust port.

Many variations of this design include reed or flapper-type check valves on the crankcase instead of the crankcase port. Another variation is to have the crankcase port mated to a rotary valve in or on the crankshaft.

None of these variations has much effect on the problems associated with turbocharging this type of engine, Figure 120. The main problem is the exhaust port which opens before the inlet port, closes after it. This means supercharge pressure will be determined by the back pressure from the turbine and it is possible for some burned exhaust gases to re-enter the cylinder after the inlet port has closed.

Both of these problems can have a substantial effect on the volumetric efficiency of the engine and actual results are often quite different than those calculated.




Figure 121-Loop-scavenged two-stroke-cycle engine





Figure 122-Uniflow-scavenged two-stroke-cycle engine





A similar type two-stroke engine is the loop-scavenged type, Figure 121. In this engine, both ports are on the same side of the cylinder and no baffle is required on the top of the piston. It still has the problem of the exhaust port closing after the inlet port.

Figure 122 is a schematic of a uniflow-scavenged engine. Here the exhaust port is replaced by a poppet valve of the same type used on four-stroke engines. This valve is opened and closed by a camshaft and can be timed to open before the intake port and close before it. This prevents the air-fuel mixture from being blown out through the exhaust port or exhaust gas from re-entering the cylinder. There are many other types including opposed-piston engines but the three described here will cover most cases.

It is not necessary to use the crankcase for a scavenge pump but on small engines it is convenient and inexpensive. Using the crankcase for this purpose means that a separate crankcase must be provided for each cylinder except where two cylinders are 180° apart and can fire at the same time. The efficiency of the crankcase as a scavenge pump is an inverse function of the volume of the crankcase when the piston is at bottom center. This means the smaller the crankcase volume, the better it will be as a scavenge pump. One of the problems with this design is the air-fuel mixture must lubricate the connecting-rod and crankshaft bearings. Because gasoline is not a very good lubricant, it is necessary to add oil to the mixture. This is fine except that oil has a detrimental effect on the octane rating of the fuel. If oil causes a problem normally aspirated, it is twice as bad turbocharged where octane rating is critical.

One way around the problem is to use mist lubrication in the crankcase, fuel injection, and hope the oil vapor is not carried into the cylinder with the air charge. A more positive answer is not to use crankcase scavenging. On large two-stroke engines it can be accomplished by driving the turbocharger mechanically until the engine develops enough energy to self-sustain. This method is not practical on small engines so a scavenge pump must be provided. Going back to Chapter 1, several types of mechanically driven compressors are discussed. All of these have been used at one time or another




Figure 124-Two-stroke engine with turbocharger added to scavenge pump

for scavenging two-stroke engines, Figure 123. In addition, the re-entry compressor sometimes referred to as a drag pump, has also been used for this purpose.

Right away the question arises, "If I have a high-pressure mechanically-driven scavenge pump, why can't it be used to supercharge my engine?" Except in the uniflow engine, much of the charge will blow right out the exhaust port and no supercharging will take place. If a turbo-charger is added to the system, back pressure caused by the turbine will retain most of the high-pressure charge in the combustion chamber. When such a setup is used, the turbocharger compressor discharge is usually fed directly into the

scavenge-pump inlet, Figure 124.

Remember when calculating throughflow for compressor matching, the twostroke engine has a power stroke every revolution and uses twice as much air as a four-stroke engine of the same displacement at the same speed. Another thing to remember is most two-stroke engines have no oil pump and therefore a separate lubrication system—oil pump, reservoir, filter and cooler—must be provided when a turbo is installed.

Two-stroke engines have been supercharged successfully to produce more than twice their normally-aspirated output and the potential should be as high as for a four-stroke engine.

13 HIGH-ALTITUDE TURBOCHARCING



Piper Seneca is a light twin. This version has Rajay aftermarket kits on Lycoming Engines. Factory-turbocharged Continental engines on later versions are also Rajay turbocharged.

Turbocharging aircraft engines is a very specialized science, not only because of the unique problems involved but also from a safety viewpoint. A turbocharger or engine failure in a ground vehicle can be annoying but usually is not catastrophic. Because such a failure in an airplane, particularly a single-engine airplane, will normally cause the airplane to come down, every effort is made by the Federal Aviation Authority to be sure the turbocharger-engine system is not overstressed and any controls which might be used are fail-safe. Fail-safe in this case means they will not

cause the turbocharger to overspeed and destroy itself or the engine.

Because of these very special requirements, I don't recommend airplane owners try to turbocharge their own engines. Certified kits are available for most of the popular light planes and if one is not available for a certain airplane, it will probably be less expensive to trade the plane in on one which does have a kit available, rather than going through the routine of getting a supplementary type certificate from the FAA. For someone who does not have previous test information to fall

back on, the cost of building a dynamometer cell with high-altitude capabilities and running the tests will probably run upwards of \$250,000. If this is not a deterrent, go to it.

Turbochargers used on aircraft installations may look identical to those used on farm tractors or automobiles but the quality control of raw material and machining operations are quite different. Manufacturers must be able to prove that the correct materials were used, any heat treatment was done under controlled conditions and the machining operations checked with regularly calibrated measuring instruments. Besides this, special operations such as Zyglo or Magniflux must be performed on all critical parts. These are the reasons why aircraft turbochargers are so much more expensive than industrial units. This is also why repair and overhaul of aircraft turbochargers should only be done by licensed mechanics using parts from authorized manufacturers.

After this discouraging introduction, the reader might wonder why I include a chapter on high-altitude turbocharging. The reason is many engines must be operated at relatively high altitudes although they never leave the ground. Turbocharged engines have done very well in the past in the Pike's Peak Hill Climb and marine engines operating on Lake Tahoe, for instance, suffer a considerable loss of horsepower unless turbocharged.

This chapter is intended to cover regaining horsepower for engines which operate only at high altitude, maintaining horsepower on engines which operate from sea level to high altitude and the problems associated with an engine already turbocharged at sea level when it is operated at high altitude.

A naturally-aspirated engine will produce power in direct proportion to the density of the intake air. At sea level, air has a density of .0765 lb./ft.³ At 10,000 feet altitude, the density drops to 0.0565 lb./ft.³

This means an engine which delivered 100 HP at sea level will deliver

$$100 \text{ x} = \frac{.0565}{.0765} = 73.9 \text{ HP}$$

at 10,000 feet.

Airplane engines equipped with turbochargers to regain power loss due to altitude are referred to as "normalized" engines. A normalized engine usually will have a wastegate valve to pass all of the exhaust gas at sea level so no turbocharging will take place, Figure 125. As the engine starts to lose power at altitude, the wastegate is gradually closed, either manually or by an automatic control, and the turbocharger compresses the inlet air to sea-level pressure. This allows the engine to deliver essentially sea-level horsepower up to an altitude where the wastegate is completely closed and all the exhaust gases pass through the turbine.





Figure 125-Schematic of aircraft engine with simple waste-gated turbocharger system


Piper Apache uses single Rajay turbocharger on each Avco-Lycoming 0-360 engine to maintain sea-level power at altitude.






Avco-Lycoming TIGO-541. Geared 541 CID aircraft engine produces 425 HP with single AiResearch turbocharger.







Rajay Installation on a Piper Aztec C. Lube oil is scavenged from the turbochargers by an engine-driven gerotor pump.

When the airplane continues to climb above this altitude (critical altitude), the engine will start to lose power because the turbocharger can no longer deliver air at sea-level pressure. This critical altitude will vary with the engine and the turbocharger used. It is easy to attain a critical altitude of 15,000 feet and turbocharged engines with correct intercooling have been able to deliver sea-level naturally aspirated power at 40,000 feet.

If a vehicle is to be used only at a certain altitude, and sea-level power is to be maintained, then the turbocharger should be matched to deliver 30 inches Abs. If the engine must operate over a broad range of speed maintaining 30 inches intake-manifold pressure, then a boost control should be used, see Chapter 9. If the engine is to be operated at several different altitudes, an aneroid-type control should be used to prevent overboosting at lower altitudes. These are special cases where no more than sea-level naturally-aspirated power is desired.

In most cases, it is desired to supercharge the engine at sea level with as little loss as possible at high altitude. To accomplish this, several different approaches may be taken depending on the importance of maintaining full power at altitude.

Figure 126 shows how naturally-aspirated engine output is reduced as the altitude is increased. The output is a function of air density and decreases directly with it. If an engine is turbocharged at sea level with a free-floating turbocharger, it will also lose power as altitude is increasedbut not so fast as a naturally aspirated engine, Figure 127. At wide-open throttle, the intake-manifold gage pressure will remain almost constant regardless of altitude. As an example, if the engine is turbocharged to 10 lbs, gage pressure at sea level, it will still be turbocharged at 10 lbs. gage at 10,000 ft, altitude. The ambient air pressure, however, will have been reduced from 14.7 lb./in.2 to 10.15 lb./in.2 At sea level, the absolute intake pressure was 24.7 lb./in.2 while at 10,000 ft. altitude it is only 20.15 lb./in.2 The naturallyaspirated engine will put out only 73% of sea-level power at 10,000 feet while the free-floating turbocharged engine will





Figure 126-Naturally-aspirated engine output at various altitudes

Figure 127—Free-floating turbocharged-engine output at various altitudes







Figure 128—Comparison of naturally aspirated and free-floating turbocharged engine output at various altitudes



Jacobs 757 CID engine is rated at 350 HP for take-off with only 2 psi boost, provides sea-level cruise 275 HP performance at 19,500 feet altitude. Single AiResearch turbo is used.

be producing

$$\frac{20.15}{24.7} = 81.5\%$$

of sea-level power, see Figure 128.

Because of the ability of a free-floating turbocharged engine to compensate for at least part of the power loss due to altitude. a turbocharged engine with the same sealevel power as a naturally-aspirated engine will perform substantially better at altitude. Figure 128 shows the comparative performance of a naturally-aspirated engine and a free-floating turbocharged engine. If both of these engines are rated at 100 HP at sea level, the turbocharged engine will deliver horsepower at 10,000 feet 9.5% better than the naturally-aspirated engine. As a rule of thumb, the turbo speed will increase approximately 2% per 1,000 feet of altitude.

There may be applications where no loss of output can be tolerated and the free-floating turbocharger is not acceptable in the manner shown above. If the engine is to be used strictly at a given altitude, the turbine housing may be replaced by one with a smaller A/R to increase the rotor speed and boost pressure. I don't

know of an exact method of determining the new A/R to retain sea level performance, so the trial-and-error method is useful until the user has established enough "feel" to predict the exact size in advance.

Depending on the engine and the amount of supercharge at sea level, the engine should be able to produce sealevel power up to at least 16,000-ft. altitude even if the boost pressure is 15 psig at sea level. In this case, at sea level, the compressor will be producing 2:1 pressure ratio and the intake manifold pressure will be 30 psia. To maintain this manifold pressure at 16,000-ft. altitude where the ambient pressure is 7.95 psia, the compressor must put out 3.78 pressure ratio which does not seem possible with a compressor such as shown on Figure 117, This map, however, is based on 60°F, and the average ambient temperature at 16,000 feet is about 0°F. Centrifugal compressors produce pressure ratio at a lower speed as the inlet temperature goes down in the ratio of

Standard temperature Abs
Inlet temperature Abs

which in this instance is


$$=\sqrt{\frac{520}{460}}$$

= 1.06

Figure 117 indicates a turbocharger speed of about 125,000 RPM to produce this pressure ratio but at 0°F, the actual speed will be only


$$\frac{125,000}{1,06}$$
 = 117,900 RPM, Approximately

which is still possible to achieve without overspeeding the turbocharger. There may be other problems which will occur at this altitude to prevent the engine from delivering sea-level power. The small turbine housing size required to produce the necessary pressure ratio may cause excessive pressure which might reduce the output of the engine even though intakemanifold pressure is available. The high intake-manifold air temperature may cause detonation and valve burning. The higher combustion temperatures and pressures may cause a general deterioration of the engine. This is a nice way of saying the engine may come apart at the seams.



Franklin six-cylinder aircraft engine with a single AiResearch TEO6 turbo. As is typical in aircraft installations, carburetor is pressurized by turbo to maintain near sea-level pressure. Altitude-sensitive controller allows turbo boost to keep engine at near sea-level power output. Pilot adjusts mixture for desired exhaust-gas temperature.

Figure 129-Altitude performance of waste-gated turbocharged engine



Some engines must be operated at several altitudes and still be capable of turning out sea-level power. It is neither convenient nor practical to change the turbine housing each time the engine is moved to a different altitude. The problem can be solved the same as on an airplane by using a turbine housing small enough for high altitudes and opening a wastegate to prevent overboosting at low altitudes. This type control may be operated either manually or by a servo motor and is covered in Chapter 9 on Controls.

When an engine is equipped with a wastegate, either manually or automatically operated, it is possible to maintain sea-level output up to some altitude where the wastegate is completely closed. Above this altitude, the engine will act the same as the free-floating turbocharged engine. Figure 129 shows engine output in percent of sea-level rating vs. altitude for an engine where the wastegate is fully closed at 15,000 feet. Assuming this engine is supercharged to 10 lbs. boost at sea level, the absolute intake manifold pressure is 25 psi. To maintain this at 15,000 feet where the ambient pressure is 8.3 psi, it will be necessary to increase boost to 25 - 8.3 = 16.7 psig. Above this altitude, the boost pressure will remain the same since the wastegate is fully closed and at 20,000 feet the absolute intake-manifold pressure will be 6.75 + 16.70 = 23.45 psia. This will reduce the engine output to


$$\frac{23.45}{25}$$
 = .94

or 94% of sea-level power. Here, as in the case of the free-floating turbocharger, the engine will have other limits which will determine the maximum altitude at which it can be operated.

The altitude at which the engine will no longer produce 100% of sea-level power is called the critical altitude of the engine.

An engine can be turbocharged to produce maximum sea-level output at high altitude, limited only by the mechanical integrity of the engine.

The critical altitude of a turbocharged engine which is already super-charged at sea-level will be lower than one which is naturally aspirated at sea-level and turbocharged only to maintain this output.




Helio Super Courier uses two Rajay turbos on an Avco-Lycoming GO-480 engine.

Turbocharging at high altitude can benefit greatly by the use of an intercooler and the higher the altitude the more the benefit, A turbocharged engine with 10 lbs. boost at sea-level will have an intake-manifold temperature of about 175°F. If this same engine is to produce about the same power at 15,000 feet, the boost pressure will have to increase to 16.7 lbs, and the pressure ratio will increase from 1.67 to 3.00. This pressure ratio will result in an intake-manifold temperature of 246°F. unless an intercooler is used. Because the standard temperature at 15,000 feet is 5.5°F., an intercooler with only 50% effectiveness will reduce the intake manifold temperature to 126°F.

Airplanes are frequently operated with a manually-controlled wastegate or with a manually-controlled throttle to limit the intake-manifold pressure because an airplane engine essentially is operated as a steady-state application. It would not be practical to put a manually-controlled wastegate on a vehicle which must be driven up and down hills at various power settings and altitudes.


To summarize, a naturally-aspirated engine to be operated only at a specific high altitude, can be turbocharged without the use of a control, just as at sea-level. An engine turbocharged at sea-level can be operated between sea-level and some high altitude without a control if some loss in horsepower can be tolerated at the higher altitude. The percentage loss of power at altitude will be less than if the engine were naturally aspirated. An engine which is either naturally aspirated or turbocharged at sea-level and is to be operated at many different altitudes where maximum horsepower must be maintained requires the use of a controlusually an aneroid-operated wastegate.

Schematic of Rajay dual-turbo aircraft installation on Turbo Islander.



Schematic of Rajay aircraft installation on Mooney Turbo 21 with single turbocharger.

14 Installation do's, don'ts & maybe's




Anyone who needs lessons on making sanitary turbo installations should study this Renault in a Lotus Europa by Rick Mack.

Each of the chapters of this book covers certain points relating to the installation of turbochargers but it seemed like a good idea to put answers to the most often asked questions in one chapter, making it easier for the reader to have a ready reference. Many more people are involved in turbocharging now than a few years ago and I have requested several of those who have had considerable experience to pass this information along so that a new enthusiast will not lose his enthusiasm by making too many mistakes

before his first turbocharged automobile is completed.

People who have been successful in this field such as Doug Roe, Paul Uitti, Chuck McInerney, Don Hubbard, George Spears, Gale Banks, Chuck Sarson, Bob Keller and Ted Trevor have been kind enough to pass along information which, if used correctly, will save many hours and heartbreaks. I have included hints from many other experts as well, but the above-mentioned have given me written suggestions for this purpose.

If the reader has any specific problems such as inter-cooling or lubrication, the proper chapter should be referred to and reread if necessary to refresh his memory. When I work on a particular item such as a carburetor, I have found it to be extremely helpful to have a book describing that particular carburetor opened to the page covering the item on which I am working. The items covered in this chapter are based on the experiences of these experts and may, in some cases, tend to contradict each other. This is natural



Ak Miller uses jacket water to heat long crossover pipe on 2-liter Pinto installation. Special exhaust manifold mounts turbocharger.

because things which are good for one engine are not necessarily good for another. This is particularly true in the case of an air-cooled versus a liquid-cooled engine or an in-line engine versus a V or opposed engine.

To begin with, some basic suggestions from Doug Roe. "If it's necessary to buy a used turbo, follow a few suggestions or that \$25 to \$100 investment may cost you the entire effort.

Shop around to find a turbo for your engine that was designed for one of similar displacement and use. There is some latitude but too big a turbo dampens power response, while one too small may be short-lived and restrict mid-range and topend performance. Keep in mind that automotive-type units turn approximately 80,000 RPM during high output. Using too small a turbo will cause it to exceed these revs and failure may result.

Before making a purchase, inspect the unit carefully. With the carburetor and

exhaust removed, you can reach the impeller and turbine with your finger or a pencil eraser. With mild effort, try to turn them from either end. They are joined by a common shaft so both should turn together. If each side turns independently there are internal problems. Do not put any hard object such as a screw driver against either impeller or turbine to try to turn it. One scratch or nick can cause failure at high revs. For this reason, never scrape carbon off. Use a carbon-dissolving solvent that does not attack aluminum because most impellers are made of that metal. I use carburetor cleaner, Many high-mileage turbos are heavily encrusted with carbon and will not turn as described above. This means a disassembly must be made to remove the carbon. Parts are very costly so at this point, add up the possible costs. A Corvair exhaust turbine is over \$75.00—the compressor impeller on the boost side is over \$20.00. A gasket, bearing and seal-overhaul kit is over \$40.00. The latter two items will usually be needed. If you are out to learn and decide to do the overhaul yourself, get a manual. Turbos are precision made and some caution must be exercised in working on them, but they are not complicated.

A used turbo relatively free of carbon will turn with mild effort. The exhaust seal affords a little drag so do not expect them to free wheel. Hopefully you can find one that appears good.

Now that you have a new or good used unit, it is time to plan the installation. Holding the turbo by hand, try it in various positions and you will soon narrow down the place for it by logic. Keep in mind the following:

- 1. Hood or body clearance
- 2. Routing of the exhaust to the unit
- 3. Routing of the exhaust from the unit
- Plumbing of the compressor outlet to the carburetor or manifold depending on type chosen, and plumbing of oilpressure and oil-drain lines

Item No. 4 requires further explanation. The only critical part of the entire plumbing job is how you direct the charge of fuel and air from the turbo to the manifold on in-line and V8 engines or to the cross-over pipe on opposed engines such as Corvair and VW types.

- A. It is best to have the turbo slightly higher than the manifold or cross-over tube. This rule can be broken without big losses of power if need be.
- B. Regardless of where the turbo is mounted, never plumb to the manifold or cross-over pipe so the charge is directed in on an angle.

The same applies when plumbing to a manifold setup on in-line or V8 engines. You must provide a means of shooting the fuel/air straight in so it is directed evenly to all cylinders.

When aimed wrong, Figure 130-1, heavy fuel particles will tend to continue along the easiest path and in this case richen the right-side cylinders. Because air is lighter, it can change direction faster, so it will make the sharp turn to the left and cause those cylinders to run lean.

In short, straighten the path of the fuelair and let the cylinders have an equal chance at it.

A study of any turbo installation will reveal an exhaust pipe from all cylinders plumbed to the turbo. Plan your exhaust




Figure 130-Intake-manifold plumbing for turbocharged opposed engines

to be as short as possible without causing tight bends. Use good sized pipe for your assurance of free flow."

Doug suggests wrapping the exhaust pipe with insulating material to keep from losing any heat in the exhaust system and also to lower the temperature of the engine compartment. This is considered standard practice for racing application where fractions of a second mean the difference between winning or losing. On street applications, the installation may cause more trouble than it cures, George Spears suggests the following: "In regard to the controversial subject of wrapping the hot pipe, we have experimented both on the V6 Capri and the V6 Mustang, and found very little or no gain in wrapping the piping. What we have found is a tremendous deterioration of the piping material beneath the wrapping. It rapidly oxidizes and, in some cases, we have found that the bends will distort, the crossover pipe warps and when removed, it cannot be refitted. In our opinion, for most automotive applications, wrapping is unnecessary, costly, seriously affects exhaust pipe life, and generally is not attractive appearance-wise." In both cases, George was referring to a V6 engine which like any V or opposed engine is particularly hard on the cross-over pipe. The engine itself is water-cooled and will not get much over 220°F. Therefore, the distance between the exhaust ports on the two banks will not vary much. The cross-over pipe, on the other hand, which joins these two sets of exhaust ports may reach a temperature of 1400 or 1500°F. At this temperature, it will want to grow about

1/3 inch more if made from 300 series stainless steel. When this occurs, something has to give and because the engine block is usually far stronger than the cross-over pipe, the cross-over pipe will give. When Rajay first produced their Volkswagen Turbocharger Kit, the pipe which joined the four exhaust ports to the turbine inlet was wrapped with a very efficient heat blanket. A few months later, one of these pipes was returned as being defective when several pieces flaked out of the corners nearest the exhaust ports. This was thought to be a piece of bad tubing until several more headers were returned with the same problem. The kit was redesigned and the header was chromeplated rather than insulated. No appreciable performance difference could be measured between the two types and the chrome-plated exhaust headers had a much better appearance.

Don Hubbard has this to say on the subject. "Some people say that the turbo is operated by the waste exhaust heat of the engine and they are tempted to insulate the exhaust tubes between the engine and the turbo to get more heat to the turbo. This usually causes overheating of the exhaust tubing and then premature failure. The exhaust gases actually have a velocity and pressure along with the heat that drives the turbo. Usually, the insulation used around the exhaust system is to keep radiant heat off the other engine parts. In some Indy Cars, insulation has been used to keep the high-speed air stream from cooling the tubes excessively because the state of tune of the engine requires every little bit from the turbo for response and


power and the balance is critical.

Connections between the compressor outlet and the intake manifold should not be overlooked because a leak at this location will not only cause a loss of power and rough idling but can be a fire hazard as well on those engines where the turbocharger is mounted between the carburetor and the engine."


Doug Roe suggests the following: "When connecting the turbo and your newly fabricated intake stack or cross-over pipe, use a good grade, fuel-proof hose and clamps. If a modest bend is required, use wire-lined flex hose with a relatively smooth interior. Hopefully, the pipe size in your intake system has been kept similar to the outlet size of the compressor so as to get best connection with least irregularity."

George Spears has found that the red or green silicone hose works very well for the connection between the compressor discharge and whatever piping may be used. Conventional radiator hose is quickly attacked by gasoline. He has found the silicone hose manufactured by Flexaust or Flex-u-sil to be excellent. Paul Uitti has had good results with that manufactured by Arrowhead.

When firing up a newly rebuilt engine with a turbocharger, it is not necessary to take any more lubrication precautions than those taken on a naturally-aspirated engine. Because the turbocharger barely rotates at engine idle, oil used to lubricate the turbocharger bearing during assembly will be adequate until the oil passages of the engine become filled. Because there is always the possibility of hooking up the



Top photo shows defunct Car Corporation's first installation on a 1600cc Pinto. Note similarity to David Inall's installation on Ford 1600cc in Australia. Lower photo shows Rajay 375B turbocharger and SU carburetor.




oil lines incorrectly, it is a good idea to disconnect the oil-drain line from the turbocharger and observe oil flowing from the turbocharger drain after the engine has started. This should occur within 30 seconds after the engine has started if the correct oil viscosity and line sizes are used.

Doug Roe has some advice about the Corvair which might help prevent a turbo-charger failure. "Hook up the oil-pressure line from the engine block to the turbo. This should be 1/4-inch steel tubing or a good flexible pressure line with equivalent oil-flow capacity and capable of handling hot oil.


As a precaution to possible turbo-bearing damage, oil should be pumped through the turbo before firing the engine. This can be accomplished by turning the oil pump with an electric drill and light engine oil. On the Corvair I used a distributor with its drive gear removed. Determine how your system functions and devise a way. Turning the oil pump without running the engine also guarantees immediate oil pressure when you fire a newly-built engine. This is a very good practice. Run your oil system long enough to observe a good flow of oil out the drain hose. This will be a small steady stream with low pressure and room-temperature oil. When the oil gets hot and has full engine oil pressure against it, the drain will flow a larger amount of oil. Now you should double check everything and run the engine for leak checks."

Clive Waye's VW engine in 8 ft. wheelbase drag bike is shown here in turbocharged form with 2-inch SU carburetor. Engine has 1287cc displacement with 8:1 compression ratio. Photo made in 1968. VW engine conversions for racing are thoroughly covered in another H. P. Book: How to Hotrod VW Engines.






1963 150 HP Corvair Spyder engine on dynamometer, GM Technical Center, Warren, Michigan. Installation was automatically programmed to run the engine at full load over varying speeds for component life testing.



Impressive "hardware collection" shows part of the trophies won by Doug Roe with his turbocharged Corvair. In lower photo, he displays two turbos he has used in his competition engines. Bracket on AiResearch turbo supports weight of a four-barrel Holley carb. Engine is shown equipped with a stock Corvair Rajay (TRW) turbo and Carter YH side draft carburetor. Until 1972, Doug Roe was a carburetor and emissions engineer with one of the major auto manufacturers. He is now an automotive consultant handling special development projects and vehicle testing in Phoenix, Arizona.



When Ford decided to turbocharge a V-6 Capri they built the compressor housing into the intake manifold. Turbocharger was specially built by AiResearch.

Don Hubbard as well as the others knows the importance of the turbocharger oil drain. He suggests the following: "The turbo needs a good direct drain to the engine. The drain tube should remain full size-approximately 3/4 to one inch inside diameter-to the engine. If the drain goes to the oil sump, it should never be covered with oil. It should terminate in a position above the oil level and be protected from oil throw-off from the crankshaft and rods. The engine crankcase should be well vented to prevent high crankcase pressures due to blowby. Most oil-leakage problems in the turbo can be traced to poor oil drains. The drains should always slope down and have no low spot to trap oil in the drain tube."

This item is discussed in the lubrication chapter but no matter how often it is talked about, some people still seem to think that oil can be made to flow uphill.

People who have run turbocharged engines frequently say they get valve float at a lower RPM than they did on the same engine when it was naturally aspirated. Some attribute this to the supercharge pressure on the under side of the valve causing it to open but this force is insignificant compared to the spring closing force and Doug Roe offers a few reasons which seem more reasonable. "If stock valve springs at stock installation heights are used in a turbocharged engine, valve

float may occur at lower RPM than was the case with the naturally aspirated engine. The reasons for this are not completely clear, but can probably be attributed to the following possible causes:

- There is a tendency to use the full rev limit capabilities of a turbocharged engine. The exhilarating experience tends to generate driver enthusiasm which may not be accompanied by tach watching to insure the critical RPM is not exceeded.
- The valve springs in used engines may already be "tired out" and not giving specified seating pressure. Installing a turbo on such an engine—and then attempting to use full performance and RPM potential will often bring about valve float.

Continued use of high RPM weakens the valve springs in a hurry, requiring the use of stronger springs or a lesser installation height—either of which increases valve spring pressure so valve float does not occur prematurely.


If the springs are shimmed, it is important to observe the usual precautions to maintain adequate clearance between the spring coils with the valve at full lift. Also, be sure there is adequate clearance between the valve-spring retainer and the top of the valve guide at full lift.


An engine does not have to be very old to have 'tired springs' syndrone. If such an engine is turbocharged, consider changing the valve springs when the turbo is installed. Even a new engine, if it has been allowed to sit with the heads assembled, can have tired springs.

If excessive valve guide wear is encountered on a turbocharged engine—and this is not usually a problem—the guide bores can be knurled and then honed for correct fit. Bronzewall Guide rebuilding by the Winona Method can also be helpful as the aluminum bronze wire which is wound into the guides has more lubricity than guides made from Detroit Wonder Metal—cast iron.

Also, the valve-stem seals can be left off the exhaust valves/guides to insure that the exhaust valves get slightly more lubrication to offset any effects of higher exhaust gas temperature and increased back pressure.

On some engines, head-gasket problems may occur, especially as boosts get into the 13 to 15 psi region. If problems occur, they can be cured by '0-ringing' the cylinder head. This requires cutting a groove in the gasket surface of the head around the outside of each combustion chamber. Soft-copper wire is installed in the groove so a portion of the wire extends above the surface. This applies additional clamping





Rajay technician Dave Austin helped author MacInnes develop the Rajay VW turbo kit.

When you set out to build a kit for public use, a lot of parts have to be specially made to keep the job simple. Here is Rajay's VW kit assembled so you can see how the pieces fit.

pressure and a pressure seal which usually eliminates any tendency to blow gaskets.

Such problems are rare on air-cooled engines which spigot the cylinders into the heads. In these cases, gaskets are retained around their edges by the head design so there is little tendency for failure to occur, even at high boost pressures. VW and Porsche cylinders seal directly against the aluminum heads to provide a very effective seal if the cylinder lengths, spigot depths in the heads, and cylinder bases on the crankcase halves are correctly machined. Correct torque on the head bolts/nuts is essential and the usual practice of running the engine until it is well warmed up and retorquing after cooling is highly recommended.


Better quality exhaust valves are used by some builders when turbocharging. Turbocharged Corvairs, for instance, had Nimonic exhaust valves as standard parts. As valve diameter is increased and/or boost pressure is raised, the need for better quality exhaust valves increases.

It is very important to make sure that the turbo does not hit anything when the engine moves on its mounts or the chassis flexes during acceleration or braking or on rough roads, as in off road racing. Several turbo failures on a single car were finally traced to the fact that the turbo could hit a rollbar brace under certain circumstances, even though it appeared to have plenty of clearance with the engine and car at rest.


Remember that the turbo needs no expensive aftermarket type intake manifolds or exhaust headers. Eliminating these items alone can often offset the cost—even for a pair of turbochargers. Obviously, if you are intent on 'buzzing' the engine to higher RPM, it should be treated to a detailed blueprinting job."

George Spears suggests the following with respect to fabricating exhaust pieces: "We have experimented with various thicknesses of plate for the flame-cut flanges, and find 3/8 inch is a happy compromise. 1/4-inch has a tendency to warp during the fabrication and welding process, whereas 3/8 inch will not. In regard to tubing thickness, we have found that .083 inch, a standard gage tubing, is adequate and certainly anything thicker would be even better."

George has some other good suggestions when it comes to protecting engine components from hot exhaust pipes. "I think a question that could come up in some peoples' minds with regard to how close they can get the hot exhaust piping to heat-sensitive objects is one of the most frequently asked. Presently, we are operating our Mustang II Kit with a turbine discharge approximately 3/4 inch away from a 14-gauge metal heat shield. Electrical wiring is immediately behind this heat shield and in some cases, it is actually touching it. We have not experienced any problem with the wiring. We have placed thermocouples against the front side of the heat shield and generally can only measure about 200°F. Based on this experience, I think we can say that a 14-gauge steel shield placed one inch away from any of the hot metal parts, with at least one inch air space behind it, before any critical parts such as electrical wiring, master cylinders, etc. would give adequate protection from the heat. This might be useful information to an individual who has absolutely no idea of what the heat problems can be."



Diameters of these compressor inlets provide an excellent clue to the differences in their flow capacities. Left unit is original Corvair B-flow; at right is Corvair unit adapted for higher flow with E-flow kit by Crown. Three-inch-diameter inlet of E-flow requires an adapter to mount carburetor. Crown also has an E-flow kit with the three-bolt flange which can be used without an adapter. Kit was designed to fit 1965-66 Corvair F-flow with 1-3/8" venturi Carter carb, but also fits B-flow units used 1962-64 with 1-5/16" venturi Carter carb. Kits are available from Crown Manufacturing. 1962-64 Corvair turbos bear part numbers: 3817254, 3830651, 3831691 or 3840830. 1965-66 units have P/N 3856709. These numbers could be helpful if you are looking for a used one.



2-barrel downdraft Bendix/Stromberg WW carb on Dick Griffin Corvair. Similar adapters are available from Crown, EELCO and IECO. Crown also has adapters for the side-draft Weber, 500 CFM 2-barrel Holley and for 4-barrel Holley carbs.




Nick Trist of Hidden Hills, California had this GMC pickup modified for off-road use. It has six-wheel drive and air suspension all around. He had Ak Miller add propane and two turbochargers to give it passenger-car performance.



Because of space limitations it was necessary to mount both TO4's on one side.

Twin TO4 propane, IMPCO pressure limiters.



Lou Cruse's 350 CID El Camino with propane and Rajay 370E10.



15 TRACTOR PULLING



1975 National Tractor Pullers Association points champion in the 9,000-lb. class is this International 1066 driven by Danny Dean of South Charleston, Ohio. Photo courtesy National Tractor Pullers Association.

Tractor Pulling is becoming a spectator sport in the United States and Canada in spite of the fact that most people on the west coast have never heard of it. The National Tractor Pullers Association (NTPA) had more than a million persons at sanctioned meets during 1973 with total purses of over \$400,000. This increased to over \$600,000 in 1974.

Because some readers are probably saying, "What is a tractor-pulling chapter doing in a turbocharger book?" some explanation is necessary. Information

supplied by the NTPA states that the first recorded tractor pulls were in the year 1929 in Bowling Green, Missouri, and Monsville, Ohio. The tractor started out pulling a sled loaded with stones. As the sled was pulled along the course, a man climbed on it every 10 feet, so if he pulled the sled 100 feet he had the weight of the sled and stones plus the additional weight of the ten men. This continued until the tractor stalled, and in the early days, it was just that. As the the years went on, tractors became heavier

and more powerful so it was necessary to divide them into classes. At most tractor-pulling contests, there are two classes, modified and super-stock. A modified tractor has any combination of engines, transmissions and final drive. They must have rubber tires and only two-wheel drive. Super-stock tractors are farm tractors with a standard block and crankcase of the make and model being entered.

These two classes are further divided into weight divisions of 5,000, 7,000,

9,000, 12,000 and 15,000 pounds gross. Many other rules are pertinent to safety, such as SEMA-Approved Scatterblankets. Rules may be obtained from the National Tractor Pullers Association, 104 East Wyandot Street, Upper Sandusky, Ohio 43351.

Tractors in the modified class, as can be seen from the various photographs, are low-speed dragsters. Of the top 15 point winners in the 12,000-pound modified class in 1973, six of the tractors had Allison V-12 Engines, three had tank engines while the rest had an assortment of Ford, Chrysler and Diesels—frequently in multiples.

Super-stocks are almost exclusively turbocharged diesels although propane conversions are sometimes used. This brings us to the reason for having a Tractor-Pulling Chapter in a Turbocharger Book.

The old method of pulling a sled with men climbing aboard every ten feet is no longer used for several reasons including safety. The method normally used today is to pull a trailer which has a skid on the front end and wheels on the back end. Figure 131. The trailer starts out with a fixed load on the skid end and a movable load on the wheel end depending on the track conditions and the tractor weight division. As the trailer is pulled along the course, the movable weight which starts out resting over the rear wheels is gradually moved forward, transferring the major part of the load from the wheels to the skid. The load eventually becomes so great, the tractor bogs down and the distance from the starting line to the trailer hitch is measured accurately to determine which tractor pulled the load the farthest. Because engine size is unlimited in any class as long as the tractor conforms to the other rules, it is uncommon for a tractor to stall or power-out. The usual way to end a run is for the tractor to come to a complete stop with the wheels still turning.

Turbochargers were first introduced to tractor pulling in the early 60's—long before they were common at such places as Indianapolis or on the CanAm Racing Circuit, Many of these first applications were pretty crude but it wasn't long before the pullers learned which turbochargers worked best on which engines





Figure 131-Dynamometer sled used in tractor-pulling contests

AiResearch T18A on top of T04B with aftercooling. John Deere engine.






Figure 132—Schematic of tandem turbocharger system

and how much manifold pressure they could stand before the engine gave up. Originally, 10 to 15 pounds manifold pressure felt pretty good because it gave the puller such a big advantage over the naturally-aspirated engines. However, when the majority of pullers were using turbochargered engines, it was necessary to up the boost pressure to win. Forty psig was about the limit from a single-stage turbocharger and the engines still didn't give up. This is about the maximum pressure run on championship-type race cars.

The next step was to mount the turbochargers in tandem, Figure 132. By using this method, it is possible to get ridiculous manifold pressures without overstressing the turbocharger. It was necessary, however, to intercool between the two compressor stages or the intake-manifold temperature would go out of sight. Because each run only takes a couple of minutes, intercooling can be done rather easily with ice water as the cooling medium. If each compressor is matched to produce 2.7:1 Pressure Ratio, the interstage absolute pressure will be 2.7 x 15 = 40.5 psia, Intake-manifold pressure will then be 109 psia or 94 psig. Some of the tractor pullers have actually reported intake-manifold pressures as high as 105 psig.

In Dr. Alfred J. Büchi's Monograph on Turbocharging published in 1953, he dis-

cusses the power increase of a diesel engine as a function of the charging-pressure ratio. He determined the output of a given turbocharged engine when properly scavenged and intercooled continued to increase at pressure ratios as high as 4:1 without any increase in engine-exhaust temperature. Extrapolating these curves, it appears the output will continue to increase probably up to a charging-pressure ratio of 10:1. What this points out is a diesel engine properly turbocharged and intercooled will continue to increase in power at manifold pressures beyond the capabilities of today's engines. He also pointed out that these higher outputs are not necessarily accompanied by higher combustion temperatures. Dr. Büchi was running intake-manifold pressure of 71 psig in 1909. He would probably have run higher pressures even in those days if he had the materials to stand the added stress.

As a result of this high-pressure turbocharging with intercooling, tractor pullers are starting with 400 CID diesel engines designed to produce somewhere around 175 brake horsepower at 2,500 RPM and are obtaining up to 800 horsepower at 4,000 RPM. Two horsepower per cubic inch from a gasoline engine is considered pretty good at about 8,000 RPM. These fellows are doing it at half that speed and with a diesel no less.

When two turbochargers are used in tandem, it is necessary to match the output of the first-stage compressor with the input of the second-stage compressor after the charge has been intercooled. This must be done backwards just as a building is designed from the top floor rather than from the basement. As an example, a 400 CID engine running at 4,000 RPM at 80% volumetric efficiency will use 375 CFM, see Figure 40. Assuming 65% compressor efficiency and 2.7 pressure ratio, the density ratio will be 1.8.

$1.8 \times 375 = 675 \text{ CFM}$

This means a turbocharger with a compressor capable of producing 675 CFM at 2.7 pressure ratio must be used for the second stage. Either an AiResearch T04B V-1 Trim, Rajay 370E, or a Schwitzer 4LE-354 will handle this. Choosing the first-stage compressor is a little harder because an intercooler will be used between the two compressors. Assuming an effectiveness of the intercooler of 75%, the temperature of the air coming from the first-stage compressor will be reduced 75% of the difference of this temperature and that of the medium which, in the case of ice water, will be 32°F. Using Don Hubbard's Chart, Figure 19, and again assuming 65% compressor efficiency, discharge temperature of the first stage at 2.7 pressure ratio will be

360°F. Subtracting 32° from 360°, the difference between the compressor discharge temperature and the cooling medium is 328°F. Multiplying this by .75, the temperature drop across the intercooloer will be 246° and therefore the temperature of the air entering the second stage compressor will be 114°F. This means we will have 675 CFM of air entering the second stage compressor at 114°F. Assuming a negligible pressure drop through the heat exchanger, the flow from the first-stage compressor will be:

$$CFM_2 \times \frac{T_1}{T_2} = 675 \times \frac{360 + 460}{114 + 460}$$
$$= 675 \times \frac{820}{574}$$
$$= 964 CFM_1$$

Where CFM2 is the flow into the secondstage compressor and CFM1 is the flow from the first-stage compressor into the intercooler. The 460 must be added to each of the temperatures because all ratio calculations must be done in degrees Rankine. The 964 CFM will be the output from the first-stage compressor. Because it is desirable to keep the pressure ratios of the two compressors about the same, the density ratio will also be the same or 1.8. Multiplying $964 \times 1.8 = 1735$ CFM, the required capacity of the first-stage compressor. This is where things start to get a little hairy because we are now talking about a fairly good size turbocharger. The turbocharger used for the first stage must be capable of suppling air to an 800 horsepower engine. The first-stage compressor doesn't know it is blowing the air into another compressor raising the pressure to a point where it can be forced into a 400 CID engine. The horsepower obtained from these engines is still a function of the amount of air which can be pumped through it. AiResearch T-18 Turbochargers have been used successfully but because there are so many versions of this, be sure to pick the right one. Model T18A40 with a 1.50 A/R turbine housing has worked out pretty well.

A little luck will be required in picking the correct turbine housing sizes the first time. It will be necessary to have two pressure gages, one on the intake manifold and one between the stages to determine if each turbocharger is running at the same pressure ratio. Remember in each case it is necessary to add atmospheric pressure to

the gage pressure when working out pressure ratios.

Some engine builders use an aftercooler between the second-stage compressor and the engine in addition to the intercooler between stages. When this is done, it is necessary to calculate the increase in flow through the second-stage compressor in the same manner as it was done above for the first stage.

Dyed-in-the wool drag-race fans may laugh at the thought of a tractor pulling contest but there are many similarities between them, such as the super-stock class, the tractor version of the funny car. The pulling contest, however, has one big advantage; you can cheer your hero on for two minutes instead of six seconds. And, you can see the participants from start to finish!



A birds-eye view of the installation shown in the photo below.

International Harvester tractor with AiResearch T18A40 on top of an AiResearch TH08 with intercooling and aftercooling. 1HC DT-436 engine produces 800-1000 HP @ 4500—5000 RPM. Kolb photo.



16 MAINTENANCE



Now that turbochargers have come to age, users are not quite as ready to blame engine failures on them as they were a few years ago. In spite of this, far too many turbocharger and engine failures occur from lack of maintenance which would have only taken a little time and saved the user many dollars and heartaches.

Over the years I have looked at enough failed turbocharger parts to be able to determine, in most cases, whether the failure was due to manufacturing problems or some reason outside of the turbocharger. In the vast majority of cases, the failures were caused by either lack of maintenance or misuse. If the information supplied by this chapter is heeded and used during an installation and afterwards when operating an engine with a turbocharger, it could very well prevent a premature failure which is not only discouraging but expensive.

Chapter 2 described the design and operation of a turbocharger. Chapter 4 went through the procedure of sizing and matching the turbocharger to the engine. Assuming this was done correctly, the turbocharger will run at least as long as the engine unless it is mistreated. The next few pages cover typical turbocharger failures and why they occur.

Jack Lufkin used to run this 300 CID turbocharged big-block Chevrolet in the gasolineburning sportscar class at the Bonneville National Speed Trials. Car was third-fastest at 1971 meet with a 265 MPH run. Engine used AiResearch turbos, intercoolers and waste gates. Injection is a Bosch timed unit. Lufkin works with Ak Miller.

Journal-bearing failures are about as common as any other type. They are frequently caused by lack of lubrication which is easy to spot since the shaft journals will be discolored from the heat generated at high speed with no lubrication, Figure 133. This could be caused by a broken oil supply line, lack of oil in the engine or too heavy oil viscosity for the ambient temperature conditions. It could also be caused by placing an orifice in the oil-supply line to reduce oil pressure to the turbocharger bearings. One speck of dirt can clog a small orifice and cause a failure similar to that shown in the photograph in a matter of seconds.

Journal bearings will also fail when dirt gets into the lubricating oil. This type of failure, shown in Figure 134, will not necessarily have discolored journals but will usually have several grooves in the journals where dirt has become embedded in the radial bearings.

Another symptom of this type of failure is bearing material welded to the shaft journals. The cause could be one of several reasons. If dirt is allowed to enter the turbocharger from dirty working conditions during installation, such a failure could occur. Running an engine without a filter is another cause. Not changing a bypass type oil filter will result in oil flowing around the filter element without being cleansed and then into the turbocharger journals where the failure occurs.

There has been much controversy as to whether an oil filter should be installed in the turbocharger oil-inlet line. Many failures have occurred when a filter element became clogged and prevented oil from flowing to the turbocharger. Many failures have also occurred as stated above when the filter became clogged and oil flowed through the bypass. In either case these failures would not have occurred if the user changed the oil-filter elements at regular intervals. This is one place where it certainly is not economical to save a couple of dollars. As the man used to say in the TV oil-filter ads, "Pay me now or pay me later."

Anyone who builds a racing engine is usually very careful to put covers over all the inlets to the carburetor or fuel-injection system whenever the engine is not running. This is certainly a good practice because dirt or foreign objects are very




Figure 133—Journal and bearing failure caused by lack of lubrication. Dark areas are actually straw to dark blue in color. Bearing material has welded to the journal.

Figure 134—Journal and bearing failure caused by dirty oil. Both journals have been grooved by particles in the oil.






Figure 135-Compressor impeller failure caused by foreign object




Figure 136—Turbine wheel failure caused by foreign object





Figure 137A—Turbine wheel failure caused by over temperature and/or overspeed. This is a mild case because only one of the blades flew off. When the hub bursts it is much more damaging.

Figure 137B—Compressor impeller hub burst caused by overspeed. This type failure usually results in the impeller passing completely through the compressor housing.



destructive to any kind of engine. In spite of this, one of the major causes of turbocharger failure is a foreign object in the compressor impeller. If a nut or bolt enters the compressor housing when the turbocharger is running at high speed, it is like putting something in a meat grinder except that, in this case, the meat is tougher than the grinder. See Figure 135. To make things worse, pieces chewed off the impeller will enter the engine along with the original object, whatever it might be. This type of failure is about as bad as they come, because it may mean a new engine as well as a new turbocharger. For this reason, an air cleaner is always recommended on a turbocharged engine and if matched correctly should not cause any horsepower loss.

When building up a naturally-aspirated engine, little concern is shown for dirt in the exhaust manifold. If a few nuts or bolts happen to be left in there, they will be blown out and no harm done. Not so with a turbocharged engine. Several years ago, it was established that a turbocharger is an excellent spark arrester for engines which must operate in hazardous locations such as dry forests. The reason the turbocharger is a good spark arrester is that particles which are much heavier than air hit the tips of the turbine blades and are knocked back into the turbine housing until they are so small they are no longer considered a spark. The same thing happens with a nut or bolt or a small piece of exhuast valve or piston ring. Whenever one of these gets into the exhaust system of a turbocharged engine, it will hit against the tips of the turbine blades until it looks like a mouse has been chewing on them, Figure 136. This frequently occurs without loss of balance of the rotating group and the turbocharger may run for many thousand of hours without further damage. Most of the time, however, one of the blades will finally break off and the imbalance will cause immediate failure of the journal bearings.

Some users of turbochargers brag about how they get 50 psi out of their compressor when the compressor map for this particular unit only goes to 30 psi. They may be lucky for a while but eventually they will end up with a turbine or compressor wheel that looks

something like Figure 137. When this occurs, it is like a hand grenade going off in the turbine housing and the higher the speed at which the burst occurs, the more dangerous it will be.

The most frequent complaint about turbochargers is that they leak oil. This condition is usually an installation or engine problem although it always gets blamed on the turbocharger. Many turbochargers are designed with a simple labyrinth seal at the turbine end and this design does not seem to leak oil any more or less than those with a piston-ring seal on the turbine end.

As mentioned before, lubricating oil enters the turbocharger from the engine system and at engine pressure. After the oil passes through the bearing it must flow by gravity out of the bearing housing and back to the engine. Anything which restricts the oil drain line will cause the level of oil in the bearing housing to rise above that of the oil seals and in the case of a labyrinth or piston ring seal, the oil will leak into the end housings. This is probably the main cause of oil leakage, although other things will contribute as welf.

Starting at the compressor end, if the air cleaner is allowed to get so dirty it has a sizable pressure drop through it, it is possible, particularly at idle conditions where the turbocharger is blowing through the carburetor, to have a slight vacuum behind the compressor impeller. If the turbocharger has a piston-ring seal on the compressor end, oil will actually be sucked into the compressor housing and lots of blue smoke will come out of the exhaust. Because the piston-ring type seal on the compressor end is capable of preventing oil leakage against only a very small vacuum, it is not recommended to use this type seal when sucking through the carburetor because vacuums as high as 29 in. Hg abs will be imposed on the compressor housing. If the mechanical-facetype seal as used on Rajay and certain models of AiResearch T04 Turbochargers leaks, it has probably become gummed up with varnish and is not able to float freely. When this occurs, the seal should be cleaned or replaced immediately or dirt will enter the space between the carbon-seal face and mating ring and cause rapid seal failure. Other oil-drainage problems which can frequently cause oil leakage are discussed in detail in Chapter 8 on Lubrication.

Table IX shows a list of problems which occur on turbocharged engines and the probable cause of these problems. Whenever possible, try to find a remedy which does not include disassembly of the turbocharger because it probably is not the culprit.

Jack Lufkin has been running turbocharged cars at Bonneville for many years and is still using the same turbocharger he put in service back in the sixties. This isn't just luck and yours can last that long too if it is correctly installed, supplied with clean oil and protected from swallowing solid objects.

NOTE: See Appendix for a thorough discussion of analyzing turbocharger failures.

TABLE IX

CARE AND MAINTENANCE

Typical problems causing turbocharged-engine malfunction

| SYMPTOM | CAUSE | HOW TO CHECK | REMEDY |
|---------------------------------------|--|---|---|
| Lack of boost | Gasket leak or hole in exhaust system | Block off tailpipe with engine running, If engine continues running, leaks are present | Repair leaks, usually gasket surfaces |
| Lack of boost | Worn valves or rings | Compression check engine | Repair |
| Lack of boost | Carburetor too small or butterfly does not open completely | Check pressure drop through carburetor | Use larger carbu- retor or adjust linkage |
| Lack of boost | Restriction in turbine discharge system (muffler) ² | Check turbine discharge pressure | Use larger muffle r |
| Lack of boost | Dirty air cleaner | Remove air cleaner | Service air cleaner |
| Gasoline odor during boost conditions | Small leak at compressor discharge or intake manifold | Look for fuel stains around joints | Tighten joints or replace gaskets |
| Poor throttle response (stumble) | Clogged circuit in carburetor | Try another carburetor or richen jet/s | Clean carburetor and check jet sizes |
| Plugs miss at high power | Gap too large | Measure gap | Clean and reset to 0.025"(2) |
| Plugs miss often(1) | Bad leads | Check lead resistance against specifications | Replace leads |
| Oil leak into turbine housing | Blocked oil drain | Remove drain line and check for plugged or crimped line | Clean or replace drain line |
| Poor idling | Air leak between carbu- retor and compressor | Listen for hissing around carburetor at engine idle | Repair leak |

- At boost of 15 pounds or more, use the best capacitor-discharge ignition system available, preferably with a high-output coil.
- 2. Smaller gaps may be required if misfiring continues.

17 KITS & WHERE TO BUY THEM




Figure 138-Accel Turbo-Module on 350 CID Chevrolet

Universal Turbo-Module by Accel for street use on V-8 engines. Priority-valve actuator does not show in this photo. Turbo is AiResearch TO4.



A few years ago, turbocharger kits for passenger cars-particularly those of the bolt-on type-were such a novelty that automobile magazines were glad to give them space. Today there are so many on the market it is difficult to tell whose kit is on an engine unless a nameplate is hung on it. This is true not only of automobile kits but also those for motorcycles. Because of the large number of motorcycle kits available, these are discussed separately in Chapter 21 on Motorcycles. Not quite as many bolt-on kits are available for marine engines but they are covered in Chapter 11 on Marine Engines. Companies which offer kits are listed in alphabetical order and complete addresses and phone numbers for each company are in the back of this book.

ACCEL TURBOSONIC SYSTEMS BRANFORD, CONNECTICUT

Several years ago, Bob Keller and a couple of other fellows started a company called Turbonics as a sideline while Bob was working at Grumman Aircraft on Long Island, New York. In 1973, Turbonics joined the Flagship Marine Engine Company in Freeport, Long Island, New York, as the Turbonics Division. In June, 1974, the Turbocharger Division was sold to Accel Division of Western Automotive Controls. (Echlin Corp.)

Bob Keller is one of those kind who turbocharged his own car back in the 60's when nobody else was doing it. He had a Dodge with a slant-six engine in it and based his installation on the AiResearch T-5 Turbocharger used on the OldsmobileJetfire. Turbonics made some experimental installations for drag racers and even put out a kit for the small-block Mustang but things really started moving in early 1973. The Keller approach to a turbocharger kit is a little different than others. They build what they call a Turbo-Module which bolts in place of the standard carburetor. The carburetor mounts on top of this module and the

engine operates in a naturally-aspirated mode until the turbocharger is required. To quote their brochure, "The Accel Turbo-Module Kit features a matched turbocharger coupled with a unique automatic manifold priority valve assembly which allows all the advantages of turbo-supercharging without the annoying problems of throttle hesitation, lag, poor idle, etc. By means of this specially designed (patented) valve assembly, the Turbo-Module permits the fuel/air mix to pass directly through the carburetor and into the intake manifold during nonturbocharged operations thereby providing a sharp, crisp throttle response and all of the smooth idle characteristics of the stock-engine configuration. Only when the compressor is providing supercharged power does the fuel/air mix pass through the turbocharger."

Accel offers a number of complete street and competition installation kits for popular engines. These include small-block Chevrolet, Chrysler and Ford V-8 engines, Pinto, Vega and Dodge Colt. A Universal Turbo-Module kit, Figure 138, permits installing a turbo on most V-8 engines. This type kit requires a little more work and know-how on the part of the engine builder, but it is far more flexible and allows the kit to be used on many engine variations. Adapters and flanges are available to simplify the installation. Results of a Universal Turbo-Module on a 350 CID Chevrolet are shown in Figure 139.

Accel's development group has spent considerable time and effort to offer desirable turbo-related accessories, such as water-injection kits, ignition-retard kits, variable-boost-control kits and wastegates. As anyone who has dabbled in the world of turbocharging knows, these items can prove to be godsends.

Each time I hear of a new company in the turbocharger-kit business, I immediately contact them so I can pass the information along. No doubt some kits are being produced and sold without my knowledge but I have included all of those I knew about when we put this book to press.






Figure 139-Test results of Accel Turbo-Module on 350 CID Chevrolet

Pressure-retard vacuum-advance mechanism by Accel retards ignition 1° per pound of boost to a maximum of 8° retard.






Street turbo system by Accel for 1600-2300cc engines.




Accel competition kit for Pinto.

Vega competition kit by Accel uses 500 CFM Holley two-barrel on angle adapter. Because inlet and exhaust are on same side of engine, turbo outlet connects directly to intake manifold through one of Accel's many standard adapters.



Dodge Colt competition kit by Accel.



BROADSPEED SOUTHAM, WARWICKSHIRE, ENGLAND

The ability of Ralph Broad's firm to produce results is known the world over. They have been responsible for winning many national and international salooncar championships and very often are responsible for the preparation of works entered cars. It's hardly surprising that with all their attributes, they should turn their attention to turbocharging. At present they offer two turbocharged engines, the English V-6 in a turbocharged form, and a turbocharged version of the 1.9-liter Opel Manta. Both turbocharge installations use the "blowthrough the carb" method for installation reasons. They use a novel recirculating valve to reduce throttle lag and serve as a boost limiter. Horsepower increases on both these models are as shown below:

3-liter V-6 Ford

| RPM | Naturally Aspirated | Turbocharged |
|------------|---------------------|--------------|
| | Horsepower | Horsepower |
| 2000 | 64 | 72 |
| 3000 | 105 | 150 |
| 4000 | 125 | 187 |
| 5000 | 135 | 215 |
| 5500 | 135 | 220 |
| 6000 | 125 | 220 |

Boost was 6.5 psi for the above results. A later version using 8.5 psi produces 230 HP.


1.9-liter Opel

| RPM | Naturally Aspirated | Turbocharged |
|------|---------------------|--------------|
| | Horsepower | Horsepower |
| 2000 | 35.5 | 45 |
| 3000 | 59 | 88.5 |
| 4000 | 77 | 133 |
| 5000 | 80 | 155 |
| 5500 | 80 | 157 |
| 6000 | 73 | 156 |


This performance is obtained with 9.5 psi boost.

CHECKPOINT AMERICA ST. LOUIS, MISSOURI

Checkpoint America of St. Louis, Missouri, has a turbocharger kit for the Lotus Europa equipped with a 1600cc twin-cam engine. Installation as shown in the photograph is quite simple but very effective. Robert Vandivort of Checkpoint




Checkpoint America's Lotus Europa twin-cam kit uses Rajay 377B40 turbo with the stock 9.5 compression. Boost starts at 2800 RPM, is restricted to 11 psi. Front Stromberg CD carb is retained. Standard air filter and exhaust systems are used. Exhaust manifold is stainless-steel seamless tubing; incorporates support brace for turbo. Distributor has standard advance curve; is retarded 2°. 0–60 MPH time is 6.1 seconds; 1/4 mile elapsed time is 13.7 seconds. Fuel consumption is same as stock.




1972 Lotus Super 7 twin-cam with Checkpoint America turbo kit. Rajay 377B40 turbo pumps up to 21 psi. Single Stromberg CD 1-3/4 inch replaced dual twin-choke Webers. Boost starts at 1500 RPM and a rev limiter is set at 7000 RPM. Lucas distributor is used with a CD unit. Fuel consumption is 37 MPG.





Checkpoint America 1973-75 MGB prototype kit uses Rajay 377B40 turbo. Boost comes in at 1800 RPM, is restricted to 14 psi. SU carburetor uses a special air filter. Distributor is reworked to limit total advance. Exhaust HC and CO emissions reduced 50%, NO_X slightly lower than stock. Builder claims fuel consumption 10% less than stock.

Figure 140-Schwitzer-turbocharged 1600cc Volkswagen engine.



America has found it to be very responsive at low RPM, more tractable and easier to drive and if you desire, will out-accelerate a Daytona Ferrari from zero to 120 miles per hour. It will still cruise at better than 70 miles per hour at 33 miles to the gallon. If this isn't impressive enough, the rearwheel horsepower on a chassis dynamometer showed the following before and after the turbocharger was installed:

| RPM | Naturally Aspirated | Turbocharged |
|------|---------------------|--------------|
| | Horsepower | Horsepower |
| 4000 | 39 | 78 |
| 4500 | 46 | 110 |
| 5000 | 59 | 123 |
| 5500 | 72 | 132 |
| 6000 | 78 | 149 |
| 6500 | 81 | |

It is interesting to note the turbocharged version only goes to 6000 RPM rather than the 6500 of the naturally aspirated engine. This should impress the people who think a turbocharger only works at very high engine speed.

Their kit for the Lotus Super 7 is just as impressive. This model requires a little more work because the compression ratio must be lowered from 10.3:1 to 8.5:1 by using special forged J. E. Pistons. The 0-60 time runs around 5.0 seconds using 185/70-13 radial tires. The 1/4-mile time is 12.28 seconds. Vandivort uses it for daily transportation when weather permits.

Checkpoint America also has a kit for the MGB shown in the photograph. This particular installation not only produces a lot more horsepower but an emissions test showed it reduced all three pollutants.

CRANE CAMS INC., HALLANDALE, FLORIDA

Crane Cams not only offer Schwitzer Turbocharger Kits for the Volkswagen and the Vega but their Division V. P., Don Hubbard has written a manual on turbocharging engines using Schwitzer Turbochargers. It includes information on choosing the right turbocharger for the application and Don has actually picked the exact turbocharger to be used for many installations. The manual also contains cam information for turbocharged engines and service instructions for the turbochargers. Anyone wishing to use Schwitzer Turbochargers for their engines

should obtain a copy of this manual—\$1.00 and read it before starting on an installation. Most of the sizing and matching information from the Crane Manual is included in Chapter 4.

Compressor maps of the available Schwitzer Turbochargers are included in the appendix. Because the Crane Manual is aimed more at helping the end user turbocharge his own engine rather than listing available kits, the results of some of these installations should be interesting to the reader and the photos may give some additional installation hints. Starting with the standard Schwitzer VW Kit for 1500 and 1600cc engines, the comparative results are quite impressive. See Figures 140 and 141.

The results of a wastegated 3LH-209 on a 73 cu. in. Offy Midget are shown in Figure 142. A USAC Car with this setup belonging to Bob Heiman finished second in the 1972 point standings.







Figure 142—Drake (Offy) midget 73 CID with waste-gated Schwitzer 3LH-209, power and torque

Figure 142A—Offy Midget-73 CID, Turbo-3LH-209 with double flow 1.10 inch²-149590 Turbine Housing & Divided Exhaust Manifold.











Figure 143-Power curve of Schwitzer 3MD-560 on Ford Boss 302 engine

Figure 144-Power curve of Schwitzer 3MD-560 on Ford 460 Cobra Jet engine



The Schwitzer 3MD-560 mounted on a Ford 302 Boss Mustang with a wastegate makes a neat package. The power curve is neat also as shown in Figure 143. The peak horsepower was increased from 262 to 330 while the peak torque not only increased about 40% but the speed for maximum torque decreased from around 4500 to 3800 RPM.


A similar installation including the wastegate was mounted on a Ford 460 Cobra Jet. The same turbo size (3MD-560) was used but the turbine nozzle increased from 3.0 in. 2 to 3.4 in. 2 because of the larger engine. Here the peak power was increased from 310 to 360 HP which is a modest increase but the peak torque jumped from 410 pounds feet to 560 which is a whopping increase, Figure 144. Just don't step down too hard on the throttle at around 3000 RPM.

Figure 145 shows how complete Schwitzer's Vega Kit is, even including emission-control-system parts.



Schwitzer on Ford 302.

Schwitzer on Ford 460.







Figure 145-Exploded view of Schwitzer kit for Vega



Turbocharged Vega with Schwitzer aftermarket kit dynoed 150 BHP at 5800 RPM. Kit is available from Crane Cams.




Figure 146—Performance of Porsche 914 with and without turbocharger. Photo below shows installation.




Figure 147—Comparison of stock Datsun L-1600, one modified by BRE and stock engine with Crown turbocharger kit

CROWN MANUFACTURING CO. NEWPORT BEACH, CALIFORNIA

Ted Trevor, the former owner of Crown Manufacturing, was one of the pioneers in turbocharging when he offered a smaller A/R turbine housing for the standard Corvair Turbocharger back in the 60's to obtain more boost pressure for racing purposes. Crown also offered adapters for the Corvair Compressor Inlet to allow the use of large Weber or SU-Type Carburetors, Back in 1972, the Crown Turbocharger Kit for the Datsun 240Z was one of the first of its kind offered and is now available for the 260Z as well. Later the same year, Crown developed turbocharger kits for the 1600 and 1800cc Datsun Engines.


In 1973, Crown was sold to Derek Torley who, with the help of Rick Mack, continued to develop new turbocharger kits, including one for the Porsche 914. This kit is another first because the 914 has a fuel-injected engine and getting the right air/fuel ratio at the right time is a different story than with a carburetor. Figure 146 shows the improvement in performance when turbocharged,

Figure 147 compares the output of a stock 1600cc Datsun, one modified by BRE and the stock engine with the bolt-on turbocharger kit. Here again, it is interesting to note as in the case of engines turbocharged by Schwitzer, the horsepower increase was obtained without resorting to high engine RPM.

No doubt we can look forward to Crown Manufacturing offering more turbocharger kits in the future.







Crown 240Z and 260Z installation with cast manifold adapter.

Crown Datsun 1600 kit.




Figure 148—Far East Trading's Sigma Turbocharger System with fuel-pump pressure controlled by compressor-discharge pressure


FAR EAST TRADING COMPANY LTD. TOKYO, JAPAN

The export manager of TRW International, John Gaspari, sent me information on the F.E.T. Sigma Turbocharger Kit for the 2000cc six-cylinder Datsun Engine. This engine has a single carburetor but otherwise appears similar to the 240Z Engine.

The kit is quite different from those produced by Crown in that the carburetor is pressurized and the compression ratio is reduced to 8/1 with a special gasket included in the kit. Figure 148 is a schematic of this installation and shows how the fuel pressure is regulated.


Far East Trading installation on 1974 Datsun 6-cylinder 2000cc engine. 8:1 compression and 11 psi boost. Air cleaner is built to withstand full boost pressure because carburetor is pressurized. Develops 160 HP at 6000 RPM.





BMW 2002 installation by Doug Fraser uses a Rajay turbo for 7-10 pounds boost, moves carburetor to right side. IMPCO pressure-limiting valve is in turbo-to-intakemanifold crossover pipe.

Doug Fraser 911 Porsche installation with an exhaust sniffer used to aid in the initial jetting of the carburetor. Pressure line through rear window is attached to a recorder which can plot rapid intake-manifold-pressure changes which can easily be missed while trying to keep a car of this potential aimed in the right direction.



DOUG FRASER RACING ENGINES MARBLEHEAD, MASSACHUSETTS

Doug Fraser has been making very neat turbocharger installations for several years. His kits are quite complete and include a boost-pressure controller (IMPCO). Manifolds are handsomely made jig-welded assemblies.

Fraser makes custom installations and has kits for BMW 2002, Porsche 911, Lotus Elan, Pinto, Capri, Spitfire, Datsun 240, 260, 280Z, Chevrolet V8, Vega, Ford V8, Colt and Opel.

MATHWALL ENGINEERING THURSLEY, SURREY, ENGLAND

This firm has developed kits for the BMW 2002 and the Opel Manta. On a BMW installation, a large SU carburetor is used. It is sized in conjunction with exhaust restriction to prevent overboosting. This makes for a very simple setup and with a careful matching of turbine housings, etc., has produced a useful power curve, plus a very good increase in top end HP. Mathwalls claim an increase from 100 to 175 HP; engines usually show between 180 and 185 HP on their dyno. The 0-100 time for the 2002 BMW is 17.8 seconds which compares very favorably with the 19 seconds for the works-turbo-ed 2002. A spot check on the chassis dyno produces 130 HP at the rear wheels at 5000, peak power being nearer 6000. On the Manta they use a similar system. 0-100 time is 19.2 seconds and the HP is up from 80 to a conservative 160.




Figure 149-Ak Miller 2000cc Pinto Kit installation

AK MILLER ENTERPRISES PICO RIVERA, CALIFORNIA

Ak Miller and his cohorts, Jack Lufkin and Bill Edwards, have been in the hotrod business since before they were called hot rods. These fellows, along with Duke Hallock of AiResearch, have been using turbochargers to get added horse-power since the 50's. It is only natural that Ak should offer turbocharger kits and in some cases he has combined them with propane fuel for the cleanest turbocharger kits in town.

Ak has kits for the 2,000cc Pinto, Chrysler Slant Six, 170, 200, 240, 250 and 300 CID Ford 6's, Chevy 6, V-6 Capri, and fuel-injected Porsche 911 and 914.

To quote Ak, "The six-cylinder installation is one of the sweetest set-ups you could imagine. The turbo is neatly tucked away beneath the exhaust manifold and is not visible when you lift the hood. There is as much as 100% gain with these kits."

Ever since I turbocharged my six-cylinder Chevelle back in 1964, I have been convinced that the in-line engine is the way to go in turbocharging. There is

usually plenty of room, practically no ducting is required and you may not need a crossover pipe from the other bank of cylinders. In addition, for the street machine, the results are much more gratifying because the average naturally-aspirated four or six is usually a little shy on power for its respective automobile.

Ak does not stop here as he also offers kits for the Chevrolet, Dodge and Ford pickups. He also has one for the Ford 534 truck engine. Figure 149 is an exploded installation drawing of Ak Miller's Pinto Kit.

For the do-it-yourselfer, Ak offers AiResearch Turbochargers and other items such as carburetor adapters, manifolds and even a flow-control valve which prevents an engine from being overboosted by limiting the flow on the intake side of the engine. This valve, manufactured by IMPCO, is described in detail in Chapter 9, Controls.

Ak has done considerable testing in the emission field showing turbocharging an engine results in better overall emissions. This is discussed at length in Chapter 18, Exhaust Emissions.

MINNOW-FISH CARBURETTORS LTD., LOCHGILPHEAD, ARGYLL, SCOTLAND

This establishment, run by Bob Henderson, specializes in turbo conversions utilizing the Minnow-Fish carburetor which they also manufacture. The usual method with the Henderson Minnow-Fish system is to blow through the carburetor and limit boost with a dump valve upstream of the carb. The range of cars covered by the Minnow-Fish concern is quite wide, including such vehicles as BMW's, Chrysler Avenger and Imp, Volkswagens, British Leyland series B engines and a few more besides.

TETERIN ENGINEERING PTY. LTD. NEWCASTLE, N.S.W., AUSTRALIA

David Inall is one of the pioneers in high-performance turbocharging. David is head of the Product Development Section of Teterin Engineering where he has made many custom installations as well as bolt-on kits.

Their Toyota Celica kit for the 2T-1600cc pushrod engine is quite simple as can be seen in the photos but the results are outstanding as shown below:

| | Rear W | heel | | | |
|------------|--------|------------|----|--|--|
| Engine RPM | Horsep | Horsepower | | | |
| | Before | After | | | |
| 2000 | 21 | 25 | 0 | | |
| 2500 | 23 | 32 | 2 | | |
| 3000 | 25 | 44 | 6 | | |
| 3500 | 28 | 63 | 10 | | |
| 4000 | 34 | 72 | 11 | | |
| 4500 | 42 | 83 | 12 | | |
| 5000 | 51 | 103 | 12 | | |
| 5500 | 53 | 108 | 12 | | |
| 6000 | 54 | 113 | 12 | | |
| | | | - | | |

ENGINE: 2T Toyota—1600cc. Pushrod, hemi four 370B40 Rajay Turbocharger with 40 DCOE Weber Carburetor.

They plan to produce kits for the Datsun 4 and 6-cylinder engines, Colt 4 cylinder and Chrysler 6 (different from U.S. Slant Six).

The kit for the Ford 250 CID (Maverick in U. S. A.) Engine is just as neat looking as the Celica Package and the improvement is even neater.


| | Rear \ | Nheel | |
|------------|--------|-------|----|
| Engine RPM | Horse | Boost | |
| | Before | After | |
| 2000 | 68 | 70 | 1 |
| 2500 | 82 | 102 | 4 |
| 3000 | 90 | 168 | 8 |
| 3500 | 92 | 183 | 12 |
| 4000 | 88 | 191 | 14 |
| 4500 | 84 | 187 | 14 |
| 5000 | 78 | 179 | 14 |
| | | | |

ENGINE: Six-cylinder 250 CID 370E80 Rajay Turbocharger with 45 DCOE Weber Carburetor

The Australian Holden uses a slightly reduced version of the Chevrolet 6-cylinder Nova Engine. The Teterin kit is a good example of a large increase in power without resorting to high engine speed.


| | Rear \ | Vheel | |
|------------|--------|-------|----|
| Engine RPM | Horses | Boost | |
| | Before | After | |
| 2000 | 53 | 56 | 1 |
| 2500 | 67 | 83 | 5 |
| 3000 | 70 | 140 | 9 |
| 3500 | 64 | 164 | 13 |
| 4000 | 38 | 158 | 14 |
| 4500 | 28 | 150 | 14 |
| 5000 | - | 141 | 14 |


ENGINE: Six-cylinder GMC 186 CID 370F60 Rajay Turbocharger with 40 DCOE Weber Carburetor.



Ford 250 CID kit by Teterin Engineering.

Toyota Celica 2T-1600cc kit by Teterin Engineering uses Rajay turbo, Weber carburetor.





Holden 186 CID kit by Teterin Engineering.

SHELBY-SPEARCO DISTRIBUTING COMPANY, INC.

SANTA MONICA, CALIFORNIA

Early in 1974, Rajay Industries decided to get out of the automotive-kit business and concentrate on turbocharger manufacturing. Rajay Volkswagen Kits for single and dual-port Volkswagens and all Rajay turbochargers for the automotive, cycle and marine aftermarket are now distributed by Shelby-Spearco.

Additionally, a 350 CID small-block Chevy turbocharger kit fits most automobiles and light trucks equipped with the small-block engine. Horsepower increases from 25% to 100% are accomplished by selecting A/R exhaust housings and carburetor sizes.

SPEARCO PERFORMANCE PRODUCTS, INC. SANTA MONICA, CALIFORNIA

Spearco Performance Products has turbocharger kits for the 2000cc Pinto, the V-6 2800cc Mustang II, and the V-6 2600cc Capri.

A Pinto Kit designed for the street produces 7 psi boost to increase horse-power 45%. It operates on 91-octane unleaded fuel. An optional exhaust system and turbine housing ups maximum boost to 14 psi and output 100%. Water injection and O-ringing the head is recommended with this version.

The V-6 Mustang Kit in Figure 150 increases the output to 185 HP. It has excellent low-speed driveability, with boost pressure staring at 2,100 RPM. Spearco claims the kit improves fuel mileage.

The V-6 Capri Kit in Figure 151 is similar—but not identical—because the engines have more differences than just displacement. The Capri engine with this kit produced 175 HP. Again, Spearco claims increased fuel mileage.

They have several other irons on the fire such as the Honda Civic installation. This was done with a prototype low-flow Rajay Turbocharger and will not become a kit until the turbocharger goes into production.

Honda Civic 1300cc with Rajay B-flow unit by Spearco Performance Products is boosted at 8 psi at around 5500 RPM.







Figure 150-Shelby Spearco V-6 Mustang kit


Rajay (Shelby-Spearco) dual-port VW kit installed.



Spearco 2000cc Pinto kit puts turbocharger on the left side so factory air conditioning can be retained. This also eliminates any need to relocate the battery. Rajay 301B.4 turbo gives 10 psi boost.







Peugeot 504 1974 diesel sedan turbo-ed by Turbochargers, Inc. Remote oil filter to supply turbo is at the far left side of photo. The turbocharged car was driven round trip from Los Angeles to Fairbanks, Alaska with a 3000-pound trailer being pulled all the way, mileage averaged out at 24 MPG! Windshield washer reservoir and pump were relocated to give exhaust-pipe clearance. Intake and exhaust manifolds are stock. A J-pipe makes the exhaust-manifold-to-turbo connection. Stock air cleaner is retained. Factory air conditioning installs with minor modifications.

Turbocharger, Inc. 300D Mercedes installation connects turbo directly to the air cleaner and intake manifold. Performance is about the same as 450SE.



TURBOCHARGER, INC. DOWNEY, CALIFORNIA

This kit is unique in that it is for a diesel. Many diesel kits have already been offered for trucks, farm tractors and construction but this one is for a passenger car. It is common knowledge the Mercedes diesel-powered cars are not very exciting when it comes to acceleration. This lack of performance is not due to the fact it is a diesel but rather because it is a *small* diesel. The largest four has a displacement of only 2.4 liters or 144 CID.

Turbocharging a diesel such as this has all of the advantages of turbocharging a gasoline engine plus a few more. These are:

- 1. Lower exhaust temperature
- 2. Less smoke and odor problem
- 3. Lower noise level
- 4. Increase in fuel economy

The performance of this kit as measured by Road and Track (September 1973) is:

| Time to | | |
|-------------|------------|------------|
| Speed, Sec. | Stock 220D | Turbo 220D |
| 0-30 MPH | 7.0 | 6.5 |
| 0-40 MPH | 12.3 | 9.4 |
| 0-50 MPH | 18.0 | 13.2 |
| 0-60 MPH | 27.5 | 17.9 |
| 0-70 MPH | 44.2 | 24.3 |


The 0-60 MPH time was reduced by almost 10 seconds—not bad by any standards.

The kit fits all series 200,220 and 240 diesels with either manual or automatic transmissions.

TURBO SYSTEMS, INC. AKRON, OHIO

Bill Laughlin of Turbo Systems decided a few years ago that turbochargers were the only way to go so he purchased the Pinto and Vega turbocharger kit lines from Car Corp. of Livonia, Michigan, and has since added a small-block Chevy kit of his own. This is a real performance kit using two turbochargers and will fit all of the small-block Chevy's from 265 up to 400 CID. Bill has cast new exhaust manifolds for the engine so the turbochargers can be mounted high on the front end. This kit is for the man looking for power rather than comfort because air conditioning cannot be used.


Turbo Systems has done quite a bit of work with diesel tractors used in tractor pulling contests.



Roto-Master kit for the naturally aspirated Cummins 220 HP diesel is produced by the firm which author Hugh MacInnes serves as Vice President and Chief Engineer. Roto-Master is a division of Echlin Manufacturing Co., one of the largest automotive aftermarket suppliers.


Turbocharger, Inc. kit for 200, 220, 240 diesel fits even with air conditioning.





18 EXHAUST EMISSIONS





Northrop Institute of Technology entry in 1973 and 1974 Reduced Emission Rallies for college students was a turbocharged Toyota using propane fuel. One-third of the cars entered in 1974 had turbocharged engines.

NOTE: Tests have shown in nearly every case that turbochargers reduce emissions—or at least do not increase them. Even so, to add one to a non-turbocharged gasoline engine was illegal in the state of California when this book went to press. Diesel and propane use with an add-on turbocharger apparently was allowable.

One of the most frequently asked questions about turbochargers is "What will a turbocharger do for the exhaust emissions from my engine?" There is no simple answer to this question because a turbocharger is not a device designed to chop up exhaust emissions in little bits and spit them out as clean air. However, tests have shown that a turbocharger applied either to a diesel or a gasoline engine in good running condition will not significantly increase any of the measured exhaust emissions and in almost every case will decrease them. The nice part about this is it can be done while increasing the output of the engine by as much as 100%.

Looking at this from another view-point, the output of a standard U. S. gasoline engine, when equipped with all the devices to meet the 1975 and later exhaust-emissions requirements, has lost so much power the vehicle will no longer perform in a manner most of us have accepted as a way of life. A turbocharger applied directly to such an engine will allow it to produce the horsepower it had before all the emission devices were applied. The largest single disadvantage here is the fuel consumption will not be as good as the original high-compression naturally-aspirated engine.

With the diesel engine, it is a slightly different story. The diesel engines up until recently were not considered seriously for use in U. S. passenger cars for several reasons including a poor power-to-weight ratio and high initial cost. Even with the addition of all the emission-control devices, few people looked at the diesel engine seriously because the extra fuel burned in the gasoline engine wasn't all that expensive. The 1974 fuel shortage and subsequent price increase has altered our thinking considerably and it has suddenly become patriotic to try to reduce fuel consumption as well as exhaust emissions.

An engine such as the Nissan CN6-33 six-cylinder in-line diesel of 198 CID will

run at 4,000 RPM-fast enough for any passenger ¢ar or pickup truck. This engine ' is almost competitive weight and powerwise with a small V-8 gasoline engine equipped with all the exhaust-emission devices including a catalytic converter. I say almost competitive because the simple addition of a free-floating turbocharger makes it more than competitive. The state of California has been conducting tests with this engine since January 1974 where fuel consumption is a consideration just as important as low exhaust emissions. The original test was run on two Dodge 3/4-ton pickups normally equipped with 360 CID gasoline engines. One of the trucks has a naturally-aspirated CN6-33 Nissan engine while the other has the same basic engine with a Rajay Turbocharger. The naturally-aspirated engine has a maximum output of 92 HP at 4,000 RPM while the turbocharged version of this engine produces approximately 130 HP. Both vehicles were tested for exhaust emissions and fuel consumption before the gasoline engines were removed. The emissions and fuel consumption tests were rerun after the diesel engines were installed and the comparative results are shown in Table X. The turbocharged diesel, when compared to the proposed California Requirements for 1976, was twice as good on HC, seven times as good on CO and only 7% too high on NOx. The nicest thing about this is the engine contains no special devices which contribute to fuel consumption without producing power. Patricia Spears recently made a comment when looking at a 1974 car with the hood raised. She said, "The only people who make out from all these emission controls are the hose manufacturers."

Tony Campana of Wilcap who made the installation for the state of California has been running several diesel-powered passenger cars including a Dodge Dart with a turbocharged diesel like one of the state pickups. Because of the light weight of this vehicle, he gets 40 miles to the gallon. He doesn't have to worry about passing through a town which may not have a diesel fuel pump. He might drive through an entire state without refueling.

Because most of us are concerned with gasoline rather than diesel engine vehicles, the effect of a turbocharger on exhaust emissions is of more importance

TABLE X

Fuel-Consumption & Exhaust-Emissions Comparison of a 1973 3/4-Ton Truck with Gasoline & Diesel Engines, both Air-Conditioned

| | | COLD | START CVS | TEST | |
|-------------|---------------------|---------|-------------|-------|--------------|
| | | | GRAMS/MII | L E | |
| TRUCK | ENGINE | HC | co | NOx | MILES/GALLON |
| CHC 2747 | Baseline Gasoline | 3.72 | 53.82 | 4.93 | 11 |
| CHC 2748 | Baseline Gasoline | 2.91 | 37.84 | 4.52 | 11 |
| CHC 2747 | Baseline Diesel | 1.17 | 4.14 | 2.52 | 20 |
| CHC 2748 | Turbocharged Diesel | 0.47 | 2.54 | 2.13 | 20 |
| | ADDITIO | NAL HOT | CVS – 1 TES | T . | |
| | | нс | co | NOx | |
| CHC 2748 | Emissions | 0.26 | 2.10 | 1.85 | |
| | | | SPEED | (MPH) | |
| | | 30 | 40 | 50 | 60 |
| Dynamometer | Fuel Consumption | 29.4 | 26.2 | 23.8 | 20.3 |

TABLE XI

Comparison of Exhaust Emissions of Naturally Aspirated and AK Miller Turbocharged Engines


EMISSIONS RESULTS

TURBOCHARGED VEHICLES

| DATE | VEHICLE | CID | TRANS | FUEL | LAB | TEST | HC | co | NOx |
|----------|-------------------|-----|-------|---------------|--------------|---------|------|-------|-------|
| 9/4/73 | Pinto Pangra (T) | 120 | 4-spd | Gas | Scott | CVS 1-2 | 1.84 | 20 | 3.01 |
| 9/72 | Pinto 2000 (T) | 120 | Auto | Gas | AESI | CVS 1-2 | 1.51 | 27.04 | 1.72 |
| 4/8/71 | Pinto 2000 (T) | 120 | 4-spd | Propane | Auto Club | 7-mode | 0.7 | 10.9 | 1.3 |
| 2/73 | Maverick (NA) | 250 | Auto | Gas-EGR | AESI | CVS 1-2 | 1.70 | 24.07 | 1.92 |
| 9/72 | Maverick (T) | 250 | Auto | Gas No EGR | AESI | CVS 1-2 | 1.23 | 19.73 | 3.2 |
| 3/7/72 | Maverick (T) | 250 | Auto | Propane | Auto Club | 7-mode | 0.55 | 1.83 | 1.007 |
| 10/20/71 | Dodge 440 (NA) | 440 | Auto | Gas | Auto Club | 7-mode | 1.15 | 19.05 | 5.13 |
| 4/5/72 | Dodge 440 (NA) | 440 | Auto | Propane | Auto Club | 7-mode | 0.25 | 2.07 | 0.58 |
| 5/73 | Dodge 440 (T) | 440 | Auto | Propane | Auto Club | 7-mode | 0.23 | 2.38 | 0.63 |
| 7/73 | Aston Martin (NA) | 327 | 4-spd | Gas | Auto Club | 7-mode | 0.32 | 8.17 | 1.30 |
| 8/73 | Aston Martin (T) | 327 | 4-spd | Gas | AESI | CVS 1-2 | 1.72 | 34.3 | 2.70 |

T - Turbocharged

NA - Naturally Aspirated



1972 Monte Carlo 350 CID Chevrolet turbocharged by Schwitzer for high power and low emissions. This system pressurizes the carburetor.

TABLE XII

Exhaust Emissions of Naturally-Aspirated vs.

Turbocharged Datsun 240Z

| | 1973 California | Test 1 | Test 2 |
|-----------------|-----------------|------------|-------------------|
| | Standards | Stock 240Z | Turbocharged 240Z |
| нс | 3.2 | 2.085 | 1.476 |
| co | 39.2 | 22.306 | 16.270 |
| NOx | 3.0 | 2.073 | 1.409 |
| MPG | | 18.83 | 19.398 |
| MPG (steady | | 31.74 | 31.99 |
| state 50 MPH) | | | |
| HC | 3.2 | 2.9* | 2.9 |
| co | 39.0 | 29.0* | 38.9 |
| NO _× | 3.0 | 1.8* | 1.1 |
| | | | |

^{*}Baseline Data From Nissan Motor Car Co.

TABLE XIII

COMPRESSION PRESSURE OF VARIOUS ENGINES CALCULATED FROM FIGURE 152

| | Naturally | | | |
|--|-----------|----|--------|--------|
| | Aspirated | | Turboc | harged |
| Compression Ratio | 10.5/1 | | 7.0/1 | 7.0/1 |
| Intake Manifold Pressure PSIA | 14.7 | Pb | 29.4 | 25 |
| Inducted Charge Temperature R | 600 | Th | 750 | 700 |
| Inducted Charge Density Ft ³ /Lb. | 15.05 | Vb | 9.41 | 10.5 |
| Entropy | .085 | S | .095 | .09 |
| Charge Density at end of Compression | | | | |
| Stroke – Ft ³ /Lb. | 1.43 | Vc | 1.345 | 1.53 |
| Compression Pressure PSIA | 340 | Pc | 360 | 320 |

to us. Two companies, in particular Ak Miller Enterprises and Crown Manufacturing, have gone out of their way to show the results obtained by applying a turbocharger to a standard gasoline engine without disturbing the emission equipment. Ak Miller, in addition, has made many installations where the fuel system was converted to use propane and here, even better results were obtained. Table XI compiles these results and shows dates for the runs. Crown Manufacturing has concentrated on kits for the Datsun 240Z and 260Z. Emission tests were run before and after the turbocharger was installed. The results of these tests are shown on Table XII. Here again we see where an engine equipped with devices to meet the 1973 California Standards actually improved somewhat on exhaust emission when equipped with a turbocharger and at the same time nearly doubled its output.

Now that it is established that a turbocharger on either a diesel or gasoline engine will not hurt exhaust emissions and usually will improve them it is only fair to ask why? In the case of the diesel engine, the answer is relatively simple. Air flow through a naturally-aspirated diesel is strictly a function of engine speed and not power because the engine does not normally contain a butterfly in the air intake. Output is governed by the amount of fuel injected with each power stroke. Maximum output of a naturally-aspirated diesel is limited by the exahust smoke. When a turbocharger is applied to a diesel engine, a manifold pressure of 10 psigwhich is easy to obtain-will increase the air flow through the engine by about 67%. If the fuel setting is left the same as when naturally aspirated, the extra air will lower the combustion temperature and therefore the amount of NOx in the exhaust. The extra air will also do a better job of reducing hydrocarbons and carbon monoxide merely by having excess. oxygen present to produce a more complete combustion. Even when the engine output is increased by burning more fuel per stroke, exhaust emissions will be reduced as long as the fuel/air ratio is kept considerably leaner than when naturally aspirated.

The gasoline engine is a different story. Here, regardless of output or operating condition, the fuel/air ratio must be kept close to a stoichiometric mixture or it will




Figure 152—Compression chart for a chemically-correct octane-air mixture plus an average amount of clearance gases.

Line A is naturally aspirated, 10.5:1 compression ratio.

Line B is supercharged at 2:1 pressure ratio, 7:1 compression ratio.

Line C is supercharged at 1.7:1 pressure ratio, 7:1 compression ratio.

Lb fuel/lb air = 0.0665; E of combustion = 1280 (1-f); H of combustion = 1278 (1-f).

(From Hershey, Eberhardt and Hottel, Transactions of the S.A.E., October 1936).

not burn. This means the fuel/air ratio of the turbocharged engine will have to be approximately the same as the naturallyaspirated engine. Because of this, any improvement in the exhaust emissions after the turbocharger is applied must come from some other cause than air/fuel ratio. When the carburetor is placed upstream of the compressor, it is necessary for all of the fuel to pass through the compressor impeller on its way to the combustion chamber. A centrifugal compressor is inherently a high-speed device and even at part load, the compressor can easily be rotating at somewhere between 20,000 and 30,000 RPM. This high speed not only makes it impossible for small droplets of gasoline to be carried into the intake system but also does a thorough mixing job on the gasoline which has already been vaporized.

A naturally-aspirated gasoline engine does not have a perfect intake manifold and the fuel/air ratio will vary somewhat from cylinder to cylinder. As a result, some of the cylinders will be slightly lean while others will be slightly rich. Those which are slightly lean will tend to increase the output of NO_{\times} while those which are slightly rich will tend to increase the output of HC and CO_2 . If the turbocharger compressor is installed correctly so that no stratification takes place in the intake manifold, see Chapter 14—Installation Hints, there will be a relatively even fuel/air mixture to all cylinders, promoting consistent combustion in each.

This is not too hard to sell on the part-load basis on which the emission tests are run, but the next question is what about when the engine is really pulling power. Won't the emissions be a lot worse than they were on a high-compression naturally-aspirated engine? Back in 1936, some gentlemen named Hershey, Eberhardt and Hottel published the curve shown in Figure 152, in the SAE Transactions. This curve when used properly is a means of determining compression pressure at the end of the compression stroke when using a chemically-correct mixture of gasoline and air. Using it as a basis, a naturally-aspirated engine with 10.5:1 c.r. can be compared to a turbo-

charged engine of 7:1 c.r. to find out how high the compression pressure will be which will have a direct effect on the combustion temperature. In Table XIII we see that with 10 lbs, intake-manifold pressure (25 psia) the compression pressure of the turbocharged engine will actually be 20 lbs. less than the naturally aspirated engine. The turbocharged engine with approximately 50% more air and fuel available will put out over 50% more power than the naturallyaspirated engine. However, because of the added turbulence due to the compressor impeller, and because the combustion temperature will not be any higher, exhaust emissions will usually be about the same or a little less with the turbocharged engine. When running at wide-open throttle, intake-manifold pressure will usually be higher than the exhaust-manifold pressure. This will remove the clearance gases and reduce the combustion temperature of the turbocharged engine even further.

Gary Knudsen of McLaren Engines ran tests on a big-block Chevy engine


TABLE XIV

TURBOCHARGED TCCS ENGINE-POWERED M-151 VEHICLE

Emissions and Fuel Economy With Gasoline Fuel & Without Emission Controls

| | | EMISSIONS. | GPM | FUEL ECONOMY MPG (Liters/100km) |
|-------------------------------|------|------------|------|------------------------------------|
| | HC | со | NOx | WEIGHT |
| Full emission controls | 0.35 | 1.41 | 0.35 | 16.2 (14.5) |
| No emission controls | 3.13 | 7.00 | 1.46 | 24.3 (9.7) |
| Carbureted L-141 engine | 4.50 | 73.18 | 3.22 | 15.3 (15.4) |
| Proposed Federal Limit (1976) | .40 | 3.4 | .41 | |
| *Fuel: gasoline | | | | |


Chevy 350 CID Z-28 engine on test at AiResearch for low emissions development. Similar projects were accomplished by Rajay and Schwitzer for Chevrolet Engineering.



where he observed the compression pressure in the combustion chamber by means of a pressure transducer and an oscilloscope. He was surprised to learn that the turbocharger did not appreciably increase the compression-pressure peak but fattened up the curve considerably. The fatter curve increased the BMEP and therefore the horsepower.

For many years, Texaco has been experimenting with a different type of combustion chamber known as the stratified-charge engine or the Texaco Controlled Combustion System, TCCS. Many S.A.E. papers have been published on this subject. I do not intend to go into detail on the design of this combustion system but would like to point out the addition of a turbocharger greatly increased the maximum output of the engine, improved fuel economy and reduced exhaust emissions. Table XIV shows where the turbocharged version of this engine equipped with full emission controls not only met the then-proposed 1976 Federal Limitations but did it at better fuel economy than the original engine with practically no emission-control devices. This engine which might be considered halfway between a diesel and a spark-ignition engine has cylinder injection which actually sprays the fuel on the spark plug. The word fuel is used because it will run on almost anything which will burn.

Turbocharging definitely has a place in the engine of the fututre, not just because it can improve the power-to-weight ratio but also because it can help reduce exhaust emissions without hurting the fuel consumption.




Australian Holden 186 CID in-line sixcylinder engine turbocharged by David Inall, Inc. using a Rajay unit. Carb is an SU.

WATER INJECTION 19

Most bolt-on kits for street use will produce a maximum intake-manifold boost pressure of somewhere between 5 and 10 psig. This amount of boost normally will not require any modification of the engine and it will not detonate on premium fuel when the fuel/air mixture and the ignition are set correctly. If modifications are made to the engine to allow the boost pressure to go above 10 psig, it is not always possible to prevent detonation, even with a retarded spark.

In Chapter 5 on Carburetion, I discussed enriching the fuel/air ratio as a method of preventing detonation when the engine is in the supercharged condition. This method will work up to a certain limit and beyond that the engine will detonate regardless of how rich the mixture is. Beyond this point either water or water-alcohol injection are required to prevent detonation.

We all have a tendency when we discover such phenomenon and the solution to it, to think we have "invented the wheel." This problem, for one, has been around a long time and Ricardo not only faced it but ran a series of tests in the early 1930's, plotted in Figure 153. Reference: The High-Speed Internal Combustion Engine by H. Ricardo. To quote Mr. Ricardo, "In this case, running throughout at a speed of 2,500 RPM and with a compression ratio of 7:1, the engine was run on an economical mixture, i.e. about 10% weak, and supercharge applied to the first incidence of detonation, which occurred when the BMEP had reached 168 pounds per square inch. The mixture strength was then increased, step by step, and more supercharge applied until the same intensity of detonation was recorded; this process was continued until a point was reached at which no further enrichment was effective. In fact, after about 60% excess fuel, not only did further enrichment have no effect but there was even some indication that it increased the tendency to detonate. A finely pulverized water spray was then delivered into the





Tom Keosababian combined ecology with engineering by running on propane to break the record for the class at Bonneville in August 1974. He ran over 170 MPH that year. He used two Rajay turbochargers and two propane carburetors. Water for injection comes from a valve on the firewall to each compressor inlet.




Figure 153—Variation in maximum BMEP without detonation by enriching mixture and with water injection. Fuel was 87-octane gasoline.

induction pipe which served to suppress detonation, in part by the inter-cooling it provided, and in part by the influence of steam as an anti-detonant, and so allow of further supercharging. This was continued progressively, admitting just sufficient water at each stage to ward off detonation until a BMEP of 290 pounds per square inch was reached, which was found to be the limit of the dynamometer. At the same time, it was noted that, with the addition of water, the influence of steam as an anti-knock allowed the fuel/air ratio being much reduced. From this curve, Figure 153, it will be seen that under these operating conditions a limiting BMEP that could be reached with 87 octane petrol alone at an economical mixture; strength was 168 psi. By enriching the mixture to the limit of usefulness, the BMEP could be stepped up to 237 psi. By the introduction of water, it could be further stepped up 290 psi and probably more; at the same time the fuel/air ratio could be reduced once again; in fact with water injection, no appreciable advantage was found from the use of an overrich fuel/air mixture. It will be noted that the total specific consumption of liquid, i.e.,

fuel plus water, is not so very much greater than when running on a very rich mixture of fuel alone."

"The slope of the curve of maximum cylinder pressure is interesting in that after the injection of water, it no longer rose but even tended very slightly to fall, and the same applied to the gross heat flow to the cooling water which reached a maximum at a BMEP of about 230 pounds per square inch, and thereafter fell off, until at a BMEP of 290 pounds per square inch it had fallen to the same level as that of 170 pounds without water injection."

The result of this kind of test will vary with engine speed, engine size, compression ratio, fuel octane etc. These variations are not important as far as the principle is concerned. The main thing the curve shows is detonation may be prevented up to a certain point by fuel enrichment, but after that point, water or water-alcohol injection must be used.

Water is usually combined with methanol (methyl-alcohol) in proportions up to 50-50 water-methanol to increase the volatility of the injected mixture—and

therefore its cooling effect—to add part fuel instead of all water for further horse-power increase, and to eliminate the possibility of the water freezing on a cold day. Harry Ricardo, again quoting from his book, The Higher Speed Internal Combustion Engine, says "Higher percentages of methanol are not desirable because methanol, itself, is prone to pre-ignition."

Tests made in 1971 by Ted Trevor of Crown Manufacturing showed that mixtures containing more than 50% methanol provided no additional HP gains over a 50/50 mixture. Dick Griffin confirmed that 50/50 is practical in his tests which were made several years earlier.

Opinions vary as to the amount of boost pressure which makes water or water/alcohol injection mandatory. Some say any boost over 5 psi should be accompanied by injection. Others claim that 8 psi is where the "borderline" begins. And, we've talked with some racers who felt 15 psi boost was a good place to start using water injection. As the saying goes, "Circumstances alter cases." Obviously, a higher compression ratio or advanced spark will require such injection at a lower boost pressure than would a lower c.r. and lesser spark advance. If detonation is occuring at a particular boost pressure and RPM, then water injection should be started prior to the onset of detonation. Should detonation occur, it is essential to back off on the throttle instantly because sustained detonation will destroy the engine very quickly. In any case, water should not be injected at a manifold pressure much below where it is needed. If injection does not take place below 5 lbs. boost, there will usually not be any loss of power due to the cooling effect. It should be noted that engines which are equipped with water-injection will be unusually free from carbon when torn down for inspection or repair. Pistons, combustion chambers and valves all stay remarkably clean with water injection. As a side benefit, spark plugs last longer too.

At least three types of water-injection systems can be considered—and probably a lot more types that I did not think of as this chapter was put together. Two types apply manifold boost pressure to the anti-detonant liquid to push the water through a tube to the carburetor inlet, Crown Figure 154, or through a fitting in the

carburetor base—Griffin Figure 155—when boost occurs.

Crown's system uses a vent at the carburetor air inlet, alongside the injector outlet jet. This vent bleeds off pressure applied to the tank so injection does not start until after boost pressure has reached several psi. The boost pressure at which injection begins is tailored by the size of the restrictor jet in the vent line.

A third type turns on a constant-pressure windshield-wiper pump when a pressure switch on the intake manifold sees 5 psi boost—Ak Miller, Figure 156. This system is probably the most economical because it can be made by modifying an electric-type windshield washer with the pump in the reservoir. All that is needed is a pressure switch and a tube to the carburetor. A modification of this type could use water stored under pressure and a solenoid valve actuated at 5 psi by a pressure switch on the intake manifold.

From these variations you can develop many other combinations depending on your imagination, pocketbook and inclination toward time and experimentation.

Doug Roe uses a slightly different approach to the problem by spraying water into the cooling-air stream of a Corvair engine. 3/16-inch V-type "shooter" or spray tubes with 0.040-inch orifices are located at the front and rear of the cooling-fan inlet and are supplied with water when boost pressure reaches 5 psi or more. Roe's system uses boost pressure to move the water, but a windshield-wiper pump actuated by a manifold-pressure switch could be used instead. Also, this type of system could be augmented by using water-injection into the manifold with the air/fuel mixture.

Tom Keosababian has clearly shown what can be done if water injection is used to its limit. His 1965 Corvair is a street machine with stock suspension. He used two stock Corvair Rajay F turbochargers. Water was injected into each compressor inlet from a valve mounted on the top of the firewall. Carburetion was two Impco CA425 Propane mixers.

This setup with a few other goodies such as a Mallory distributor and transistor ignition produced 450 HP @ 6,700 RPM and ran 176.125 MPH at Bonneville in 1974. He showed it is possible to break a record without spending a fortune.






Figure 154-Crown water-injection system



REAR VIEW - CORVAIR INSTALLATION

Figure 155-Dick Griffin water-injection system

Figure 156-Ak Miller water-injection system



20 MOTORGYGLES

Turbocharging a motorcycle engine may involve all the same basic principles as any other engine but the problems associated with it are quite unique.

Starting with turbocharger size, even the smallest models manufactured by AiResearch, Rajay and Schwitzer are really too large even for the Harley Davidson Electra Glide but in spite of this many installations have been made which give outstanding results and several companies are now in the business of producing bolt-on kits for turbochargers. If Schwitzer would produce the prototype turbocharger shown in Figure 157 mounted on a Petter Diesel Engine, we could almost turbocharge a large-size lawn mower.

The amount of lubricating oil used by a turbocharger compared to a passenger-car engine, even a small one, is so insignificant that it is rarely necessary to add any capacity to the engine oil pump. This is not so on a motorcycle engine where the half gallon a minute used by a turbocharger may be enough to lower the oil pressure to the rest of the engine when it needs it the most. For this reason it is advisable to have a good oil-pressure gage on the bike and if there are signs of oil starvation, a larger oil pump should be installed.

In Chapter 8 on Lubrication, the increase in oil temperature due to the turbocharger bearings was discussed. This can also be a serious problem because the capacity of the oil sump in the motorcycle is limited. If possible, it is desirable to put an oil cooler on the system.

Some motorcycles are equipped with distributors similar to those used on passenger cars while others have a very simple breaker device which fires at the top of the exhaust stroke as well as at the top of the compression stroke. This apparently does not give any problems on a naturally-aspirated engine. However, on a turbocharged engine there is the possibility, particularly at wide-open throttle and high

engine speed, for the intake-manifold pressure to be greater than the exhaust-manifold pressure. Under these conditions when both the exhaust valve and intake valve are open at the top of the exhaust stroke, air/fuel mixture will be blown into the combustion chamber and ignited by the plug. This, of course, will cause severe back firing and loss of power. When this happens, it is necessary to install an automotive-type distributor in place of the breaker points.

A four-cylinder engine with an intake stroke every 180° will cause an almost uninterrupted flow from the compressor discharge and therefore not much volume is required between the compressor housing and the intake ports. A two-cylinder engine, on the other hand, does not necessarily have an intake stroke every 360° and even if it did, the intake stroke would last less than 180° and air in the pipe between the compressor discharge and the intake ports would be stagnant half the time. For this reason, it is advisable to have a plenum chamber on the intake manifold on a two-cylinder engine. The volume of all the pipes from the compressor discharge to the cylinder heads should be at least twice the volume of a single cylinder and preferably three times as great. If the volume is not great enough, intake-manifold pressure will drop off at high engine speed even though the flow is far below the capacity of the compressor.

We are so used to seeing one exhaust stack for each cylinder and one carburetor for each cylinder of a naturally-aspirated bike, it may be hard for the uninitiated to believe a simple exhaust system, where all the cylinders are connected into a single pipe and a simple intake system where a single carburetor is used, can give much better performance just because of a little gadget called a turbocharger. I can assure you this is the case. Bill Hahn of American Turbo Pak has been able to get perfor-

mance out of his 500cc Hondas in street trim which is scary to say the least, Figure 158. The nice thing about the Honda layout is that the original designer must have had turbocharging in mind because it fits in so neatly. The only thing noticeable as it drives by is the lack of exhaust pipes. Figure 159 shows how the various parts of the Honda 500 kit are mounted. The 750 kit in Figure 160 is almost the same but the intake manifold must be connected to the engine by hoses rather than bolting directly.

If the performance on the stock Honda with a turbocharger is not enough, American Turbo Pak offers other goodies such as heat-treated connecting rods for those who want to go all the way. Bill built one up with 811cc displacement which ran the quarter mile in 10.6 seconds at 139 MPH.

It is possible to turbocharge a twostroke-cycle motorcycle but the lack of an oil pump makes it more difficult. This is covered in Chapter 12 on Two-Stroke Engines, and poses many more problems than a four-stroke engine.

Figure 157—Schwitzer's smallest experimental turbo on a Petter 16 CID diesel





Figure 158-Turbocharged performance of 500cc Honda with American Turbo-Pak kit


500 CC HONDA

TURBOCHARGED BY AMERICAN TURBO-PAK

TURBOCHARGED 500

| | DYNO HORSEPOWER | |
|-------|-----------------|-------|
| | AT LBS, BOOST | |
| RPM | TURBOCHARGED | STOCK |
| 4870 | 18.7 | |
| 5350 | 21.2 | |
| 5850 | 24.5 | |
| 6350 | 27 | |
| 6820 | 29.5 | |
| 7300 | 33/1 | 33 |
| 7800 | 38/2 | 34 |
| 8280 | 44.5/3 | 36 |
| 8770 | 52/4.5 | 35.8 |
| 9250 | 58/6 | 35.4 |
| 9750 | 68/8 | 34 |
| 10080 | 76/10 | 32.8 |

Figure 159-Exploded view of American Turbo-Pak Honda 500 kit






Figure 160-Exploded view of American Turbo-Pak Honda 750 kit

Figure 162–900 Kawasaki Turbocharger kit by Blake Engineering uses a Model 377B 25 Rajay Turbocharger. Installation is capable of over 30 pounds boost. Water injection is also used.



Blake Enterprises of Muskogee, Oklahoma, have a kit for the stock Z-1 Kawasaki. Bill Blake says it starts to get boost at about 5000 RPM and reaches approximately 18 psig at 8,500 RPM. It can easily pull 10,000 RPM in fifth gear and depending on gearing, tires and fairing will run 150 to 190 miles per hour in street trim. This kit goes all the way with water-alcohol injection, pressure-retarded spark and a separate pump and oil filter. Anybody for a Sunday drive in the country?

The present kit has an electric oil pump but Bill is working on a crankshaft-driven pump which will be offered when development is completed. Figure 161 shows what this kit looks like before bolting on the motorcycle.

Because the engine layout is similar to the Honda 750, the turbocharger is not obvious once it is installed, Figure 162.

One of the most annoying things to non-cyclists is the noise the bikes make—particularly if you run alongside one for any length of time. The combination of joining the exhaust pipe together and running them through the turbocharger does an excellent job of quieting down the exhaust and the turbocharged motorcycle without a muffler runs quieter than the naturally-aspirated with a muffler on each exhaust pipe. This might not appeal to the purist but is pleasing to the guy who drives behind or alongside of one.



Figure 161-Blake Enterprises kit for Kawasaki Z-1

21 TURBOCHARGING THE INDY ENGINE



1975 Indianapolis winner was this Gurney Eagle. Powerplant was a Turbo-Drake (Offy) modified by John Miller of All-American Racers.

With the advent of the wing on championship-type race cars, peak horsepower has become the most important item to achieve maximum lap speeds. Acceleration or power below peak RPM is still important but with car speeds varying only 25% from straightaway to turns, rather than 33% or more without the wings, it is less significant.

There are several ways power in excess of 900 HP may be obtained with the aid of turbocharging. The method used will determine not only the acceleration and peak power obtainable but also the optimum RPM and have a definite effect

on engine stress and life. Engine power is a function of speed, inlet-manifold pressure and inlet-manifold temperature. Exhaust back pressure will have some effect but it is not as direct as the other three. Let us look at these variables and try to determine the optimum operating conditions.

ENGINE SPEED

Air flow through the engine in CFM is a direct function of engine speed. For an engine of this type, assume a volumetric efficiency (η_{vol}) of 120%. This volumetric efficiency is extremely high and is the

result of high valve overlap and intakemanifold pressures which run as much as 10 psi above exhaust-manifold pressures. It will vary from engine to engine depending on porting, valve timing and the turbocharger overall efficiency, but we will use the 120% figure so the calculations will be consistent.

Air Flow =
$$\frac{\text{Displ (in.}^3) \times \text{RPM} \times \eta_{\text{vol}}}{1728 \times 2}$$

= $\frac{160 \times \text{RPM} \times 1.2}{1728 \times 2}$
Air Flow = .0556 CFM x RPM
See Figure 163




Figure 163-Flow versus RPM of 160 CID engine with 120% volumetric efficiency

This CFM air flow must be converted to lbs./hr. before we can determine how much power can be obtained. In a naturally-aspirated engine we can use a direct conversion factor because air density will remain relatively constant over the operating range. This is not the case with a turbocharged engine. Here we must take into account both the intake-manifold pressure and temperature to convert from cubic feet of air to pounds. The formula to convert air at standard conditions from CFM to lbs./min. is:

CFM x .0765

= lbs./min. (at 29.92 in. Hg bar, and 60°F.)

When the conditions are other than standard, corrections must be made for pressure and temperature. All units must be absolute (Rankine Temp.).

Lbs./min.

 $= \frac{\text{CFM x Man. Press in. Hg Abs x } 520^{\circ}\text{x .0765}}{29.92 \text{ x Manifold Temp. }^{\circ}\text{R. (}^{\circ}\text{F. + 460)}$

For example, take a 160 CID engine running at 8,000 RPM with intake manifold pressure of 92 in. Hg Abs and 350°F.

Lbs./min.

<u>445 CFM (From Fig.158) x 92 x 520 x .0765</u> 29.92 (350 + 460)

 $= \frac{445 \times 92 \times 520 \times .0765}{29.92 \times 810}$

Lbs./min. = 67.2

Lbs./hr. = $67.2 \times 60 = 4,032$

MANIFOLD PRESSURE

An increase in intake-manifold pressure will increase lb./hr. of air at a given engine speed while an increase in intake-manifold temperature will decrease lb./hr. Because of this, it is advantageous to achieve a combination of engine speed, intake-manifold pressure and temperature which will result in the maximum output with the least stress. Because different engines run best at different speeds, the effect of compressor efficiency was plotted for all engine speeds from 5,000 to 10,000 RPM: Figures 164, 165, and 166. In addition a plot was made of the 65% compressor with jacket-water intercooling, Figure 167.

To make use of the air-flow charts, we will assume a given amount of air is

needed to produce a certain horsepower but with varying stress on the engine. Let us say that 4,000 lbs./hr. of air is needed for 800 HP. This flow may be obtained by several combinations of intake-manifold pressure and engine speed. In addition, the effect of compressor efficiency and an intercooler are plotted.

COMPRESSOR SIZES

Figures 168, 169 and 170 are three compressor maps with different flow capacities. The 4000 lbs./hr. conditions are plotted on each to show which engine speed falls in the optimum location and which size compressor is best suited for the application.

Starting with Figure 168 it is apparent that this compressor is too small to handle the flow. If the engine were driven 9,000 RPM, it would still need 4000 lbs./hr. of air to produce 800 HP. But because this point falls in the 50%-efficiency region of the map, the intake-manifold pressure will be 96 in. Abs and the intake-manifold temperature will be about 500°F. The intercooled condition is not plotted because it would fall off to the right of this compressor map in the choked condition.

If the compressor in Figure 169 is used the power may be obtained at several engine speeds with different intake-manifold pressures and temperatures, tabulated in Figure 171.

It is apparent the Figure 169 Compressor may be used to obtain the desired horsepower at different engine speeds both with and without intercooling. The user has the choice of setting up the engine to run at 8,000 RPM with high intake-manifold pressure and temperature or to run it a little faster at 9,000 RPM, with considerably less pressure and temperature. The choice will be governed by the comparative ability of the engine to run at high pressure or high speed. The best operating point will no doubt vary from engine to engine.

In either case, intercooling makes a vast difference by reducing both the intake-manifold temperature and pressure. In addition, for a given output, exhaust temperature will vary directly as the intake-manifold temperature. At 8,500 RPM intercooling can cool the exhaust temperature by 150°F. This lower exhaust temperature can mean




Figure 164—Air flow through 160 CID engine with 120% volumetric efficiency at various intake-manifold pressures. Compressor efficiency 65%, temperature 90°F (550°R)




Figure 166—Air flow through 160 CID engine with 120% volmetric efficiency at various intake-manifold pressures. Compressor efficiency 55%, temperature 90° F $(550^{\circ}$ R)

Figure 165—Air flow through 160 CID engine with 120% volumetric efficiency at various intake-manifold pressures. Compressor efficiency 60%, temperature 90° F (550° R)





Figure 167—Air flow through 160 CID engine with 120% volumetric efficiency at various intake-manifold pressures. Compressor efficiency 50%, temperature 90°F (550°R) with 50%-effective intercooler using 200°F (660°R) jacket water






Figure 168—Compressor map of low-flow-capacity turbocharger







Figure 169—Compressor map of medium-flow-capacity turbocharger

Photo shows Al Unser's winning turbocharged Ford setup. Chief Mechanic George Bignotti chose a Schwitzer turbo and waste gate with Bendix fuel injection. Schematic drawing shows exhaust and intake routing. Photo and drawing courtesy Schwitzer.







| Figure 1 | 70-Compressor | map of hig | h-flow-capacity | turbo- |
|----------|---------------|------------|-----------------|--------|
| charger | | | | |

| icity turbo- |
|---|
| |
| and speed on the dynamometer, it could |
| be disastrous to make changes on the |
| track. Moving into either the surge or |
| choke regions can overstress both engine |
| and turbocharger. Operating in the center |
| of the map will allow the lowest intake- |

a given horsepower output.

This survey is concerned only with the compressor but it is obvious the turbine and nozzle should also be matched for best performance, because most race cars use wastegates.

manifold temperature and pressures for

It is no problem to set it to provide the proper intake-manifold pressure; however, a poorly matched turbine or nozzle will cause unnecessarily high back pressure which will spoil everything gained by intercooling. On the other hand, it is possible that intercooling will drop the exhaust temperature to the point where the turbine will not produce enough power to

spin the compressor fast enough to open the wastegate. If this condition exists, it is necessary to reduce the nozzle size or

perhaps even the turbine size.

All intercooling calculations were done using engine-cooling water as the cooling medium but the car builder is not limited to this. Back in the 20's, they used air-to-air coolers sticking out into the slip stream. Today's cars already have a wing or wings which could be finned and cored without any substantial increase in drag.

As I have mentioned earlier, they used to run the Indy 500 back in 1936 with a limit of 37.5 gallons of fuel for the whole race. Now the owners are complaining about being cut to below 300 gallons. If they used the fuel for power alone instead of as a cooling agent as well, they could run just as fast but with a lot less fuel and considerably less stress on the engines.

the difference between finishing or not finishing a race.

If the compressor is too large for the air requirement, a situation will occur as shown in Figure 170. Here, the requirement of 110 in. Hg at 8,000 RPM will put the compressor in the surge area. This could cause pulses in the intake system great enough to destroy both the engine and the turbocharger. This would occur before the driver was aware that anything was wrong.

The same compressor would be all right at higher engine speeds and with intercooling it would work at even lower engine speeds.

The purpose of making these illustrations is to show a compressor which is good for one set of operating conditions is not necessarily good if the conditions are changed. If the engine and turbocharger are set up for a certain horsepower

Figure 171—Intake-manifold temperature and pressure using compressor on Figure 169 with and without intercooling.

APPENDIX

Glossary

Adiabatic — ideal reversible compression of a gas, implies that there is no heat loss in the process.

Blower - term often applied to all types of superchargers, but usually to low-pressure-ratio units.

Blow-off valve — a spring-loaded valve in either intake or exhaust manifold to prevent over boosting.

Boost – difference in pressure between barometer and intake manifold on a supercharged engine.

Charge + air/fuel mixture to be burned in combustion chamber.

Clearance volume — the volume of a cylinder between the top of the piston and the cylinder head.

Combustion chamber – volume formed by cavity in cylinder head and top of piston when piston is at top of stroke.

Compression ratio – ratio of clearance volumes of a cylinder top and bottom dead center.

Compressor – that portion of the turbocharger which increases the pressure of the air or air/fuel mixture.

Compressor flow range — that area of the compressor map between the surge line and 60% efficiency (for centrifugal compressors only).

Compressor housing — the housing which encloses the compressor. Sometimes referred to as a scroll.

Compressor impeller — the rotating portion of the compressor.

Compressor pressure ratio – compressor outlet absolute pressure divided by compressor inlet absolute pressure.

Critical gas flow — maximum flow through an orifice or restriction for a given pressure upstream of the orifice or restriction.

Density — weight of air or charge per cubic foot of volume.

Diffuser — the stationary portion of the compressor which increases the static pressure of the air or air/fuel mixture. Efficiency — actual performance of a piece of equipment compared to the ideal. Enthalpy — internal energy of a working fluid. Usually stated in BTU/Lb. Exducer —the gas-exit portion of a radial turbine wheel.

Exhaust gas recirculation (EGR) — ducting some engine exhaust back into the intake manifold to reduce oxides of nitrogen in the exhaust.

Inducer – the gas-entry portion of a centrifugal compressor rotor.

Intercooler (aftercooler) — a heat exchanger which reduces the temperature of the compressed charge before it enters the combustion chamber.

Micron – particle-size measurement used to indicate quality of air or oil filter.

1 micron = 0.00004 inch.

Naturally aspirated — an engine without a supercharger. Abbreviated N.A.

Normalize — supercharge an engine running at high altitude, but only to regain power lost because of lower air density.

Nozzle — the stationary portion of the turbine which increases the velocity of the exhaust gases and directs them to the turbine wheel. Most small turbochargers accomplish this with a scroll-shaped turbine housing.

Positive crankcase ventilation (PCV) — engine crankcase fumes ducted back to the intake manifold to reduce air pollution. Pressure, absolute — pressure measured above a complete vacuum.

Pressure, boost – intake manifold gage pressure. 1 psi boost = 2 in. Hg boost (approximately).

Pressure, gage - pressure measured be-

tween two places, usually between ambient and manifold.

Pressure, static – pressure measured in a housing or duct through a hole in a wall parallel to the direction of flow.

Pressure, total — pressure measured in a housing or duct with a probe which senses the velocity pressure as well as the static pressure.

Residual gases — exhaust gases left in the clearance volume at the end of the exhaust stroke.

Rotor — the rotating portion of a turbocharger, including the impeller, shaft and turbine wheel.

Scavenging – removing combustion products from the combustion chamber.

Stoiciometric mixture – correct chemical mixture of fuel and air for complete combustion of both.

Stroke – distance travelled by piston between top and bottom dead center.

Supercharge – increase density of charge by compressing it before it enters the combustion chamber.

Surge line – a line on a centrifugal-compressor map representing minimum flow at each pressure ratio.

Turbine — that portion of the turbocharger which converts the energy of the engine exhaust gases to shaft power.

Turbine wheel — the rotating portion of the turbine.

Turbocharger — an engine supercharger driven by an exhaust-gas turbine.

Valve overlap — the number of crankshaft degrees expressing the time when both the intake and exhaust valves are open.

Vane — stationary guide of diffuser or nozzle.

Volute – A scroll or snail shaped housing. Vortex – free-flowing inward spiral such as seen at the drain of a bathtub.

F

ļ

| Symbol | Name | Used For | Units |
|-------------|--|---|--|
| A | | Acceleration | in./sec,2 or ft./sec,2 |
| A | | Area | Sq. in. |
| ABDC | After BDC | Valve timing vs. piston position | Degrees (O) |
| ABS | Absolute | Pressure or temperature above absolute zero | |
| A/R | Area Ratio | Turbine housing size | In. |
| ATDC | After TDC | Valve timing vs. piston position | Degrees (O) |
| BDC | Bottom Dead Center | Piston position/valve timing | |
| BBDC | Before BDC | Valve timing vs. piston position | Degrees (O) |
| BSFC | Brake Specific Fuel Consumption | | Lb/BHP-Hr. |
| BTDC | Before TDC | Valve timing vs. piston position | Degrees (O) |
| вти | British Thermal Unit | Unit of energy | 778 Ft. Lbs. |
| cc | Cubic Centimeters | Engine size | Cu. cm. |
| CFM | | Volume flow | Cubic feet per minute |
| CID | Cubic Inch Displacement | Engine size | Cu. in. |
| \triangle | Delta | Differences | none |
| e.t. | Elapsed time | Timing | Sec. |
| h | Eta | Efficiency | none |
| F | Fahrenheit | Temperature | Degrees (O) |
| F | Force | Calculating horsepower | Lb. |
| FPS | | Speed | Feet per second |
| G | | Acceleration of gravity | 384 in./sec. ² or 32.2 ft./sec. |
| HP | Horsepower | Engine output | 550 ft. lb. sec. |
| In. Hg | Inches mercury | Pressure | Inches |
| Ĭ | | Moment of inertia | Lb. in. Sec. ² |
| K | Radius of gyration | Moment of inertia | In. |
| L | Liter | Displacement | Liters |
| M | Slug | Mass | Lb. sec. ² |
| M.E.P. | Mean Effective Pressure | Calculating torque | psi |
| MPH | | Speed | Miles per hour |
| N | Rotational speed | | RPM |
| N.A. | Naturally aspirated | Engine designation | |
| Р | | Pressure | Lb,/in ² or In. Hg (mercury) |
| PSIA | | Absolute pressure | Lb./in. ² Absolute |
| PSIG | | Gage pressure | Lb./in. ² gage |
| Q | Volume rate of flow | | Ft ³ /Min. |
| E | | Pressure ratio | none |
| R | | Radius | In. |
| R | Rankine | Temperature (absolute) | Degrees (O) |
| T | and a state of the | Temperature | ^o F or ^o R |
| θ | THETA | Temperature ratio | T° R 520 |
| TDC | Top Dead Center | Piston position/valve timing | 520 |
| T | | Torque | Lb. ft. |
| TC | Turbocharged | Engine designation | |
| 1 | | Volume | Cu. ft. or cu. in. |
| V | | Velocity | Ft/Sec. |
| W | | Weight | Lbs. |
| Y | | Calculating compressor | |

temperature rise

Symbols

Y tables

VALUES OF "Y" FOR NORMAL AIR AND PERFECT DIATOMIC GASES

 $A = \frac{1}{1283} - 1$ $A = \frac{1}{12} - \frac{1}{1295}$ $A = \frac{1}{1295}$

| | | | | | | | | | | | | 506 | 981 | 991 | Sti | 125 | 105 | 980 | 190 | 550 | 054 | 41.0 | 69 1 |
|-----|------|------|------------|------|------|------------|------|------|------------|-----------------|------|------|------------|------|------|------------|------------|------|------|-----|------|---------------------|------|
| 851 | 208 | 687 | ELL | 191 | 147 | 724 | 807 | 269 | 949 | | 2.18 | 003 | 586 | 896 | 845 | 922 | 206 | 188 | 198 | 148 | 850 | | 891 |
| 099 | 449 | 627 | 119 | 969 | 678 | 599 | 949 | 630 | pra | | 2.17 | 008 | 087 | 694 | 687 | 817 | 869 | 119 | 499 | 989 | 919 | | 491 |
| 861 | 184 | 997 | 611 | 433 | 911 | 004 | 384 | 898 | 198 | | 2.16 | 969 | 978 | 199 | 534 | 213 | £64 | 472 | 425 | 431 | 110 | | 99'1 |
| 335 | 319 | 302 | 982 | 270 | 253 | 237 | 221 | 204 | 881 | | 2.15 | 390 | 370 | 349 | 328 | 308 | 787 | 992 | 246 | 225 | 205 | 61.0 | 991 |
| 172 | 122 | 681 | 123 | 106 | 060 | 440 | 780 | 140 | 024 | 0.24 | 2.14 | 181 | 163 | 145 | 155 | 101 | 080 | 090 | 680 | 810 | £66 | | b9'1 |
| 800 | Z66 | 946 | 696 | 242 | 926 | 606 | £68 | 778 | 098 | | £1,S | 116 | 996 | 986 | 116 | 893 | 872 | 895 | 158 | 018 | 687 | | 68.1 |
| 448 | 728 | 118 | 194 | 87.7 | 194 | S47 | 728 | 217 | 969 | | 212 | 897 | LVL | 726 | 907 | 589 | 199 | 643 | 622 | 109 | 089 | | 1.52 |
| 649 | 299 | 919 | 629 | 613 | 969 | 649 | 663 | 979 | 930 | | 11.5 | 699 | 888 | 419 | 961 | SLT | 191 | 433 | 415 | 195 | 330 | | 18.1 |
| 513 | 1.60 | 084 | £9t | LVV | 430 | pip | 397 | 380 | 198 | | 2.10 | 349 | 328 | 307 | 982 | 264 | 243 | 222 | 201 | 081 | 691 | 0,12 | 09.1 |
| 347 | 155 | 314 | 792 | 182 | 597 | 747 | 231 | 214 | L61 | | 2.09 | 861 | 911 | 960 | 470 | 680 | 032 | 010 | 686 | 896 | 1.46 | | 64.1 |
| 181 | 191 | 741 | 130 | til | £60 | 080 | 790 | 740 | 030 | 0.23 | 2.08 | 926 | 106 | 883 | 298 | 048 | 618 | 867 | 977 | SSL | 734 | | 84.1 |
| 510 | 466 | 086 | 896 | 976 | 930 | 518 | 968 | 678 | 638 | | 207 | 712 | 169 | 699 | 849 | 627 | 909 | 188 | 299 | 149 | 220 | | 74.1 |
| 948 | 829 | 812 | 964 | 877 | 762 | Str | 728 | til | 169 | | 2.06 | 861 | 974 | 994 | 433 | 412 | 390 | 698 | 347 | 326 | 304 | | 911 |
| 778 | 099 | vv9 | 129 | 019 | 869 | 929 | 699 | 242 | 229 | | 20.S | 283 | 192 | 239 | 218 | 861 | 971 | 123 | 131 | 011 | 880 | 11.0 | 95.1 |
| 803 | 161 | セムセ | 897 | 177 | 424 | 104 | 390 | 373 | 998 | | 2.04 | 990 | 949 | 620 | 100 | 676 | 896 | 986 | 116 | 892 | 178 | | ו על |
| 339 | 322 | 908 | 882 | 175 | νSZ | 752 | 220 | 203 | 981 | The Application | 2.03 | 648 | 728 | 908 | EBY | 191 | 740 | 817 | 969 | 478 | 299 | | E4.1 |
| 691 | 195 | 135 | 811 | 101 | 1/80 | 990 | 640 | 032 | 210 | 0.22 | 20.2 | 630 | 809 | 989 | 199 | 242 | 129 | 664 | LLV | 994 | 433 | | 24.1 |
| 866 | 186 | t/96 | 146 | 930 | 516 | 968 | 878 | 198 | 844 | | 10.5 | llt | 688 | 366 | PPE | 322 | 300 | 278 | 997 | 234 | 212 | 01.0 | 14.1 |
| 728 | 018 | 792 | SLL | 894 | 147 | 724 | 707 | 689 | 672 | | 2.00 | 061 | 891 | Stl | 123 | 101 | 64.0 | 7.20 | 980 | 012 | 066 | | 04.1 |
| 999 | 869 | 920 | 603 | 989 | 699 | 299 | 534 | 415 | 009 | | 66.1 | 896 | 91/6 | 923 | 106 | 678 | 7.88 | AE8 | \$18 | 067 | 767 | | 95.1 |
| 482 | 994 | 844 | 154 | 214 | 960 | 975 | 198 | 344 | 327 | | 86.1 | StL | 723 | 007 | 878 | 999 | 633 | 119 | 889 | 999 | E43 | | 8E.1 |
| 309 | 262 | 275 | 752 | 240 | 222 | 205 | 881 | 170 | 193 | 12.0 | 76.1 | 129 | 864 | 914 | E9t | 131 | 804 | 386 | 595 | 148 | BIE | | TE I |
| 981 | 811 | 101 | 580 | 990 | 840 | 150 | 610 | 966 | 646 | | 1.96 | 962 | 273 | 092 | 228 | 505 | 182 | 091 | 137 | bli | 760 | 60.0 | 98.1 |
| 196 | b46 | 976 | 606 | 168 | ₽Y8 | 998 | 628 | 1.28 | 108 | | 96'1 | 690 | 910 | 023 | 100 | 87.6 | 996 | 932 | 016 | 788 | 198 | | 98.1 |
| 987 | 897 | 154 | EE7 | 317 | 869 | 189 | 599 | 949 | 829 | | 46.1 | 148 | 818 | 964 | 773 | 094 | 127 | POL | 189 | 899 | 989 | | 1.34 |
| 019 | 593 | 978 | LGG | 01/9 | 229 | 109 | 784 | 691 | 752 | | 56.1 | 612 | 689 | 999 | 543 | 920 | 7.6h | セノセ | 184 | 8Zb | 904 | THE PERSON NAMED IN | EE.I |
| 434 | 911 | 336 | 185 | 263 | 345 | 328 | 310 | 292 | 275 | | 1.92 | 382 | 329 | 338 | 313 | 062 | 267 | 243 | 220 | 161 | DLI | 80.0 | 1.32 |
| 752 | 239 | 221 | 204 | 981 | 891 | 091 | 133 | 211 | 460 | 0.20 | 16.1 | 191 | 128 | 104 | 180 | 890 | 980 | 110 | 886 | 996 | 146 | | 15.1 |
| 640 | 190 | 770 | 920 | 800 | 066 | 272 | 596 | 937 | 616 | | 06'1 | 816 | 968 | 178 | 848 | 828 | 108 | 877 | DSL | 731 | 807 | | 1.30 |
| 106 | £88 | 998 | 748 | 628 | 118 | 16% | 944 | 887 | 047 | | 68.1 | 489 | 199 | 489 | ₹19 | 069 | 499 | E#9 | 920 | 961 | 472 | | 1.29 |
| 722 | POL | 989 | 899 | 099 | 632 | 119 | 969 | 878 | 099 | | 88.1 | 674 | 425 | 402 | 378 | PSE | 155 | 307 | 283 | 560 | 236 | 70.0 | 1.28 |
| 242 | 224 | 909 | 884 | OVA | 754 | 434 | 914 | 868 | 085 | | 78.T | 212 | 681 | 591 | 141 | 111 | ⊅60 | 070 | 910 | 055 | 866 | | 12.1 |
| 362 | 344 | 326 | 308 | 985 | 271 | 263 | 235 | 217 | 661 | | 88.1 | 47.6 | 196 | 726 | 603 | 678 | 998 | 188 | 708 | E87 | 694 | | 1.26 |
| 181 | 163 | ttt | 128 | 801 | 060 | 0.72 | ₽90 | 350 | 710 | 61.0 | 98.1 | SEL | 117 | 789 | E99 | 689 | 213 | 169 | 499 | 543 | 619 | | SZ.1 |
| 666 | 186 | 396 | 1116 | 926 | 806 | 068 | 178 | 863 | 988 | | 1.84 | 965 | 074 | 9446 | 455 | 398 | 274 | 098 | 325 | 105 | 277 | | 1.24 |
| 918 | 867 | 087 | 762 | 243 | 7.25 | 707 | 889 | 049 | 299 | | 58.1 | 263 | 228 | 204 | 180 | 991 | 131 | 101 | 280 | 890 | PE0 | 90.0 | 1.23 |
| 553 | 919 | 969 | 878 | 099 | 1119 | 223 | 909 | 984 | 894 | | 28.1 | 600 | 986 | 096 | 986 | 116 | 788 | 298 | 858 | 813 | 687 | | 1.22 |
| 677 | 121 | 412 | 394 | 376 | 367 | 339 | 350 | 305 | 283 | 029 920 | 18.1 | 191 | 740 | 317 | 169 | 999 | 149 | 719 | 269 | 499 | 243 | | 12.1 |
| 592 | 246 | 228 | 209 | 161 | 172 | 153 | 981 | 911 | 860 | 81.0 | 08.1 | 819 | £67 | 691 | サササ | 614 | 294 | 370 | STE | 320 | 962 | | 1.20 |
| 640 | 190 | 240 | 053 | 900 | 886 | 896 | 61/6 | 930 | 216 | | 67.1 | 270 | 245 | 221 | 961 | 171 | 951 | 121 | 960 | 170 | 940 | 90.0 | 6t t |
| 968 | 874 | 998 | 837 | 818 | 008 | 187 | 292 | DUL | 725 | | 87.1 | 150 | 966 | 178 | 91/6 | 126 | 968 | 178 | 948 | 128 | 964 | | 81_f |
| 907 | 889 | 699 | 099 | 159 | 613 | b69 | 978 | 999 | 829 | | 7.T | 077 | Stl | 720 | 969 | 049 | 1119 | 619 | b69 | 699 | 243 | | 71,1 |
| 619 | 200 | 185 | 462 | 2443 | 425 | 901 | 387 | 368 | 349 | 11:0 | 92.1 | 813 | E6t | 194 | 244 | Lit | 1.68 | 998 | 148 | 315 | 290 | | 91.1 |
| 330 | 118 | 292 | 274 | 592 | 236 | 217 | 861 | 179 | 160 | 71.0 | 92.1 | Z64 | 239 | 213 | 881 | 291 | 137 | 111 | 980 | 090 | 920 | ₽0.0 | 91.1 |
| 141 | 122 | 103 | 1/80 | 990 | 940 | 027 | 800 | 686 | 07.6 | | 47.1 | 600 | 586 | 856 | 835 | 906 | 188 | 998 | 829 | 408 | 877 | | pt.t |
| 196 | 932 | 613 | 1/68 | 875 | 998 | 837 | 818 | 664 | 780 | | 57.1 | 752 | | 700 | 919 | 649 | 623 | 7.68 | 115 | 579 | 619 | | ELL |
| 094 | 177 | 722 | 203 | 489 | 999 | 91/9 | 979 | 708 | 889 | | 1.72 | £64 | L94 | 100 | SIF | 688 | 363 | TEE | 311 | 285 | 692 | 0.03 | 1.12 |
| 699 | 099 | 129 | 116 | 265 | 473 | bSb LOZ | 757 | 517 | 965 | | 17.1 | EEZ | 207 | 181 | 122 | 621 | 102 | 920 | 090 | 024 | 466 | | ti i |
| LLE | 387 | 338 | 319 | 568 | 280 | 192 | 242 | 222 | 203 | | OZ.1 | 17.6 | 946 | 616 | 268 | 998 | 048 | 813 | 787 | 094 | 734 | | 01.1 |
| 184 | 164 | 971 | 152 | 901 | 7.80 | 790 | 810 | 820 | 600 | 91.0 | 69 1 | 807 | 189 | 999 | 829 | 209 | 978 | 619 | 225 | 961 | 69t | | 60.1 |
| 066 | 026 | 196 | 126 | 216 | 892 | 873 | 853 | 834 | 814 | | 89 1 | 244 | 914 | 389 | 362 | 336 | 309 | 282 | SSS | 556 | 202 | 0.02 | 80.1 |
| 967 | SZZ | 997 | 736 | 111 | Z69 | 878 | 899 | 829 | 619 | | 79.1 | SZI | 841 | 155 | 960 | 890 | 150 | 410 | 786 | 096 | 933 | | 1,07 |
| 669 | 089 | 099 | 049 | 129 | 109 | 184 | 462 | 442 | 453 | | 99.1 | 906 | 678 | 258 | 928 | 867 | LLL | 744 | ZIZ | 069 | 899 | | 80.1 |
| 403 | 283 | 595 | 344 | 324 | 304 | 284 | 592 | StZ | 552 | | 39.1 | 929 | 809 | 188 | 199 | 222 | 200 | 272 | Stt | 814 | 390 | | 30.1 |
| 506 | 981 | 991 | 951 | 126 | 101 | 780 | 190 | 740 | 750 | 91.0 | 191 | 595 | 336 | 308 | 182 | 253 | 226 | 661 | 171 | 144 | 911 | 10,0 | 40.T |
| 700 | 886 | 896 | 846 | 928 | 806 | 888 | 898 | 848 | 828 | | 59.1 | 680 | 190 | 034 | 900 | 876 | 196 | 923 | 968 | 898 | 048 | | 1.03 |
| 808 | 887 | 897 | 847 | 728 | 807 | 889 | 899 | 849 | 829 | | 1.62 | 812 | 785 | 757 | 729 | 107 | £73 | 91/9 | 819 | 069 | 799 | | 1.02 |
| 809 | 889 | 899 | 848 | 828 | 809 | 884 | 891 | 844 | 428 | | 19.1 | 123 | 909 | 874 | 091 | 422 | 594 | 366 | 338 | 310 | 282 | | 101 |
| 804 | 785 | 292 | 745 | 327 | 307 | 782 | 767 | 246 | 556 | | 09.1 | 554 | 226 | 861 | 691 | 101 | 113 | 980 | 780 | 820 | 000 | 00,0 | 1.00 |
| c | 0 | 9 | 0 | C | 4.7 | c | 2 | 7 | 0 | | :90 | 6 | 0 | , | 0 | c | 263 | c | 7 | 37 | 0 | | 70 |

| r | | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | r | | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 |
|----------------------|------|------------|------------|-------------|------------------------|-------------------|------------|------------|------------|--------------|-------------|--------------|------------|--------------------|-------------------|------------|------------|------------------------|------------|------------|------------|------------|--------------------|
| 2.19 | | 838 | 854 | 870 | 886 | 902 | 918 | 934 | 950 | 966 | 983 | 2.88 | | 899 | 912 | 925 | 939 | 952 | 965 | 978 | 991 | 005 | 018 |
| 2.20 | | 999 | 015 | 031 | 047 | 063 | 079 | 095 | 111 | 127 | 143 | 2.89 | 0.35 | 031 | 044 | 058 | 071 | 084 | 097 | 110 | 124 | 137 | 150 |
| 2.21 | 0.25 | 159 | 175 | 191 | 207 | 223 | 239 | 255 | 271 | 287 | 303 | 2.90 | | 163 | 176 | 190 | 203 | 216 | 229 | 242 | 255 | 269 | 282 |
| 2.22 | | 319 | 335 | 351 | 367 | 383 | 399 | 415 | 431 | 447 | 463 | 2.91 | | 295 | 308 | 321 | 334 | 347 | 361 | 374 | 387 | 400 | 413 |
| 2.23 2.24 | | 479 638 | 495 654 | 511 669 | 526 685 | 542 701 | 558 717 | 574 733 | 590 749 | 606 765 | 622 780 | 2.92 2.93 | | 426 557 | 439 570 | 452 584 | 466 597 | 479 610 | 492 623 | 505 636 | 518 649 | 531 662 | 544 675 |
| 2.25 | | 796 | 812 | 828 | 844 | 859 | 875 | 891 | 907 | 923 | 938 | 2.94 | | 688 | 701 | 714 | 727 | 740 | 753 | 767 | 780 | 793 | 806 |
| 2.26 | } | 954 | 970 | 986 | 001 | 017 | 033 | 049 | 064 | 080 | 096 | 2.95 | | 819 | 832 | 845 | 858 | 871 | 884 | 897 | 910 | 923 | 936 |
| 2.27 | 0.26 | 112 | 127 | 143 | 159 | 175 | 190 | 206 | 222 | 237 | 253 | 2.96 | | 949 | 962 | 975 | 988 | 001 | 014 | 027 | 040 | 053 | 066 |
| 2.28 | | 269 | 284 | 300 | 316 | 331 | 347 | 363 | 378 | 394 | 409 | 2.97 | 0.36 | 079 | 092 | 105 | 118 | 131 | 144 | 157 | 169 | 182 | 195 |
| 2.29 | | 425 | 441 | 45 6 | 472 | 488 | 503 | 519 | 534 | 550 | 566 | 2.98 | | 208 | 221 | 234 | 247 | 260 | 273 | 286 | 299 | 312 | 324 |
| 2.30 | | 581 | 597 | 612 | 628 | 643 | 659 | 675 | 690 | 706 | 721 | 2.99 3.0 | 0.3 | 33 7 647 | 350 659 | 363 672 | 376 685 | 389 698 | 402 711 | 415 723 | 428 736 | 440 749 | 453 761 |
| 2.31 2.32 | i | 737 892 | 752 907 | 768 923 | 783 938 | 799 954 | 814 969 | 830 984 | 845 | 861 015 | 876 031 | 3.1 | 0.3 | 774 | 786 | 799 | 811 | 824 | 836 | 849 | 861 | 874 | 886 |
| 2.33 | 0.27 | 046 | 062 | 077 | 092 | 108 | 123 | 139 | 154 | 169 | 185 | 3.2 | | 898 | 911 | 923 | 935 | 947 | 959 | 971 | 984 | 996 | 800 |
| 2.34 | | 200 | 216 | 231 | 246 | 2 6 2 | 277 | 292 | 308 | 323 | 338 | 3.3 | 0.4 | 020 | 032 | 044 | 056 | 068 | 080 | 091 | 103 | 115 | 127 |
| 2.35 | | 354 | 369 | 384 | 400 | 415 | 430 | 446 | 461 | 476 | 492 | 3.4 | | 139 | 150 | 162 | 174 | 186 | 197 | 209 | 220 | 232 | 244 |
| 2.36 | | 507 | 522 | 538 | 553 | 568 | 583 | 599 | 614 | 629 | 644 | 3.5 3.6 | | 255 369 | 267 380 | 278 392 | 290 403 | 301 414 | 313 425 | 324 437 | 335 448 | 347 459 | 35 8 470 |
| 2.37 | | 660 | 675 | 690 | 705 | 721 | 736 | 751 | 766 | 781 | 797 | 3.7 | | 481 | 492 | 503 | 514 | 525 | 536 | 547 | 558 | 569 | 580 |
| 2.38 2.39 | | 812 964 | 827 979 | 842 994 | 857 009 | 873 024 | 888 039 | 903 054 | 918 | 933 085 | 948 | 3.8 | | 591 | 602 | 612 | 623 | 634 | 645 | 656 | 666 | 677 | 688 |
| 2.40 | 0.28 | 115 | 130 | 145 | 160 | 175 | 190 | 205 | 220 | 236 | 251 | 3.9 | | 698 | 709 | 720 | 730 | 741 | 752 | 762 | 773 | 783 | 794 |
| 2.41 | 0.20 | 266 | 281 | 296 | 311 | 326 | 341 | 356 | 371 | 386 | 401 | 4.0 | | 804 | 815 | 825 | 835 | 846 | 856 | 867 | 877 | 887 | 898 |
| 2.42 | 1 | 416 | 431 | 446 | 461 | 476 | 491 | 506 | 521 | 536 | 551 | 4.1 4.2 | 0.5 | 908 | 918 020 | 928 | 939 | 949 | 959 060 | 970 070 | 980 080 | 990 | 100 |
| 2.43 | | 566 | 581 | 596 | 611 | 626 | 641 | 656 | 671 | 686 | 701 | 4.3 | V 3 | 110 | 120 | 130 | 140 | 150 | 160 | 170 | 179 | 189 | 199 |
| 2.44 | | 716 | 730 | 745 | 760 | 775 | 790 | 805 | 820 | 835 | 850 | 4.4 | | 209 | 219 | 228 | 238 | 248 | 258 | 267 | 277 | 287 | 296 |
| 2.45 2.46 | 0.29 | 865 013 | 879 028 | 894 043 | 909 | 924 073 | 939 | 954 102 | 969 117 | 984 132 | 998 | 4.5 | | 306 | 316 | 325 | 335 | 344 | 354 | 363 | 373 | 382 | 392 |
| 2.40 | 0.29 | 162 | 176 | 191 | 206 | 221 | 235 | 250 | 265 | 280 | 295 | 4.6 | | 401 | 411 | 420 | 430 | 439 | 449 | 458 | 467 | 477 | 486 |
| 2.48 | | 309 | 324 | 339 | 353 | 368 | 383 | 398 | 412 | 427 | 442 | 4.7 4.8 | | 495 588 | 505 597 | 514 606 | 523 616 | 533 6 25 | 542 634 | 551 643 | 560 652 | 570 661 | 579 670 |
| 2.49 | | 457 | 471 | 486 | 501 | 515 | 530 | 545 | 559 | 574 | 589 | 4.9 | | 679 | 688 | 697 | 706 | 715 | 724 | 733 | 742 | 751 | 760 |
| 2.50 | | 604 | 618 | 633 | 647 | 662 | 677 | 691 | 706 | 721 | 7 35 | 5.0 | | 769 | 778 | 787 | 796 | 805 | 814 | 822 | 831 | 840 | 849 |
| 2.51 2.52 | | 750 896 | 765 911 | 779 925 | 794 940 | 808 954 | 823 969 | 838 984 | 852 998 | 867 013 | 881 027 | 5.1 | | 858 | 867 | 875 | 884 | 893 | 902 | 910 | 919 | 928 | 936 |
| | 0.30 | 042 | 056 | 071 | 085 | 100 | 114 | 129 | 144 | 158 | 173 | 5.2 5.3 | 0.6 | 945 | 954 040 | 962 048 | 971 057 | 980 065 | 988 | 997 082 | 006 091 | 014 099 | 023 1 08 |
| 2.54 | | 187 | 202 | 216 | 231 | 245 | 260 | 274 | 289 | 303 | 318 | 5.4 | 0.0 | 116 | 125 | 133 | 142 | 150 | 159 | 167 | 175 | 184 | 192 |
| 2.55 | | 332 | 346 | 361 | 3 7 5 | 390 | 404 | 419 | 433 | 448 | 462 | 5.5 | | 200 | 209 | 217 | 225 | 234 | 242 | 250 | 258 | 267 | 275 |
| 2 56 | | 476 | 491 | 505 | 520 | 534 | 548 | 563 | 577 | 592 | 606 | 5.6 | | 283 | 291 | 300 | 308 | 316 | 324 | 332 | 340 | 349 | 357 |
| 2.57 | | 620 764 | 635 778 | 649 | 663 807 | 678 | 692 | 707 | 721 | 735 | 750 | 5.7 5.8 | | 365 446 | 373 454 | 381 462 | 389 470 | 397 478 | 405 486 | 413 494 | 421 502 | 430 509 | 438 517 |
| 2.58 2.59 | | 907 | 921 | 793 936 | 950 | 821 964 | 836 979 | 850 993 | 864 007 | 879 021 | 893 | 5.0 5.9 | | 525 | 533 | 541 | 549 | 557 | 565 | 573 | 581 | 588 | 596 |
| | 0.31 | 050 | 064 | 079 | 093 | 107 | 121 | 136 | 150 | 164 | 178 | 6.0 | | 604 | 612 | 620 | 628 | 635 | 643 | 651 | 659 | 666 | 674 |
| 2.61 | | 193 | 207 | 221 | 235 | 249 | 264 | 278 | 292 | 306 | 320 | 6.1 | | 682 | 690 | 697 | 705 | 713 | 721 | 729 | 736 | 744 | 752 |
| 2.62 | ļ | 335 | 349 | 363 | 377 | 391 | 405 | 420 | 434 | 448 | 462 | 6.2 | | 759 | 767 | 774 | 782 | 789 | 797 | 805 | 812 | 820 | 827 |
| 2.63 2.64 | i | 476 618 | 490 632 | 505 | 519 | 533 | 547 | 561 | 575 | 589 | 603 | 6.3 6.4 | | 835 910 | 843 918 | 850 925 | 858 933 | 865 940 | 873 948 | 880 955 | 963 | 895 970 | 903 978 |
| 2.65 | | 759 | 773 | 646 787 | 660 801 | 674 815 | 688 829 | 702 843 | 716 | 730 | 744 | 6.5 | | 985 | 992 | 000 | 007 | 014 | 021 | 028 | 036 | 043 | 050 |
| 2.66 | | 899 | 913 | 927 | 941 | 955 | 969 | 983 | 857 997 | 871 011 | 885 025 | 6.6 | 0.7 | 058 | 065 | 073 | 080 | 087 | 095 | 102 | 110 | 117 | 124 |
| | 0.32 | 039 | 053 | 067 | 081 | 095 | 109 | 123 | 137 | 151 | 165 | 6.7 | | 131 | 138 | 145 | 153 | 160 | 167 | 174 | 181 | 189 | 196 |
| 2.68 | | 179 | 193 | 207 | 221 | 235 | 249 | 262 | 276 | 290 | 304 | 6.8 6.9 | | 203 274 | 210 281 | 217 288 | 224 295 | 232 302 | 239 309 | 246 316 | 253 323 | 260 330 | 267 338 |
| 2.69 | | 318 | 332 | 346 | 360 | 374 | 388 | 402 | 416 | 429 | 443 | 7.0 | | 345 | 352 | 359 | 366 | 373 | 380 | 386 | 393 | 400 | 407 |
| 2. 70 2.71 | | 457 596 | 471 610 | 485 624 | 4 99 637 | 513 651 | 527 665 | 540 679 | 554 693 | 568 707 | 582 720 | 7 1 | | 414 | 421 | 428 | 435 | 442 | 449 | 456 | 463 | 470 | 4 77 |
| 2.72 | | 734 | 748 | 762 | 776 | 789 | 803 | 817 | 831 | 845 | 858 | 7.2 | | 483 | 490 | 497 | 504 | 511 | 518 | 524 | 531 | 538 | 545 |
| 2.73 | ! | 872 | 886 | 900 | 913 | 927 | 941 | 955 | 968 | 982_ | 996 | 7.3 7.4 | | 552 620 | 559 626 | 565 633 | 572 640 | 579 646 | 586 653 | 592 660 | 599 666 | 606 673 | 613 680 |
| | 0.33 | 010 | 023 | 037 | 051 | 065 | 078 | 092 | 106 | 119 | 133 | 7.4 | | 687 | 693 | 700 | 706 | 713 | 720 | 726 | 733 | 740 | 746 |
| 2.75 | | 147 | 161 | 174 | 188 | 202 | 215 | 229 | 243 | 256 | 270 | 7.6 | | 753 | 760 | 766 | 773 | 779 | 786 | 792 | 799 | 806 | 812 |
| 2. 76 2.77 | | 284 420 | 297 434 | 311 448 | 325 461 | 338 475 | 352 488 | 366 502 | 379 516 | 3 9 3 | 407 543 | 7.7 | | 819 | 825 | 832 | 838 | 845 | 851 | 858 | 864 | 871 | 877 |
| 2.78 | | 556 | 570 | 584 | 597 | 611 | 488 624 | 638 | 651 | 529 665 | 543 679 | 7 8 7.9 | | 884 949 | 890 ass | 897 | 903 | 910 | 916 | 923 | 929 | 936 | 942 |
| 2 79 | | 692 | 706 | 719 | 733 | 746 | 760 | 773 | 787 | 801 | 814 | 8.0 | 0.8 | 013 | 955 019 | 961 025 | 968 032 | 974 038 | 981 044 | 987 051 | 993 057 | 000 063 | 006 070 |
| 2.80 | | 828 | 841 | 855 | 868 | 882 | 895 | 909 | 922 | 936 | 949 | 8.1 | | 076 | 082 | 089 | 095 | 101 | 108 | 114 | 120 | 126 | 133 |
| 2.81 | | 963 | 976 | 990 | 003 | 017 | 630 | 044 | 057 | 070 | 084 | 8.2 | | 139 | 145 | 151 | 158 | 164 | 170 | 176 | 183 | 189 | 195 |
| 2.82 2.83 | 0 34 | 097 | 111 | 124 | 138 | 151 | 165 | 178 | 191 | 205 | 218 | 8.3 2.4 | | 201 | 207 | 214 | 220 | 226 | 232 | 238 | 245 | 251 | 257 |
| 2.84 ; | | 232 366 | 245 379 | 259 393 | 272 406 | 285 419 | 299 433 | 312 446 | 326 459 | 339 473 | 352 486 | 8.4 8.5 | | 263 324 | 269 330 | 275 336 | 281 343 | 288 349 | 294 355 | 300 361 | 306 367 | 312 373 | 318 379 |
| 2.85 | | 500 | 513 | 526 | 540 | 553 | 566 | 580 | 593 | 606 | 620 | 8.6 | | 385 | 391 | 397 | 403 | 409 | 415 | 421 | 427 | 433 | 439 |
| 2.86 | | 633 | 646 | 660 | 673 | 686 | 700 | 713 | 726 | 739 | 753 | 8 7 | | 445 | 451 | 457 | 463 | 469 | 475 | 481 | 487 | 493 | 499 |
| 2.87 | | 766 | 779 | 793 | 806 | 819 | 832 | 846 | 859 | 872 | 886 | 88 | | 505 | 511 | 517 | 523 | 529 | 535 | 541 | 547 | 552 | 558 |

| r | | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 |
|------|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| 8.9 | | 564 | 570 | 576 | 582 | 588 | 594 | 600 | 605 | 611 | 617 |
| 9.0 | | 623 | 629 | 635 | 641 | 646 | 652 | 658 | 664 | 670 | 676 |
| 9.1 | | 681 | 687 | 693 | 699 | 705 | 710 | 716 | 722 | 728 | 734 |
| 9.2 | | 739 | 747 | 751 | 757 | 762 | 768 | 774 | 779 | 785 | 791 |
| 9.3 | | 797 | 802 | 808 | 814 | 819 | 825 | 831 | 837 | 842 | 848 |
| 9.4 | | 854 | 859 | 865 | 871 | 876 | 882 | 888 | 893 | 899 | 905 |
| 9.5 | | 910 | 916 | 921 | 927 | 933 | 938 | 944 | 949 | 955 | 961 |
| 9.6 | | 966 | 972 | 977 | 983 | 989 | 994 | 000 | 005 | 011 | 016 |
| 9.7 | 0.9 | 022 | 028 | 033 | 039 | 044 | 050 | 055 | 061 | 066 | 072 |
| 9.8 | | 077 | 083 | 088 | 094 | 099 | 105 | 110 | 116 | 121 | 127 |
| 9.9 | | 132 | 138 | 143 | 149 | 154 | 159 | 165 | 170 | 176 | 181 |
| 10.0 | | 187 | 192 | 198 | 203 | 208 | 214 | 219 | 225 | 230 | 235 |

From "Engineering Computations for Air and Gases" by Moss and Smith, Transactions A.S.M.E., Vol. 52, 1930, Paper APM-52-8

EXAMPLE:

Assume: $P_{T2}/P_{T1} = r = 1.82$

Air Flow = 290 CFM

 T_1 (inlet temperature = $92^{\circ}F = (92 + 460)^{\circ}R = 552^{\circ}R$

h c (from Figure 5) = 68%

Y (from table) = 0.18468


 T_i (ideal temperature rise) = $T_1 \times Y = 552 \times .18468 = 102^0$ ΔT_A (actual temperature rise) = $\frac{\Delta T_i}{h_c} = \frac{102}{.68} = 150^0$ T_2 (compressor outlet temperature) = $T_1 + \Delta T_A = 92 + 150 = 242^0 F$

Altitude chart

| Altitude Ft. | Air Press. in.Hg | °F | Standard Day | $\sqrt{\Theta}$ |
|-----------------|---------------------|--------|--------------|-----------------|
| Sea Level | 29.92 | 59.00 | 518.69 | 1.00 |
| 1000 | 28.86 | 55.43 | 515.12 | .997 |
| 2000 | 27.82 | 51.87 | 511.56 | .993 |
| 3000 | 26.81 | 48.30 | 507.99 | .989 |
| 4000 | 25.84 | 44.74 | 504.42 | .986 |
| 5000 | 24.90 | 41.17 | 500.86 | .982 |
| 6000 | 23.98 | 37.61 | 497.30 | .979 |
| 7000 | 23.09 | 34.05 | 493.73 | .975 |
| 8000 | 22.23 | 30.48 | 490.17 | .972 |
| 9000 | 21.39 | 26.92 | 486.61 | .969 |
| 10000 | 20.58 | 23.36 | 483.04 | .965 |
| 11000 | 19.80 | 19.79 | 479.48 | .962 |
| 12000 | 19.03 | 16.23 | 475.92 | .958 |
| 13000 | 18.30 | 12.67 | 472.36 | .954 |
| 14000 | 17.58 | 9.11 | 468.80 | .951 |
| 15000 | 16.89 | 5.55 | 465.23 | .947 |
| 16000 | 16.22 | 1.99 | 461.67 | .943 |
| 17000 | 15.58 | - 1.58 | 458.11 | .940 |
| 18000 | 14.95 | - 5.14 | 454.55 | .936 |
| 19000 | 14.35 | - 8.69 | 450.99 | .933 |
| 20000 | 13,76 | -12.25 | 447.43 | .929 |
| 21000 | 13.20 | -15.81 | 443.87 | .925 |
| 22000 | 12.65 | -19.37 | 440.32 | .921 |
| 23000 | 12.12 | -22.93 | 436.76 | .918 |
| 24000 | 11.61 | -26.49 | 433.20 | .914 |
| 25000 | 11.12 | -30.05 | 429.64 | .910 |
| 26000 | 10.64 | -33.60 | 426.08 | .906 |
| 27000 | 10.18 | -37.16 | 422.53 | .903 |
| 28000 | 9.741 | -40.72 | 418.97 | .899 |
| 29000 | 9.314 | -44.28 | 415.41 | .895 |
| 30000 | 8.903 | -47.83 | 411.86 | .891 |
| 31000 | 8.506 | -51.38 | 408.30 | .887 |
| 32000 | 8.124 | -54.94 | 404.75 | .883 |
| 33000 | 7.756 | -58.50 | 401.19 | .880 |
| 34000 | 7.401 | -62.05 | 397.64 | .876 |
| 35000 | 7.060 | -65.61 | 394.08 | .872 |
| 36000 | 6.732 | -69.16 | 390.53 | .868 |
| 37000 | 6.417 | -69.70 | 389.98 | .867 |
| 38000 | 6.117 | -69.70 | 389.98 | .867 |
| 39000 | 5.831 | -69.70 | 389.98 | .867 |
| 40000 | 5.558 | -69.70 | 389.98 | .867 |

Richard Twilley of Albuquerque, New Mexico, turbo-ed this 292 CID Chevy and held his own against V-8's on the regional sprintcar circuit. AiResearch T12 turbo once pressured a Caterpiller





Turbocharger failure analysis

by Robert Elmendorf, Service Engineer, Schwitzer

Despite the outward appearance of utter simplicity, the modern Diesel turbocharger is, in fact, the end product of a highly specialized technology, and though not readily apparent on first observation, the methods used in turbocharger manufacture have been brought to a high level of sophistication, particularly during the past two decades.

The greatest demands on this technology are made in the areas of metallurgy, dimensional tolerance control, and dynamic unbalance correction. The reasons for extreme emphasis in these areas are easy to appreciate, once the typical stresses acting on a turbocharger are known. In normal operation, then, gas introduction temperatures can easily exceed 1,000° F, rotative speeds can run above 70,000 RPM, and the internal power of the turbocharger can approach values equivalent to the flywheel horsepower of the engine.

It is known even to most neophytes that turbocharger failures are inherently expensive, and have a devastating effect on engine performance. It is a widespread misconception even among the seasoned "experts", however, that all turbocharger failures occur instantaneously of primarily internal causes, and are therefore unpreventable; on the contrary, the vast majority of failures are the direct result of faulty engine maintenance or operation, and many are progressive in nature.

It is the purpose of this bulletin to acquaint the owner or operator of a "turbo"-equipped engine with the several categories of common failure, to help him recognize the symptoms associated with each, and hopefully, to enable him to avoid the expense and aggravation of repetitive failures. However, to develop a complete and well-rounded turbocharger service program, it is suggested that the information contained herein be supplemented with the wealth of routine and preventive maintenance information available for both the complete engine and the turbocharger assembly alone.

FAILURES RELATED TO FAULTY LUBRICATION

Oil plays a vital role in the life of a turbocharger, because it serves the triple function of lubricating, cooling and cleansing many of the most critical and highly stressed parts in the assembly.

Even momentary interruptions in the supply of high quality lubrication can produce disastrous results, but particularly under conditions of high speed or heavy load.

There are several facets to proper turbocharger lubrication, and as a consequence, a deficiency of any one aspect usually produces a specific symptom.

Abrasive Contamination—The presence of sufficient abrasive material in the lubricating oil will result in wear of the various bearing surfaces, and is usually most prevalent on the thrust bearing and outside diameters of the shaft bearings. Occasionally, the abrasive particles are so small that they escape the centrifuge effect of the rapidly spinning bearings; in such a case, considerable scouring of the journal sections of the rotor shaft might be noted.

The depth of scratching and amount of wear can vary widely, and depend primarily on the degree and nature of the contaminant, the operating time accumulated with the contaminant present, and the severity of engine operation.

Insufficient Pressure or Flow—It is essential that a sufficient quantity of oil flow through the turbocharger at all times to ensure suspension and stabilization of the full floating/rotating bearing system, and to continually wash heat from the unit, thereby keeping internal temperatures within workable limits.

The most frequently seen damage that can be related to insufficient oil flow is the result of what might be termed the "oil lag syndrome." This involves a faulty operating habit, in which a cold turbocharged engine is started and immediately taken to a condition of high speed or heavy load. In such a case, the rotative speed of the turbocharger approaches the peak allowable value before an effective oil cushion is established to sustain the bearings. The result is rotor gyration (often called "shaft motion" or "whirl") with attendant distress of the bearings.

Marginal oil flow—that in which sufficient oil is circulating to prevent a sudden failure—can also produce detrimental effects, the most notable of which is the gradual accumulation of varnish on internal surfaces, which makes unit disassembly quite difficult.

Improper Oil Type or Lack of Change at Recommended Intervals—The principal condition noted when either of these conditions exist is generalized sludge or varnish formation on the internal surfaces of the turbocharger; these are usually found to be heaviest at the turbine end of the unit, because the higher prevailing temperature in that area results in accelerated loss of the volatile oil components.

In certain applications, this varnish formation causes eventual seal ring fouling and wear, and can only be corrected by complete unit teardown and replacement of the turbine wheel-and-shaft assembly; this is a very expensive proposition, at best.

FAILURES RELATED TO FOREIGN MATERIAL INTAKE

The vulnerability of a turbocharger will become instantly apparent the first time a particle of significant size is inducted into either the compressor or turbine section with the unit at speed.

The sources and types of air-and exhauststream contamination are many and varied, but can range from atmospheric sand and dust (through the compressor) to engine valve fragments (through the turbine).

The point of foreign material entry usually becomes apparent as soon as the core has been separated from the compressor cover and turbine housing; though the damaging particle is seldom present or intact, some clue as to its size and type can usually be gained by close inspection of the involved wheel.

The secondary effects of high speed particle impact on either wheel are usually visible throughout the unit, but tend to focus on the bearings, which suffer from both the initial gyration and the running unbalance condition which follows:

FAILURES RELATED TO HIGH EXHAUST TEMPERATURES OR UNIT OVERSPEED

The procedure employed in the matching of a turbocharger to a particular engine is part of the specialized technology mentioned in the introduction to this bulletin, and always includes a live proofing session in the lab, using an actual engine under closely controllable conditions.

The reasons for this final precautionary measure are simple: As a free-wheeling device with intense and tremendous internal power, a mismatched turbocharger could easily "run away", damaging the engine and creating a threat to the well-being of the bystanders and attendants.

As seen in the field, mismatched engine/ turbocharger combinations are most often the result of an attempt to boost power output by means of various "adjustments", such as fuel rate tampering, indiscriminate compressor or turbine nozzle changes, or even the application of complete turbochargers to engines arbitrarily. Any of these attempts can cause overspeed damage to the bearing system of a turbocharger, distortion, warpage or erosion of the turbine wheel casting, and heat damage to such other engine components as piston crowns, valves and exhaust manifolds.

ACKNOWLEDGEMENTS

If this book were about reciprocating engines or gas turbines, a good portion of the information could have been gleaned from existing literature because of the many books and papers on these subjects. Although a few technical papers have been published, modern books on turbocharging are almost nonexistant. Turbocharger development has progressed over the last 35 years mainly because of better materials. For this reason and the fact that the thermodynamic principles do not change, the work done by Büchi in the early 1900's and Ricardo in the 1920-1930's is still valid

I was fortunate in receiving a lot of useful information from the turbocharger manufactuers. AiResearch, Rajay, Roto-Master and Schwitzer all contributed pictures and technical information. The performance outlets of these manufacturers have also graciously helped. Don Hubbard of Crane Cams authored a manual detailing how to turbocharge an engine with Schwitzer Turbochargers. I borrowed quite a few installation tips and illustrations from this manual. Ak Miller and his cohorts Jack Lufkin, Bill Edwards and Jon Meyer were more than cooperative.

George Spears of Shelby-Spearco and Spearco Performance provided many excellent pictures and helped me get pictures of his customers' installations. Bob Keller of Accel Performance Systems added much useful information. Gale Banks has been diligent in making superbly engineered marine installations and in taking professional photographs of them. He also spent several days working on the cover photo engine with Publisher Bill Fisher and Art Director Josh Young.

Crown Manufacturing has been one of the pioneers in turbocharging engines and producing kits. President Derek Torley has the same enthusiasm toward turbochargers as did founder Ted Trevor when he owned the company. Derek gave me numerous pictures and a lot of data.

John Gaspari sells Rajay Turbochargers all over the world for TRW International. He has faithfully sent pictures and other information from many countries.

M & W Gear is an important manufacturer in marine turbocharging. Jack Bradford, their Chief Engineer, has been turbocharging diesel and gasoline engines since about 1960 and really knows how to make complete bolt-on kits.


In case you get the idea that turbocharging is strictly a United States exclusive, David Inall of Tetetrin in Australia and David Vizard of England tried hard to convince me otherwise. Both sent much information and photos.

Tom Scahill became interested in turbocharging when he helped Howard Arneson install them on his off-shore racing boat. Since then Tom has established quite a reputation doing custom installations.

Vince Piggins, Bill Howell and John Pierce of Chevrolet Engineering sent us several excellent pictures of experimental installations.


Doug Roe's hints about installations will be helpful to the old timer as well as the novice.

Last and certainly not least my wife, Betty Jane typed every word of this book at least twice and put up with me in the process.




Underside of turbo on a 7.5 c.r. Chrysler Avenger/Cricket head. Large valves are only needed for maximum power for a given amount of boost. Large exhaust valves are most effective with a waste gate or a large A/R ratio housing with no built-in exhaust restriction. Tuned exhaust systems do not help a turbo setup but a strong manifold for turbo support—especially for off-road use—is a very fine idea.


Advantages of using a sophisticated highperformance carburetor like the Dellorto are three-fold: Accurate calibration is easy with available jets; by blocking off accelerator-pump action in one barrel, water injection can be applied through the pump jet in that barrel; and interchangeable venturis provide a good way to limit the boost. 25mm venturis gave 202 HP from 90 CID in this instance. Note vacuum take off for the brake servo on the carb manifold to turbo (arrow). On a suckthrough system, this is the only place to connect vacuum-powered accessories. Installation and photo by David Vizard, author of How to Modify Your Mini (another H. P. Book).





Rajay provided this chart showing typical horsepower increases for turbocharged passenger-car engines at various levels of boost.



Doug Fraser Racing Engines uses this chart for quickly calculating which turbocharger compressor size to use with various engine sizes and RPM levels.







STANDARD TURBINE HOUSING SIZES


A/R


.68

.81

.96

AiResearch TO4 Turbocharger Outline






- All dimensions are for reference and installation purposes only.
- 2. Turbocharger to be mounted from turbine-inlet flange.
- 3. For additional installation recommendations, consult manufacturer.
- 4. Connections to compressor inlet, compressor outlet and turbine outlet should be such that loads imposed on the compressor and turbine housings by misalignment, vibration, shock and thermal expansion will be negligible.
- 5. Position of turbine and compressor housings as shown: compressor of = 270°; turbine $\beta = 0^{\circ}$.
- 6. Oil supply to turbocharger to be engine oil which has been filtered by a full-flow filter of 20-micron maximum rating. Recommended minimum I.D. of oil supply line is [6.35].25. Oil pressure at turbocharger oil inlet to be [2.11 Kb/Sq.Cm] 30 PSIG minimum at peak torque speed and above and no lower than [0.70 Kg/Sq.Cm] 10 PSIG at low idle.


- 7. For connection to compressor inlet, a conical straight diffuser with maximum included angle of 7° is recommended for best performance (length as installation permits or diameter of 2.94 inch is reached).
- 8. For connection to turbine outlet, a conical straight diffuser with maximum included angle of 14⁰ (length as installation permits of diameter of 4,00 inch is reached).
- Installed centerline of oil outlet should be within 35° of the vertical centerline. Oil-return line must drain by gravity under all operating conditions. Recommended minimum I.D. of oil-drain tube is 0.750 inch.


STANDARD TURBINE HOUSING SIZES


| A/R | Part No. |
|------|----------|
| .68 | 408700-4 |
| 1,2 | 408700-1 |
| 1.39 | 408700-2 |
| 1.58 | 408700-3 |

AiResearch TE0670 Turbocharger Outline












Rajay Model 301F Turbocharger Installation Drawing




in any rotational position about the shaft \mathbb{Q} . Bearing housing can be assembled in any of twelve positions for proper oil inlet and outlet locations. Oil inlet and drain may be located up to 45° from vertical \mathbb{Q} .

1. Turbocharger is to be supported by the exhaust gas inlet flange.







Rajay Model 304E Turbocharger Installation Drawing

TURBOCHARGER MANUFACTURERS

AiResearch Industrial Division

3201 Lomita Blvd.

Torrarce, California 90505

213/530-1981

Manufactures many sizes of turbochargers used on all types of equipment. Sells to engine manufacturers or through distributors, Some models and spare parts can be purchased through equipment dealers.

Holset Corp.

500 S. Poplar

PO Box 645

Seymdur, Indiana 47274

812/522-4052

Manufactures medium-size turbochargers for Cummins Engines (USA). Complete units and spare parts available through Cummins dealers and distributors.

AiR Rajay Industries, Inc.

PO Box 207

Long Beach, California 90801

213/426-0346

Manufactures small turbochargers for all uses.
Sells though distributors and engine converters.

Roto-Master, Inc.

13402 Wyandotte Street North Hollywood, California 91605

213/875-0634

HO

Manufactures replacement turbochargers equivalent to AiResearch and Cummins Models.

Manufactures complete turbocharger kits for Cummins Engines. Conducts schools for distributors and dealers to teach them how to identify the correct turbocharger and parts for each application; covers disassembly and assembly for all models of turbochargers.

RA

R-M

Schwitzer Division

Wallace-Murray Corp. 1125 Brookside Ave.

Indianapolis, Indiana 46206

312/636-3311

Manufactures turbochargers for many types of equipment. Sells to engine manufacturers and through distributors.

SC

TURBOGHARGER DISTRIBUTORS

Check with these distributors for your nearest dealer.

ALABAMA

Alapama Diesel Co. (RA) 3328 6th Ave. South Birmingham AL 35222 205/324-4406

ARIZONA

Charles W. Carter Co. (SC) 1717 W. Roosevelt St. Phoenix, AZ 85007 602/252-4073

Industrial Parts Depot (R-M) 1143 N. 27th Ave. Phoenix, AZ 85009 602/272-0486

ARKANSAS

Taylor Diesel Service, Inc. (RA) 2120 E, Broadway PO Box 5881 North Little Rock, AR 72119 501/945-2326

CALIFORNIA

Charles W. Carter Co. (SC) 2456 Whipple Road Hayward, CA 94544 415/471-8622

Charles W. Carter Co. (SC) 2221 E. Washington Blvd. Los Angeles, CA 90021 213/589-3111

Custom Turbo Rebuilding (R-M) 13028 E. Los Nietos Rd Santa Fe Springs, CA 90607 213/944-1279

Diesel Control Corp. (RA) 226 Marine Ave. PO Box 1116 Wilmington, CA 90744 213/835-5651

DIFACO, Inc. (RA) 1390 Rollins Rd. Burlingame, CA 94010 419/342-6057

Drake Engineering & Sales Corp. (AiR) 17502 Daimler St. Santa Ana, CA 92705 540-9530 Fuel Injection Engineering (AiR) 25891 Crown Valley Parkway South Laguna, CA 92677 714/831-1170

Industrial Parts Depot (R-M) 1309 W. Sepulveda Blvd Torrance, CA 90501 213/775-6467

Ak Miller Garage (AiR) 9236 Bermudez St Pico Rivera, CA 90660 213/949-2548

Oakland Diesel Distributors, Inc. (RA) Primentel and Sons 6450 Bay St.

6450 Bay St. Emeryville, CA 94608 415/655-7442

R.M. Distributing (R-M) 3401 Investment Blvd. Suite 7 Hayward, CA 94545 415/783-4700

R.M. Distributing Co. (R-M) 1489 E. Sunset PO Box 1314 Tulare, CA 93274 209/688-2019

Shelby-Spearco Distributing Co., Inc. (RA) 2054 Broadway Santa Monica CA 90404

Santa Monica CA 90404 213/829-1577

Master distributor Rajay turbochargers for automotive, cycle and marine uses.

Turbochargers, Inc. (SC, RA) 12215 S. Woodrulf Ave. Downey, CA 90241 213/773-1880

Turbochargers, Inc. (SC, RA) 701-29C Kings Row San Jose, CA 95112 408/275-6216

Turbo Sales International (R-M) PO Box Y Agoura, CA 91301 213/889-7450

COLORADO

Central Motive Power, Inc. (R-M, SC, RA) PO Box 17128 T.A. 6301 N. Broadway Denver, CO 80217 303/428/3611 Mitchcon Corp. (SC)

Mitchcon Corp. (SC 8109 E. 39th Ave. Denver, CO 80207 303/333-2317

CONNECTICUT

ACCEL (AIR) PO Box 142 Branford, CT 06405 203/488-7241

FLORIDA

Burgman Supply Co. (R-M) 2600 W. Beaver St. Jacksonville, FL 32005 904/389-5516

Interstate Dieselect, Inc. (R-M, SC, RA) 4220 N. Orange Blossom Trail Orlando, FL 32804 305/293-7971

GEORGIA

Diesel Equipment & Parts (SC) 986 White St. Ext. Atlanta, GA 30310 404/758-7588

HAWAII

Charles W. Carter Co. (SC) 1299 Kaumuahi St. Honolulu, HI 96817 808/841-2888

ILLINOIS

Illinois Auto Central, Inc. (R-M) A Division of IAE Co 4750 S. Central Ave. Chicago, IL 60638 312/582-6200

Illinois Auto Electric (R-M) 656 County Line Rd. Elmhurst, IL 60126 312/833-4300 National Industrial Supply Co. (R-M) 1120 Ulinois Ave. E. St. Louis, IL 62201 314/621-0350

Precision Industrial Corp. (SC, RA) 60 Gordon St. Elk Grove Village, IL 60007 312/439-9122

W.M. Hales, Co. (R-M) 700 Commerce St PO Box 65 Danville, 1L 61832 217/446-7770

INDIANA

Turbo & Diesel Component, Inc. (R-M, SC) 444 W. Troy Ave. Indianapolis, IN 46225 317/783-5451

IOWA

Howell Auto Parts, Inc. (R-M, SC) 1410 Locust St. Des Moines, IA 50309 515/288-2256

M.M. Supply Co., Inc. (R-M) PO Bax 5008 Des Moines, IA 50306 515/288-0192

KENTUCKY

Diesel Injection Service, Inc. (R-M, RA) 4710 Allmond Ave. Louisville, KY 40221 502/361-1181

Republic Diesel Truck & Machine (SC) 305 E. College St. Louisville, KY 40203 502/585-5281

LOUISIANA

Gerhardt's Inc. (RA, R-M, SC) 819 Central Ave. PO Box 10161 Jefferson, LA 70181 504/733-2500

Vaughn & Bush, Inc. (R:M, RA) 1050 Crimmet Dr Shreveport, EA 71102 318/222-8432

MARYLAND

8 & D Fuel Injection Service (SC) 4800 Stamp Road Temple Hills, MD 20031 301/899-1626

Baltimore Diesel, Inc. Branch of B & D 6110 Holabird Ave. Baltimore, MD 21224 301/633-5186

MASSACHUSETTS

C.A. Krohne & Son (R-M, SC, RA) 500 W. Columbus Ave. Springfield, MA 01105 413/781-5824

MICHIGAN

Diese Equipment Sales & Service (RA) 578 E. Main St. Potterville, MI 48876 517/645-7648

MINNESOTA

Diese Service Co. (RA, SC) 1253 Eagan Industrial Rd. St. Paul, MN 55121 612/454-5530

MISSISSIPPI

J & H Diesel Service, Inc. (SC, R-M, BA) PO Bbx 5261, Highway 80 East Greenville, MS 38701 601/378-8711

J & H Turbo Service (SC, R-M, RA) 2620 S. Gallatin Jackson, MS 39204 601/353-1030 Taylor Diesel Service, Inc. (RA) 544 Eason Blvd. Tupelo, MS 38801 601/842-6400

MISSOURI

Diesel Fuel Injection, Inc. (RA) 9331 Broadway St. Louis, MO 63125 314/631-2500

Gooch Brake & Equipment Co. (R-M) 531 Grand Ave. Kansas City, MO 64106 816/421-3085

Taylor Diesel Service, Inc. (RA) PO Box 294 Sikeston, MO 63801 314/471-8224

White Tractor Parts & Equipment Co. (RA, SC) PO Box 206, Highway 40 Blue Springs, MO 64015 816/229-3411

MONTANA

Gomer's Diesel & Electric Service (RA) 308-2nd Ave., S. Great Falls, MT 59405 406/761-5531 Gomer's Diesel & Electric Service (RAI Highway 10 West

Highway 10 West 2203 Park St. Missoula, MT 59801 406/728-7620

Original Equipment, Inc. (SC) 905-2nd Ave., N PO Box 2135 Billings, MT 59103 406/245-3081

NEBRASKA

M.M. Supply Co. (R-M) 8615 "G" St. Omaha, NE 68122 402/331-0636

RPW (RA) 7402 "L" Street Omaha, NE 68103 402/339-6966

NEVADA

Sierra Diesel Injection, Inc. (R-M) 2525 Mill St. Reno, NV 89501 702/329-4232

NEW JERSEY

The Nycal Co., Inc. (R-M) 240 S. Main St. Hackensach, NJ 07606 201/489-0200

NEW MEXICO

Central Motive Power, Inc. (R-M, SC, RA) 808-2nd St., N.W. PO Box 1924 Albuquerque, NM 87102 506/247-0184

NEW YORK

Donnelly Diesel Service, Inc. (RA, SC) 133 Hopkins St. Buffalo, NY 14220 716/823-2525

Flagship Marine Eng. Co. (AiR) 159 S. Main St. Freeport, NY 11520 516/378-7001

McGlynn Diesel Service, Inc. (SC, RA) 827 W. Merrick Rd. Valley Stream, L. L., NY 11580 516/561-2203

NORTH CAROLINA

Diesel Equipment Co. (RA) PO Box 4227 212 Atwell Ave. Greensboro, NC 27406 919/275-0701 Diesel Injection Sales & Service (R-M) 4209 N. Graham St. Charlotte, NC 28201 704/596-6010

Diesel Injection Sales & Service (R-M) PO Box 5605 Highway 54 West Rateigh, NC 27607 919/851-1220

Diesel Injection Sales & Service (R-M) 3853 Patterson Ave. PO Box 10476 Winston-Salem, NC 27108 919/722-1196

NORTH DAKOTA

Beyer Cement, Inc. (SC) 809-16th Ave, S.W. PO Box 992 Valley City, ND 58072 701/845-2421

оню

Columbus Diesel Supply Co. (RA) 201 N. 4th St. Columbus, OH 43215 614/228-6663

Paramount Supply Co. (R-M, SC) 3535 Roundbottom Rd. Cincinnati, OH 45244 513/271-6810

Paramount Supply Co. (R-M, SC) 13688 York Rd. Cleveland, OH 44133 216/237-9164

Paramount Supply Co. (R-M, SC) 1270 Edgehill Rd. Columbus, OH 43212 614/294-5661

Turbo-Systems, Inc. (RA) 1817 N. Medina Line Rd. Akron, OH 44313 216/666-3503

OKLAHOMA

Industrial Ignition (RA) 1808 N.W. 2nd Oklahoma City, OK 73106 405/235-3788

Thompson's Diesel Fuel Injection Spec. (R-M) 2728 N.W. 10th St Oklahoma City, OK 73107 405/943-8536

Thompson's Diesel Fuel Injection Service (R-M) 10338 "B" Place Tulsa, OK 74145 918/663-7666

OREGON

Air Flow Systems, Inc. (SC) 842 S.E. Ochoco St. Portland, OR 97202 503/659-9120

PENNSYLVANIA

D & D Rebuilding, Inc. (SC) 618-18th Ave. New Brighton, PA 15066 412/846-1290

Penn Diesel Service Co. (SC, RA) RD 3, 8ox 624 Harrisburg, PA 17112 717/545-4207

Penn Diesel Service Co. (SC, RA) Rt. 93, RD 1 Hazleton, PA 18201 717/454-2426

Philadelphia Diesel, Inc. (R-M, RA) 2525 Orthodox St. Philadelphia, PA 19137 215/743-3773

SOUTH CAROLINA

The Turbo Center, Inc 6819 Rivers Ave. PO Box 10203 Charleston, SC 29411 803/797-7321

TENNESSEE

Diesel Sales & Service (R-M, SC, RA) 2236 McCalla Ave. Knoxville, TN 37915 615/546-7751

Diesel Sales & Service (R-M, SC, RA) 103 Jubilee Dr. Chattanooga, TN 37421 615/894-4050

Diesel Sales & Service (R-M, SC, RA) 423 W. Main St. Johnson City, TN 37601 615/928-1661

Diesel Sales & Service (R-M, SC, RA) 928 Main St. Nashville, TN 37206 615/227-2242

Taylor Diesel Service, Inc. (RA) 1075 S. 3rd St. PO Box 769 Memphis, TN 38101 901/948-4467

TEXAS

Diesel Injection Service of West Texas (RA) 1001 Slaton Rd. Lubbock, TX 79408 806/745-4122

Fleet & Industrial Warehouse (SC) 1901 Lever St. Dallas, TX 75207 214/748-7811

Gerhardt's, Inc. (SC, R-M, RA) PO Box 36334 5601 Braxton Dr. Houston, TX 77036 713/789-8860

Machinery & Parts Corp. (R-M) 1357 N. Walton Walker Dallas, TX 75211 214/333 6541

Texas Fuel Injection Service (RA) 4828 Calvert St. Dallas, TX 75247 214/631-0127

Tractor Parts & Supplies (R-M) 155 N. San Marcial El Paso, TX 79905 , 915/544-1576

UTAH

Industrial Power (RA) 145 N. Highway 89 North Salt Lake City, UT 84054 801/292-4898

VIRGINIA

Virginia Diesel Service, Inc. (R-M, SC, RA) 1120 Bruce St. Richmond, VA 23224 804/232-8988

WASHINGTON

Hatch & Kirk, Inc. (R-M, RA) 5111 Leary Ave., N.W. Seattle, WA 98107 206/783-2766

Pacific Diesel Co. (RA) 340 W. Nickerson Seattle, WA 98119 206/283-1011

WEST VIRGINIA

Craig Motor Service Co., Inc. (R-M, SC) 131 W. Pike St. PO Box 1420 Clarksburg, WV 26301 304/623-3421

WISCONSIN

Diesel Specialists, Inc. (R-M) 620 Clark Hinkle St. PO Box 3045 Green Bay, WI 54303 414/499-1475 Fuel Systems, Inc. (SC, RA) 12730 Robin Lane Brookfield, WI 53005 414/781-4353

WORLDWIDE EXCEPT U.S.A., CANADA & MEXICO

TRW International S.A. (RA) 8001 E. Pleasant Valley Rd. Cleveland, Ohio 44131 216/383-5557

ARGENTINA

Comblac S.A. (R-M) LaValle 422-8P Buenos Aires, Argentina Tel. 32-0619

AUSTRALIA

Boustead Wood Pty. Ltd. (R-M) 407 City Road South Melbourne, Victoria Tel. 69-7501

BRAZII

Turboex Com. E. Ind. S.A. (R.M) 04765-Rua Laguna, 136 Santa Amaro Sao Paulo, SP. Brazil Tel. 269-2846

CANADA

Brake-Drome Co. Ltd. (R-M) 2242 Alpha Ave. Burnaby, B.C. 604/299-6536

Brake-Drome Co. Ltd. (R-M, RA) 5760-11th St. S.E. Calgary, Alberta T2G0S8 403/253-7501

Brake-Drome Co. Ltd. (R-M) 8305 Davis Road Edmonton, Alberta T6E4N3 403/465-5261

Brake-Drome Co. Ltd. (R-M) 419 Mount Paul Way Kamioops, B.C. 604/374-6125

Engine Air Co. Ltd. (SC, RA) 1860 Powell St. Vancouver, B.C. 604/253-1022

Industrial Track & Turbo, Inc. (R-M) 196 Arvin Ave. Stoney Creek, Ontario 416/561-2651

Traction Specialties, Ltd. (RA) 4915 Cote Vertu St. Laurent, Ontario 514/331-9262

UAP Co. (RA, R-M, SC) , Ltd. (SC, R-M, RA) 6500 St. James St. West Montreal, Quebec 514/481 5611

UAP Co. (SC, R-M, RA) Ltd. (SC, R-M, RA) Hydraulic and Turbocharger Div. 6500 St. Jacques Quest Montreal, Quebec 514/481-5611

United Diesel Injection, Ltd. (RA, R-M, SC) 4210-103rd St. Edmonton, Alberta T6E4T3 403/434-8517

ENGLAND

Schwitzer Engineered Components (SC) Wallace Murray Ltd. Elmfield Industrial Estate Leeds LS 134 UD Pudsey (09735) 63232 Tel. 556-465

HOLLAND

Thalco, B.V. (R-M) 4, Eendrachtsplein Rotterdam - 3002 Tel. (010) 13 36 80

INDIA

Components & Machinery (R-M) 9/12 Lal Bazar St. Calcutta - 1 Tel. 22-3213

IRAI

Sherkat Sahami, Jam (R-M) Jam Building, Second Floor Suite 201 Roosevelt Avenue Teheran Tel. 822-215

ISRAEL

Automotive Ltd. (R-M) 18, Harbbaa St. Tel-Aviv Tel. 266-370

MALAYSIA

United Motor Works (R-M) Batu Tiga Industrial Estate Shah Alam Selangor Tel. 361-911

MEXICO

Ital-Diesel, S.A. (R-M) Alfredo Robles Dominguez 262 Mexico 15 D.F. Tel. 5-17-45-71

Sociedad Electro Mecanica, S.A. de C.V. (RA) Manuel Maria Contreras 25 Apartado Postal 42-164 Mexico 4, D. F. Tel. 5-66-36-00

Turbos y Refacciones, S.A. de C.V. (R-M) Av. De Las Granjas No. 574 Mexico 16, D.F. Tel. 561-09-13

NEW ZEALAND

Diesel Services (CHCH) Ltd. (R-M) 65 Blenheim Road Riccarton, Christchurch Tel. 448-825

PERL

Auto Servicios Electricos, S.A. (R-M) Av. Mexico 397 Apartado 3239 Lima 1 Tel: 24-0906

PHILIPPINES

Capricorn Associated Supplier (R-M) 2637 Taft Ave. Malate, Manila D-406 Philippines Tel. 58-22-84


SOUTH AFRICA


Associated Diesel Co. (Pty) Ltd. (R-M) CHR/HV Bree & Saver Sts. Johannesburg Tel. 834-7451

VENEZUELA

Ingenieria de Combustion, C.A. (R-M) Apartado 5255 Caracas Tel. 81-27-31-AL35

Turbo Diesel Nacionales, C.A. (Tudina) Avenida Intercomunal de Antimano (R-M) Carapa-Caracas Tel. 497-893





Bill Schroeder, left, drives this turbo-ed 74 CID Harley for owner, Duane Nealen, of Northfield, Ohio. A torque converter buried in hub of rear wheel makes the bike easier to control on the starting line.



Joe Haile, Sr. and Jr. have been turbocharging Harley-Davidson bikes since 1970. Unfortunately, there is no convenient place to hide the turbo, as is the case on Hondas and Kawasakis.

TURBO KIT MAKERS & INSTALLERS

Accel Performance Systems Echlin Mfg. Co. Box 142 Branford, CT 06405 203/488-7241

500 Carlingview Dr. Rexdale, Ontario M9W5H1 Canada 416/677-4780

Passenger-car kits

American Turbo-Pak 2141 S. Hathaway Santa Ana, CA 92705 714/557-7004

Motorcycle kits

Aviaid Metal Products 7570 Woodman Pl. Van Nuys, CA 91405 213/786-4025

Allison engine installations. Oil-scavenge pumps for turbocharged engines.

Blake Enterprises, Inc. Rt. 1, Box 403 Muskogee, OK 74401 918/683-2967

Motorcycle turbo kits, wastegates for autos, boats & motorcycles.

Gale Banks Racing Engines 929 S. San Gabriel Blvd. San Gabriel, CA 91776 213/285-3107

Marine engine kits & installations

Bob's Automotive 14402 Hawthorne Blvd. Lawndale, CA 90260 213/679-1191

Kits for most cars and trucks, marine installations

Checkpoint America 2555 S. Hanley St. Louis, MO 63144 314/644-2440

Passenger-car kits

Cooley Racing Enterprises 9748 J Cozycroft Ave. Chatsworth, CA 91311 213/368-1618

Allison engines for racing boats & tractor pulling

Corsa Enterprises 14444 Lanark Van Nuys, CA 91406 213/994-3010

Corvair installations

Crane Cams, Inc. PO Box 160 Hallandale, FL 33009 305/927-4261

Kits & Schwitzer turbos for performance engines

Crown Manufacturing Co. 858 Production Pl. Newport Beach, CA 92660 714/642-7391

Passenger-car kits

DFRE, Inc. Beringer Way Marblehead, MA 01945 617/631-2500

Kits, engine development & testing Northeast distributor for Shelby-Spearco & Rajay products

Daigh Automotive Engineering Co. 201 W. D St. Wilmington, CA 90744 213/549-0840 Installations

Demar Ray Engine Works
9036 Long Point
Houston, TX 77055
713/465-8445
Southwest distributor for Shelby-Spearco &
Rajay products

Don's Werkstatt 860 N. E. Cleveland Gresham, OR 97030 503/665-5252

Northwest distributor for Shelby-Spearco & Rajay products

Far East Trading Co. Ltd. Makajima Building Motoazbu 1-Chome Minato-Ku Tokyo Japan 106 Tel. 452-0705

Passenger-car kits

Joe Haile 4824 Arcola North Hollywood, CA 91601 213/763-4514

Motorcycle kits

Kolb Diesel Service RR 2, Box 146 703A S. Barker Ave. Evansville, IN 47712 812/464-9141

Tractor-pulling installations

M & W Gear Co. Gibson City, IL 60936 217/784-4261

Kits for diesel farm tractors, also bolt-on kits for gasoline marine engines. Contact them for local distributor.

Ak Miller Garage 9236-38 Bermudez St. Pico Rivera, CA 90660 213/949-2548

Passenger car, trucks & racing kits & installations

Modified Sports Cars Friendship Station Washington, D.C. 20016 202/966-8552

Wastegates

Performance First Marine 1424 E. St. Gertrude Santa Ana, CA 92705 714/751-3720 Passenger, race-car and marine installations Raba Turbos Z1 Performance Products 26121 Van Born Rd. Taylor, MI 48180 313/291-5030 Motorcycle kits, custom auto installations Wastegates

Race-Aero 23946 Hawthorne Blvd. Torrance, CA 90505 213/378-1400 Marine kits & intercoolers

Bill Reiste 1352-13th Ave. SW Great Falls, MT 59404 406/453-2757 Custom automotive installations

Scottsdale Automotive Specialists 3428 N. Scottsdale Rd. Scottsdale, AZ 85251 602/945-1177 Custom auto & marine installations

Shelby Spearco Distributing Co., Inc. 2054 Broadway Santa Monica, CA 90404 213/829-1577 Street, track & marine kits

Teterin Engineering Pty Ltd. 96 Fern St. Islington, New Castle NSW 2296 Australia Tel. 61-4131 Street, track & marine kits & installations

The Turbo Shoppe 310 Juanita Colorado Springs, CO 80930 303/473-7667 Mountain states distributor for Shelby-Spearco & Rajay products

Tom's Turbos 767 Lincoln Ave. No. 10 San Rafael, CA 94901 415/457-9389

Marine-engine kits, installations & intercoolers

Turbo Power Box 2585 Oakland, CA 94614 415/562-8397

Passenger-car kits & installations

Turbo Systems, Inc. 1817 N. Medina Line Rd. Akron, OH 44313 216/666-3503

Passenger-car kits

Turbocharger, Inc. 12215 S. Woodruff Downey, CA 90241 213/773-1880

Mercedes & Peugeot diesel car kits

Wilcap Co. 2930 Sepulveda Box 3366 Torrance, CA 90510 213/326-9200

Installs turbocharged diesel engines in passenger cars & light trucks